




Model GVJ01Z Parts List

Item#	Part#	Description	Q'ty
001	183W96-5	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2
	C20 8066F9-6	SWITCH LABEL	2
	C30 8057M4-8	CAUTION LABEL	1
	D10	INC. 57	
002	620J88-0	CONTROLLER	1
003	652069-6	FLAT HEAD SCREW M3X6	3
004	632P65-6	TERMINAL UNIT	1
005	266490-9	TAPPING SCREW PT 2X6	3
006	858U19-7	GVJ01 SERIAL NO. LABEL	1
007	629B64-3	STATOR	1
008	210039-7	BALL BEARING 695DDW	1
009	519769-0	ROTOR ASS'Y	1
	D10	INC. 8,10	
010	210059-1	BALL BEARING 6000DDW	1
011	142111-6	GEAR HOUSING COMPLETE	1
	C10 263002-9	RUBBER PIN 4	1
012	252171-1	SQUARE NUT M5-8	1
013	286032-3	CAP 5	1
014	233139-6	COMPRESSION SPRING 3	1
015	272280-0	LEVER 17	1
016	961018-5	STOP RING E-5	1
017	268063-4	PIN 4	1
018	142110-8	RETAINER COMPLETE	1
019	442195-7	GASKET	1
020	253196-8	FLAT WASHER 6	1
021	346688-5	PUSH PLATE	1
022	454484-8	SEAL PLATE	1
023	313260-8	BALANCE PLATE	1
024	142109-3	GEAR COMPLETE	1
025	212092-9	NEEDLE BEARING 407	1
026	253715-0	FLAT WASHER 6	1
027	961002-0	RETAINING RING S-6	1
028	310837-0	SLIDER	1
029	961017-7	STOP RING E-3	1
030	268090-1	PIN 4	1
031	232207-2	LEAF SPRING	1
032	911111-5	PAN HEAD SCREW M4X10 WITH W	4
033	214031-5	PLANE BEARING 4	1
034	256117-9	PIN 4	1
035	347B50-9	LINEAR GUIDE	1
036	141R27-0	GEAR HOUSING COVER COMPLETE	1
037	266034-5	TAPPING SCREW CT 4X16	4
038-1	265132-2	PAN HEAD SCREW M4X5	1
039	326302-9	SAFETY WIRE	1
040	620J89-8	SWITCH UNIT	1
041	231659-4	TORSION SPRING 6	1
042	454483-0	TOOL OPENER	1
043	265026-1	PAN HEAD SCREW M4	1
044	267854-0	CAP WASHER 8	1
045	421815-6	DUST SEAL 8	1

046	267854-0	CAP WASHER 8	1
047	257347-5	RING 21	1
048	424569-4	DUST COVER	1
049	962063-3	RETAINING RING R-13	1
050	165724-6	ROD	1
051	256528-8	PIN 2	1
052	233314-4	COMPRESSION SPRING 4	1
053	310485-5	LOCK PIN	1
054	233591-8	TORSION SPRING 10	1
055	310547-9	BLADE HOLDER	1
056	135602-4	ROD ASS'Y	1
	D10	INC. 48-55	
057	183W96-5	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2
	C20 8066F9-6	SWITCH LABEL	2
	C30 8057M4-8	CAUTION LABEL	1
	D10	INC. 1	
058	265995-6	TAPPING SCREW 4X18	8
059	312D19-4	BASE	1
060	232208-0	LEAF SPRING	1
061	345237-5	CRANK PLATE	1
062	347A23-6	BASE PLATE	1
063	265085-5	COUNTERSUNK HEAD SCREW M4X8	4
064	922231-0	HEX. SOCKET HEAD BOLT M5X20	1
065	858U13-9	GVJ01 NAME PLATE	1
A02	413J99-0	COVER PLATE	1
A03	415524-7	ANTI-SPLINTERING DEVICE	1
A04	783202-0	HEX. WRENCH 4	1
A15	E-10687	JIG SAW BLADE SET	2