



## Model HG6031VK Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	PR00000015	HOUSING LEFT	1 PC.
002	PR00000016	REAR COVER	1 PC.
003	PR00000017	HEATER CONTOROLL DIAL	1 PC.
004	PR00000018	REAR HOUSING	1 PC.
005	PR00000051	CONTROLLER 120V	1 PC.
006	PR00000020	TAPPING SCREW	2 PC.
007	PR00000052	MOTOR ASSEMBLY 120V	1 PC.
008	PR00000053	HEATER & SWITCH ASSY 120V	1 PC.
009	PR00000011	SUPPORT RING	1 PC.
010	PR00000010	FRONT COVER COMPLETE	1 PC.
011	PR00000023	HOUSING RIGHT	1 PC.
012	PR00000004	TAPPING SCREW	8 PC.
013	PR00000005	SWITCH COVER	1 PC.
014	PR00000006	CORD CLAMP	1 PC.
015	PR00000007	TAPPING SCREW	2 PC.
016	PR00000008	CORD GUARD	1 PC.
017	PR00000050	POWER SUPPLY CORD	1 PC.
018	PR00000007	TAPPING SCREW	1 PC.
	PR00000061	PLASTIC TOOL CASE	