



Model HHU01C1/ZX2 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	265995-6	TAPPING SCREW 4X18	1	PC.
002	452164-0	KNOB	1	PC.
003	891002-5	INDICATION LABEL	1	PC.
004	454932-7	SWITCH LEVER A	1	PC.
005	650635-3	SWITCH TG73BDH	1	PC.
006	188948-7	HANDLE SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 16		
008	346039-2	SUPPORT PLATE	1	PC.
009	643849-1	TERMINAL	1	PC.
010	271427-3	DIAL 28	1	PC.
011	255058-6	RIVET 2	1	PC.
012	233002-3	COMPRESSION SPRING 3	1	PC.
013	233117-6	COMPRESSION SPRING 6	1	PC.
014	452162-4	LOCK LEVER	1	PC.
015	454933-5	SLIDER	1	PC.
016	188948-7	HANDLE SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 6		
017	265995-6	TAPPING SCREW 4X18	9	PC.
018	814R25-4	HHU01 NAME PLATE	1	
019	452145-4	HOLDER CAP COVER	2	PC.
020	643941-3	BRUSH HOLDER CAP	2	PC.
021	CB442	CARBON BRUSH SET CB-442 (195023-3)	1	SET
022	265995-6	TAPPING SCREW 4X18	8	PC.
023	188950-0	HOUSING SET	1	PC.
	C10 263025-7	RUBBER PIN 4	4	PC.
	D10	INC. 29		
024	265995-6	TAPPING SCREW 4X18	2	PC.
025	643857-2	BRUSH HOLDER	1	PC.
026	643856-4	BRUSH HOLDER	1	PC.
027	620224-8	CONTROLLER	1	
028	650635-3	SWITCH TG73BDH	1	PC.
029	188950-0	HOUSING SET	1	PC.
	C10 263025-7	RUBBER PIN 4	4	PC.
	D10	INC. 23		
030	638020-0	YOKE UNIT	1	PC.
031	211022-7	BALL BEARING 607ZZ	1	PC.
032	519261-6	ARMATURE ASSEMBLY 36V	1	PC.
	D10	INC. 31,33,34		
033	240045-8	FAN 55	1	PC.
034	211062-5	BALL BEARING 6000ZZ	1	PC.
035	140604-7	GEAR HOUSING COMPLETE	1	PC.
036	265999-8	TAPPING SCREW 4X25	6	PC.
037	452160-8	SWITCH LEVER B	1	PC.
038	452158-5	FRONT GRIP	1	PC.
039	142216-2	PROTECTOR COMPLETE	1	
	C10 801U20-1	CAUTION LABEL	1	
	C20 801U21-9	CAUTION LABEL	1	
040	265995-6	TAPPING SCREW 4X18	2	PC.

041	443142-1	DUST GUARD	1 PC.
042	211032-4	BALL BEARING 608ZZ	1 PC.
043	253835-0	FLAT WASHER 8	1 PC.
044	142215-4	GEAR COMPLETE	1
045	196689-1	SHEAR BLADE ASSEMBLY SET	1
C10	264013-7	HEX. LOCK NUT M5-8	7 PC.
C20	257766-5	SLEEVE 5	9 PC.
C30	265181-9	+TRUSS HEAD SCREW M5X20	7 PC.
C40	345205-8	BRANCH CATCHER	1 PC.
C50	911208-0	PAN HEAD SCREW M5X10	1 PC.
C60	188605-7	OIL VESSEL SET	1 PC.
046	346325-1	PLATE	1 PC.
047	253835-0	FLAT WASHER 8	1 PC.
048	211032-4	BALL BEARING 608ZZ	1 PC.
049	265182-7	+ PAN HEAD SCREW M5X25	2 PC.
050	452156-9	UNDER COVER	1 PC.
051	911138-5	PAN HEAD SCREW M4X20	4 PC.
A01	450490-1	BLADE COVER	1 PC.
A02	***DC36WA	DC36WA BATTERY CHARGER	1 PC. (HHU01C1)
A02A	BCV02	BATTERY CONVERTER SET (195850-7)	1 PC. (HHU01ZX2)
A03	BL3622A	BATTERY BL3622A SET (195411-3)	1 PC. (HHU01C1)
A04	451153-2	BATTERY COVER	1 PC. (HHU01C1)
D01	654208-4	RECEPTACLE	1 PC.
D02	654509-0	CONNECTOR 2-SD	2 PC.