



HLE5500 Generator UT-03704 - Electric Start




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	80089	SCREW	4	
2	84046	WASHER- Flat (5/16")	4	
3	49733	SPACER- Foot	4	
4	48789	FOOT	4	
5	84058	WASHER- Flat (5/16")	6	
6	028421	MEMBER- Frame (gen. end)	1	
7	83081	WASHER- Lock (int.)	5	
8	81162	NUT- Hex (5/167-18)	8	
9		ENGINE	1	For engine replacement parts locate the engine brand name model number, and type number and consult the appropriate dealer in your area.
10	83033	WASHER- Lock (ext./int.)	8	
11	A028881	MEMBER & STARTER	1	
13	JA376123	CABLE (Battery to Solenoid)	1	
14	81242	NUT- Hex	2	
15	83009	WASHER- Lock	2	
22	83078	WASHER- Lock (3/8")	2	
23	80630	SCREW- Mach. pan hd.	2	
24	02438	PLUG- Expansion	1	
25	03044	BEARING- Needle	1	
26	023621	BRUSH HEAD	1	
27	4885301	BOLT- Stator	4	
28	84124	WASHER- Flat	4	
29	95672	RECTIFIER	1	
30	02436	WASHER- Shaft retention	1	
31	02511	BREAKER- Circuit (25 amp.)	2	
32	02863	RECEPTACLE- (240V) (Nema 6-20R)	1	
33	50991	RECEPTACLE- Duplex (Nema 5-15R)	1	

Ref #	Part #	Description	Qty	Context Note
34	02437	WASHER- Shaft retention	5	
35	02365	BRUSH HOLDER	1	
	A03035	BRUSH & RETAINER KIT	1	
36	02857	PIN- Retaining	1	
37	02664	BRUSH	2	
38	80187	SCREW- (3/8-16 x 7/8")	4	
39	A02860	CAPACITOR (w/ Leads)	1	
40	02435	CLIP- Spring	1	
41	028451	BRACKET- Generator mtg.	1	
42	028761	WRAPPER- Stator	1	
43	02983	DECAL- Warning	1	
44	A02433S	STATOR	1	
45	80083	SCREW	2	
46	82538	SCREW	1	
47	83121	WASHER- Lock (int./ext.)	2	
48	4885214	BOLT- Rotor	1	
49	03433	WASHER	1	
50	A02430AS	ROTOR	1	
51	A04013	FAN--Generator	1	
52	82526	SCREW- Pan hd.	4	
53	020267	BELL- End	1	
54	81267	NUT- Hex	4	
55	82530	SCREW- (5/16 x 3 1/4")	2	
56	82477	SCREW-Washer hex hd.	2	
57	49834	PAD- Battery	1	

HLE5500 Generator UT-03704 - Muffler Kit



Rendered by LeadVenture, Inc.