





Model HM1812 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	324236-0	TOOL RETAINER	1	PC.
002	322477-2	TOOL RETAINER POLE	2	PC.
003	256219-1	PIN 4	2	PC.
004	310616-6	TOOL HOLDER 29	1	PC.
005	233083-7	COMPRESSION SPRING 12	2	PC.
006	322560-5	RETAINER RING	2	PC.
007	213757-6	O RING 80	1	PC.
008	951272-9	SPRING PIN 8-40	2	PC.
009	324238-6	TOOL RETAINER SHAFT	1	PC.
010	265989-1	HEX. SOCKET BOLT M12X45	4	PC.
011	942301-9	SPRING WASHER 12	4	PC.
012	213797-4	X-RING 47	1	PC.
013	213798-2	O-RING 47	1	PC.
014	326469-3	IMPACT BOLT	1	
015	332127-1	WASHER 42	1	
016	262174-7	RUBBER RING 47	1	PC.
017	332127-1	WASHER 42	1	
018	143178-7	BARREL COMPLETE	1	PC.
	C10 806G43-0	CAUTION LABEL	1	PC.
019	450347-6	CAP	1	PC.
020	213953-6	O RING 24	1	PC.
021	922677-0	HEX. SOCKET BOLT M12X55	4	PC.
022	942301-9	SPRING WASHER 12	4	PC.
023	424666-6	SEAL RING A	1	PC.
024	346840-5	PLATE	1	
025	266086-6	HEX. SOCKET HEAD BOLT M5X16	2	PC.
026	326470-8	STRIKER	1	
027	213799-0	O-RING 56	1	PC.
028	332130-2	CYLINDER LINER 66	1	PC.
029	455492-2	SPACER 72	1	PC.
030	123361-2	BALLANCER ASSEMBLY	1	PC.
	D10	INC. 29		
031	455492-2	SPACER 72	1	PC.
032	332131-0	SPACER	1	
033	142922-9	CONNECTING ROD COMPLETE	1	PC.
034	268328-4	PIN 15 C	1	
035	213799-0	O-RING 56	1	PC.
036	455509-1	PISTON	1	PC.
037	213662-7	O RING 55	1	PC.
038	455490-6	CONNECTING ROD	1	PC.
039	424669-0	BELLOWS	1	PC.
040	211151-6	BALL BEARING 6306LLB	1	PC.
041	227797-8	HELICAL GEAR 57	1	
042	267290-0	FLAT WASHER 18	1	PC.
043	226834-5	GEAR COMPLETE 23-59	1	
044	212099-5	NEEDLE CAGE 1816	2	PC.
045	267290-0	FLAT WASHER 18	1	PC.
046	424667-4	SEAL RING B	1	PC.
047	455491-4	GEAR COVER	1	PC.

048	266923-4	H.S.HEAD BOLT M6X25 WITH GM	6 PC.
049	455500-9	SIDE COVER B	1 PC.
050	850X57-3	HM1812 SERIAL NO. LABEL	1 PC.
051	266923-4	H.S.HEAD BOLT M6X25 WITH GM	4 PC.
052	850T96-9	HM1812 NAME PLATE	1 PC.
053	424668-2	FILTER CAP	1 PC.
054	443127-7	FILTER	1 PC.
055	455493-0	STOPPER	1 PC.
056	213810-8	O-RING 124	1 PC.
057	961156-3	RETAINING RING S-40	1 PC.
058	142921-1	CRANK COMPLETE	1
059	267486-3	FLAT WASHER 50	1
060	142952-0	CRANK BOX COMPLETE	1 PC.
061	267486-3	FLAT WASHER 50	1
062	310619-0	COUNTER SHAFT	1
063	213902-3	O RING 135	1 PC.
064	254220-0	KEY 5	1 PC.
065	310618-2	CRANK SHAFT	1
066	211500-7	BALL BEARING 6307LLU	1 PC.
067	256559-7	FLAT FILLISTER HD PIN 6	4 PC.
068	455506-7	HANDLE C	1 PC.
069	455503-3	CENTER COVER	1 PC.
070	234349-8	COMPRESSION SPRING 12A	4 PC.
071	326471-6	ROD 10	4
072	142919-8	CRANK HOUSING COMPLETE	1 PC.
073	455503-3	CENTER COVER	1 PC.
074	455506-7	HANDLE C	1 PC.
075	265995-6	TAPPING SCREW 4X18	2 PC.
076	455499-8	SIDE COVER A	1 PC.
077	266923-4	H.S.HEAD BOLT M6X25 WITH GM	4 PC.
078	455510-6	BRACKET	1 PC.
079	266923-4	H.S.HEAD BOLT M6X25 WITH GM	2 PC.
080	265995-6	TAPPING SCREW 4X18	3 PC.
081	455495-6	CAP COVER	1 PC.
083	455514-8	LENS	1 PC.
084	632E02-4	LEAD UNIT	1 PC.
085	654531-7	TERMINAL BLOCK 2P	1 PC.
086	620364-2	CONTROLLER	1 PC.
087	265995-6	TAPPING SCREW 4X18	1 PC.
088	687683-9	STRAIN RELIEF	1 PC.
089	664290-5	POWER SUPPLY CORD AWG 14-2-5	1 PC.
090	682578-1	CORD GUARD	1 PC.
091	266923-4	H.S.HEAD BOLT M6X25 WITH GM	2 PC.
092	455494-8	CRANK HOUSING CAP	1 PC.
093	266923-4	H.S.HEAD BOLT M6X25 WITH GM	4 PC.
094	319220-8	BEARING BOX	1
095	455498-0	BRUSH HOLDER COVER	1 PC.
096	265995-6	TAPPING SCREW 4X18	1 PC.
097	265995-6	TAPPING SCREW 4X18	1 PC.
098	455498-0	BRUSH HOLDER COVER	1 PC.
099	455496-4	MOTOR HOUSING	1 PC.
100	197128-4	CARBON BRUSH CB-218	1 PC.
101	632E01-6	BRUSH HOLDER UNIT	1 PC.
102	636405-4	FIELD 100-115V	1 PC.
103	455497-2	BAFFLE PLATE	1 PC.
104	266922-6	+ HEX. BOLT M5X120 WITH GM	2 PC.

105	517911-7	ARMATURE ASS'Y 115V	1 PC.
	D10	INC. 106-111	
106	211087-9	BALL BEARING 6200DDW	1 PC.
107	681630-2	INSULATION WASHER	1 PC.
108	240156-9	FAN 90	1 PC.
109	267487-1	FLAT WASHER 17	1
110	211152-4	BALL BEARING 6303LLU	1 PC.
111	332129-7	SEALING SCREW	1
112	266923-4	H.S.HEAD BOLT M6X25 WITH GM	4 PC.
113	455504-1	HANDLE A	1 PC.
114	455508-3	SWITCH LEVER	1 PC.
115	455511-4	SWITCH GUIDE	1 PC.
116	265995-6	TAPPING SCREW 4X18	1 PC.
117	455507-5	SWITCH COVER	1 PC.
118	650738-3	SWITCH C3JW-C-P	1 PC.
119	455502-5	HANDLE BASE A	1 PC.
120	266041-8	TAPPING SCREW 5X25	6 PC.
121	256269-6	PIN 6	2 PC.
122	319222-4	BASE	1
123	266923-4	H.S.HEAD BOLT M6X25 WITH GM	4 PC.
124	455501-7	HEAD COVER	1 PC.
125	266041-8	TAPPING SCREW 5X25	2 PC.
126	455512-2	HANDLE BASE B	1 PC.
127	266041-8	TAPPING SCREW 5X25	6 PC.
128	266923-4	H.S.HEAD BOLT M6X25 WITH GM	4 PC.
129	455505-9	HANDLE B	1 PC.
130	685756-2	RUBBER SHEET	1 PC.
131	135669-2	TOOL HOLDER ASS'Y	1 PC.
	D10	INC. 1-6,8,9	
132	684970-7	GLASS CLOTH TUBE 3.5-45	2 PC.
A01	783203-8	HEX. WRENCH 5	1 PC.
D01	654510-5	INSULATED CONNECTOR 5.5-SD	3 PC.

This file was downloaded from the site
mans.io

Instruction manuals and user guides

[Samsung](#)

[Pioneer](#)

[Alpine](#)

[LG](#)

[Dell](#)

[Sharp](#)

[Sony](#)

[Philips](#)

[Epson](#)

[Netgear](#)