



Parts List for HP932K-2 Type 2

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	311978-01	F/R ACTUATOR	1
3	148354-03	BIT CLIP	1
4	607918-41	SCREWDRIVER BIT	1
5	497030-04	VSR DC SWITCH	1
6	497015-02	TOP COVER	1
7	311979-00	SHIFTER BUTTON	1
8	330013-03	SCREW	4
9	330075-26	KEYLESS CHUCK	1
10	149518-01	SCREW	1
11	311965-01	SHIFTER WIRE	1
12	497039-04	NAMEPLATE	1
13	497017-04	ID LABEL	1
14	000000-00	No Longer Available	1
15	497026-03	GEARBOX&CLUTCH	1
16	PS145	18V BATTERY	1
17	90500930-01	PS185 18V CHARGER	1
18	330019-00	SCREW	2
19	046376-00	PIN	1
861	000000-00	No Longer Available	1
875	497004-00	LATCH	2