



## Parts List for HPD14AK-2 Type 1

Item Number	Part Number	Description	Qty Required
3	5106167-00	SCREW	2
4	311993-00	SCREW	3
5	486562-00	SCREW	2
6	5146421-00	SCREW	1
8	5145641-00	ACTUATOR FWR/REV	1
9	5145510-00	SWITCH, VSR	1
10	5145504-00	SPRING,ACTUATOR	1
12	5145493-00	TOP COVER	1
16	5103096-01	SCREW	1
17	419233-17	KEYLESS CHUCK	1
20	5145915-00	IDENT. LABEL	1
21	5145496-00	SPRING	2
22	419581-01	BIT	2
23	148354-03	BIT CLIP	2
24	5145640-00	BIT TIP HOLDER	1
861	5102001-05	KITBOX	1
866	HPB14	BATTERY	2
867	5102026-00	BATTERY CAP	1
871	FSMVC	CHARGER	1
871	5103069-09	CHARGER ASSY.	1