


HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER HU725E (96143009800) PRODUCT NO. 961 43 00-98




HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER HU725E (96143009800) PRODUCT NO. 961 43 00-98

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	580 63 87-06	Upper Handle Assembly	47	580 24 40-01	Blade, 22"
2	532 42 74-97	Cable, Engine Zone Control	48	532 85 10-74	Washer, Hardened
3	532 43 00-34	Bracket, Upstop	49	532 85 02-63	Washer, Helical
6	532 18 23-98	Handle Knob, Star	50	532 85 10-84	Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8
7	532 17 88-48	Screw, Hex Washer Head #10-16 x 5/8	51	581 23 89-01	Front Baffle
8	580 84 91-02	Control Bar, Molded	52	532 40 47-63	Decal, Warning
9	532 43 13-90	Rear Door Assembly	53	532 43 73-45	Screw
11	532 42 55-75	Hairpin, Door/Handle Pivot	56	817 41 13-12	Screw, Hex Washer Head #13 x 3/4
12	532 19 19-38	Handle Knob, Standard	57	532 15 53-77	Nut, Hex
13	532 43 75-16	Plug, Lower Handle Bar	58	532 44 11-97	Lower Handle
17	581 78 21-01	Rear Baffle	59	532 19 15-74	Handle Bolt
18	532 13 20-04	Keps Locknut 1/4-20	64	- - -	Engine, Briggs & Stratton, Model Number 128M05-0004-F1 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
19	532 19 47-88	Rope Guide			
20	532 44 45-01	Rear Skirt			
21	532 41 99-49	Spring, Rear Door, LH, Black			
22	532 14 18-41	Screw, Panhead, Torx #20	72	532 42 59-37	Fuse, 40 Amp
24	532 41 99-48	Spring, Rear Door, RH, Grey	74	532 43 15-84	Battery
26	532 41 99-45	Screw, Rear Door/Handle Pivot	75	532 44 66-94	Screw
28	872 25 05-05	Bolt, Carriage 5/16-18 x 5/8	76	580 91 52-02	Button, Start
30	580 94 34-04	Grassbag	77	532 44 66-95	Nut, Hex M6
31	532 41 99-51	Frame, Grass Catcher	78	580 91 55-03	Electric Start Assembly (Includes Switch Housing, Switch & Wiring Harness)
32	532 44 11-92	Latch, Mulcher Door			
33	532 41 99-27	Mulcher Door			
34	532 43 81-34	Bracket, Grassbag			
36	532 17 57-35	Hinge Bracket Assembly	80	532 42 86-26	Charger, Battery
37	817 00 05-10	Screw, Hex Head 1/4-20	81	532 44 64-74	Box, Battery
38	532 42 61-29	Discharge Guard	83	532 75 00-97	Screw, Hex Washer Head
39	581 35 37-02	Handle Bracket, LH	84	532 42 81-24	Fastener, Push
40	581 35 36-02	Handle Bracket, RH	85	532 43 45-30	Mounting Bracket, Rear Skirt
41	532 15 04-06	Screw, Dogpoint 3/8-16 x 1-1/8			
42	532 19 30-00	Spring, Torsion	96	532 19 79-91	Clip, Cable
43	532 19 17-30	Nut, Hex	97	581 11 53-02	Belt Keeper
44	532 44 62-61	Kit, Lawn Mower Housing	99	532 43 73-89	Front Shroud Assembly
45	532 17 56-50	Rod, Hinge	- -	115 53 94-49	Operator's Manual, English / French
46	581 85 15-01	Blade Adapter	- -	115 53 94-31	Operator's Manual, Spanish

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER HU725E (96143009800) PRODUCT NO. 961 43 00-98



HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER HU725E (96143009800) PRODUCT NO. 961 43 00-98

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	581 95 05-01	Drive Control Assembly (Includes Cable)	30	532 19 17-30	Nut, Hex
4	532 19 74-80	O-Ring	31	532 40 48-45	Pawl, Drive
5	532 08 83-48	Washer, Flat	32	581 68 51-01	Wheel & Tire Assembly, Rear
9	581 95 21-01	Cable, Drive	33	532 40 91-48	Nut, Flangelock 3/8-16
10	532 43 27-90	Mounting Bracket, Drive Control	34	532 40 48-35	Pinion
12	532 40 65-57	Belt, Drive	35	532 43 11-38	Kit, Wheel Adjuster, Front, RH
13	581 68 08-01	Gear Case Assembly, Complete	36	532 43 11-39	Kit, Wheel Adjuster, Front, LH
14	532 19 41-28	Pulley, Drive	37	532 16 34-09	Screw, Hi-Lo Thread
15	581 49 79-04	Wheel Adjuster, Rear, RH	40	532 41 08-31	Wheel & Tire Assembly, Front
16	581 49 79-03	Wheel Adjuster, Rear, LH	41	532 43 84-89	Kit, Water Washout Assembly
18	532 70 10-37	Selector Knob	42	532 43 49-94	Fitting, Water Washout
20	580 80 69-01	Debris Shield	43	532 41 55-85	Washer, Lock, Internal Tooth
22	817 00 05-10	Bolt, Hex Head 5/16-18	44	532 41 55-86	Locknut, Hex, with O-Ring
25	581 31 38-02	Mounting Bracket, Debris Shield	55	581 35 13-01	Spring, Return
26	532 42 60-66	Belt Keeper	59	532 44 21-13	Support Bracket, Front Axle
27	532 06 77-25	Washer	61	532 18 16-98	Screw
28	812 00 00-58	E-Ring 7/16	84	532 41 64-05	Adapter, Quick-Connect
29	581 84 04-01	Cover, Dust, Wheel	86	580 36 43-01	Pulley, Idler
			87	581 12 76-01	Screw

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.