


ENGINE PARTS - IDC 300BV

Item	Part No.	Description
1	610311	Spark Plug
2	147011	Cylinder Assembly
3	683390	Module Assembly
4	147012	Piston and Rod Assembly
5	147013	Cylinder Gasket
6	147014	Power Shaft Assembly
7	610308	Outer Bearing
8	682040	Snap Ring Assembly
9	610309	Seal
10	682041	Inner Bearing Seal
11	147015	Crankcase
*12	147016	Crankcase Service Assembly (items 6-11)
13	612115	Carburetor Mount Gasket (10 pack)
14	147573	Reed Assembly
15	147716	Reed Plate Assembly
16	683384	Reed Plate Mounting Screws
*17	147018	Complete Reed Plate and Reed Assembly (items 14-16)
18	147619	Carburetor Assembly
19	610675	Carburetor Gasket (10 pack)
20	147019	Air Cleaner Base
21	683380	Choke Lever Assembly
22	147020	Mounting Bolt Assembly
23	612111	Air Cleaner Filter
24	683378	Air Cleaner Cover Assembly
*25	682507	Piston Ring
*26	610676	Flywheel Key (10 pack)
*27	147021	Engine Gasket Kit
*28	153308	O.E.M. Carburetor Repair Kit
*29	153309	Gasket-Diaphragm Repair Kit
30	610672	Exhaust Gasket (10 pack)
31	147024	Muffler Assembly
32	147068	Muffler Mounting Bolt Assembly
33	147025	Air Deflector
34	147026	Lower Deflector Plate
35	147027	Mounting Bolt Assembly
36	147028	Mounting Screw Assembly
37	611060	Shroud Extension
38	611063	Ground Tab
39	153520	Shroud Assembly
40	153624	Flywheel Assembly
41	147029	Spacer
42	682546	Pulley Retainer Assembly
43	683856	Recoil Pulley Assembly
44	613102	Recoil Spring
45	610300	Pull Handle
46	613103	Rope
47	611061	Rope Guide
48	683600	Starter Housing Assembly
49	147031	Engine Adapter
50	147032	Bearing Plate Assembly
51	147033	Mounting Screw Assembly
52	147034	Crank Shaft Extension

* not shown



The above part numbers are for serial numbers 809000000 thru 810030500.




BLOWER VAC PARTS - IDC 300BV

Item	Part No.	Description
1	683400	Trigger Assembly
2	145562	Fuel Cap Assembly
3	147443	Fuel Tank
4	147036	Fuel Line Assembly
*5	147350	Complete Fuel Tank Assembly (items 2, 3, 4 and 29)
6	147351	Primer Bulb and Hose Assembly
7	147038	Switch and Lead Assembly
8	147039	Throttle Wire and Housing Assembly
9	682554	Mounting Screw Assembly
10	147644	Cover Assembly R.H.
11	147645	Cover Assembly L.H.
12	683395	Mounting Screw Assembly
13	147042	Engine Mount Set
14	147043	Upper Blower Housing
15	147044	Mounting Screw Assembly
16	147353	Impeller
17	147046	Mounting Bolt Assembly
18	147047	Impact Shield
19	147616	Lower Blower Housing
20	147049	Mounting Screw Assembly
21	147050	Intake Cover
22	147051	Spring Set
23	147052	Mounting Screw Assembly
24	147053	Hinge Shaft
25	147054	Clamp Assembly
26	147055	Blower Tube
27	683424	Clamp Assembly
28	145815	Fan Nozzle
29	147356	Fuel Return Line Assembly
30	147703	Upper Vacuum Tube Assembly
31	147705	Lower Vacuum Tube
32	147058	Adapter
33	147059	Clamp
34	147715	Vacuum Bag Assembly (includes items 32 and 33)
*35	145905	Wrench

Optional Accessories


- * 682075 Shoulder Strap Assembly
- * 153407 IDC or Ryan 2-Cycle Oil (4 oz. can)
- * 147300 Gutter Clean-Out Kit
- * 147172 Sweeper Attachment
- * 147180 Extra-Large Leaf Bag

* not shown



Item	Part No.	Description
1	610311	Spark Plug
2	147725	Cylinder Assembly
3	683390	Module Assembly
4	147012	Piston and Rod Assembly
5	147724	Cylinder Gasket
6	147014	Power Shaft Assembly
7	610308	Outer Bearing
8	682040	Snap Ring Assembly
9	610309	Seal
10	682041	Inner Bearing Seal
11	147015	Crankcase
*12	147016	Crankcase Service Assembly (items 6-11)
13	612115	Carburetor Mount Gasket (10 pack)
14	147573	Reed Assembly
15	147716	Reed Plate Assembly
16	683384	Reed Plate Mounting Screws
*17	147018	Complete Reed Plate and Reed Assembly (items 14-16)
18	147619	Carburetor Assembly
19	610675	Carburetor Gasket (10 pack)
20	147019	Air Cleaner Base
21	683380	Choke Lever Assembly
22	147020	Mounting Bolt Assembly
23	612111	Air Cleaner Filter
24	683378	Air Cleaner Cover Assembly
*25	682507	Piston Ring Set
*26	610676	Flywheel Key (10 pack)
*27	147726	Engine Gasket Kit
*28	153308	O.E.M. Carburetor Repair Kit
*29	153309	Gasket-Diaphragm Repair Kit
30	147579	Exhaust Gasket (10 pack)
31	147727	Muffler Assembly
32	147575	Muffler Mounting Bolt Assembly
33	147728	Upper Heat Shield
34	147723	Lower Heat Shield
36	147722	Mounting Screw Assembly (heat shield)
37	611060	Shroud Extension
38	611063	Ground Tab
39	153520	Shroud Assembly
40	153624	Flywheel Assembly
41	147029	Spacer
42	682546	Pulley Rope Guide Retainer Assembly
43	683856	Recoil Pulley Assembly
44	613102	Recoil Spring
45	610300	Pull Handle
46	613103	Rope
47	611061	Rope Guide
48	683600	Starter Housing Assembly
49	147031	Engine Adapter
50	147032	Bearing Plate Assembly
51	147033	Mounting Screw Assembly
52	147034	Crank Shaft Extension

* not shown



The above part numbers are for serial numbers 810030501 thru 909014526.

BLOWER PARTS - IDC 300BV

Item	Part No.	Description
1	683400	Trigger Assembly
2	145562	Fuel Cap Assembly
3	147443	Fuel Tank
4	147036	Fuel Line Assembly
*5	147350	Complete Fuel Tank Assembly (items 2, 3, 4 and 29)
6	147351	Primer Bulb and Hose Assembly
7	147038	Switch and Lead Assembly
8	147039	Throttle Wire and Housing Assembly
9	682554	Mounting Screw Assembly
10	147644	Cover Assembly R.H.
11	147645	Cover Assembly L.H.
12	683395	Mounting Screw Assembly
13	147042	Engine Mount Set
14	147043	Upper Blower Housing
15	147044	Mounting Screw Assembly
16	147353	Impeller
17	147046	Mounting Bolt Assembly
18	147047	Impact Shield
19	147616	Lower Blower Housing
20	147049	Mounting Screw Assembly
21	147050	Intake Cover
22	147051	Spring Set
23	147052	Mounting Screw Assembly
24	147053	Hinge Shaft
25	147054	Clamp Assembly
26	147055	Blower Tube
27	683424	Clamp Assembly
28	145815	Fan Nozzle
29	147356	Fuel Return Line Assembly
30	147703	Upper Vacuum Tube Assembly (black)
31	147705	Lower Vacuum Tube Assembly (black)
32	147058	Adapter
33	147059	Clamp
34	147715	Vacuum Bag Assembly (includes items 32 and 33)

Optional Accessories

- * 682075 Shoulder Strap Assembly
- * 147541 IDC or Ryan 2-Cycle Oil (4 oz. can)
- * 145905 Wrench
- * not shown

