



BOSCH

Cordless Drill Driver

IXO 3 | 3 601 J60 2B0

Table of Content

Spare parts list.....	2
Illustration - Type.....	3


Spare parts list

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
103	2 609 110 292	Twist Drill Ø 2x70 MM	1	-	1	
653	2 607 225 089	Charger EU 230/3,6V	1	-	1	
653	2 607 225 415	Battery Charger CN 220/3,6V	1	-	1	
653	2 607 225 417	Battery Charger RC 115/3,6V	1	-	1	
653	2 607 225 419	Battery Charger MAL 240/3,6V	1	-	1	
653	2 607 225 619	Battery Charger	1	-	1	
899	0 601 960 280	Cordless Drill Driver CN	1	-	1	
899	0 601 960 281	Cordless Drill Driver	1	-	1	
899	0 601 960 285	Cordless Drill Driver	1	-	1	
899	0 601 960 2B0	Cordless Drill Driver KR	1	-	1	
899	0 601 960 2C0	Cordless Drill Driver TW	1	-	1	
899	0 601 960 2K0	Cordless Drill Driver ASI	1	-	1	
899	0 601 960 2K2	Cordless Drill Driver	1	-	1	
899	0 601 960 2L0	Cordless Drill Driver MY	1	-	1	
899	0 601 960 2L1	Cordless Drill Driver	1	-	1	

* Prices shown are suggested retail prices

Illustration - Type - E

3 601 J60 2B0
Stand } 11-03-03
Issue } 11-03-06 **Abb./Fig. 1**



Anderungen vorbehalten
Modifications reserved
Modificaciones reservadas
Salvo modificaciones