



Parts List for JS700LK Type 1

Item Number	Part Number	Description	Qty Required
1	583413-07	CLAMSHELL	1
2	585803-01	ARMATURE ASSY.	1
3	583820-07S	FIELD ASSY.	1
4	583416-00SV	GEAR ASSY.	1
5	588592-00	SNAP RING	1
6	588593-00	WASHER	1
7	478866-00SV	SHAFT SERVICE KIT	1
8	585809-00	THRUST PLATE	1
9	583419-00	COUNTERBALANCE	1
10	478866-00SV	SHAFT SERVICE KIT	1
11	583422-00	BEARING	1
12	583567-00	CLAMP, BEARING	1
13	583677-00	BEARING	1
14	583425-00	CONTROL BEARING	1
15	585388-00	O RING	1
16	582593-00	BLADE CLAMP	1
17	583173-00	SCREW	2
18	583430-00SV	LOW/ BEAR.CLAMP ASY.	1
19	583423-00	CAM FOLLOWER	1
20	583421-00	BEARING CARRIER	1
21	583432-00SV	BLADE SUPPORT	1
22	590341-00	SCREW	1
23	585391-00	SHOE ASSY.	1
25	582768-00	GEAR ASSY.	1
26	582601-00	ACTUATOR	1
27	586927-00	LOCKING SCREW	1
28	583657-00	SUPPORT	1

Parts List for JS700LK Type 1

Item Number	Part Number	Description	Qty Required
29	585385-00	SWITCH	1
30	583508-01	PCB ASSEMBLY	1
31	585386-00	LOCK BUTTON	1
32	583353-00	LEAD ASSY.	1
33	372067-19	CORDSET	1
34	582722-00	CORD PROTECTOR	1
36	583434-00	KNOB ASSY.	1
37	590096-00	SPRING	1
38	583455-00	FRONT FASCIA	1
39	583454-00	REAR FASCIA	1
40	583452-00	SELECTOR CAM	1
41	380414-00	CLAMP,CORD	1
42	583451-00	SELECTOR	1
43	370748	SCREW	2
44	583450-00	RETAINER	1
45	809961-00	SCREW	10
46	583449-00	SCROLLER LOCK	1
47	586220-00	LABEL	1
48	586067-09	NAME PLATE	1
49	330019-48	SCREW	2
50	586219-00	LABEL	1
51	000000-00	No Longer Available	1
52	330013-11	SCREW	6
53	583678-00	FELT SEAL	1
54	586068-00	VACUUM PIPE	1
55	582732-00	ELBOW	1
56	582761-01	BRUSH & SPRING	2

Parts List for JS700LK Type 1

Item Number	Part Number	Description	Qty Required
57	582696-00	BRUSH BOX	2
58	812171	SCREW	4
59	574853-08	BEARING	1
60	587375-00	RETAINING CLIP	1
62	583353-01	LEADWIRE ASSY.	1
63	098197-03	LOCK WASHER	1
70	489406-00S	LASER ASSEMBLY	1
71	489427-00	SCREW	1
800	761995-01	GREASE, 6 OZ.	1
856	491770-00	SCREW DRIVER	1
861	586929-00	KIT BOX	1