



Parts List for KR515K-AR Type 1

Item Number	Part Number	Description	Qty Required
1	187960-01	ARMATURE ASSY.	1
2	187997-01	FIELD	1
3	654333-00	SWITCH, 2 SPD.	1
4	187499-01	BRUSH HOLDER ASSY	2
5	875735	BRUSH HOLDER	2
6	184545-21	CORD	1
7	654376-00	NAME PLATE	1
8	187926-00	CLAMSHELL SET	1
9	187967-00	ACTUATOR	1
10	186452-00	THRUST PLATE	1
11	187965-00	BEARING BLOCK ASSY.	1
12	574297-00	BEARING,SINTER	1
13	821986	SPRING	1
14	748180-02	GEAR	1
15	187962-00	SPINDLE	1
16	330033-15	CHUCK,10MM	1
17	330034-07	CHUCK KEY	1
18	187998-03	LEADWIRE	1
19	187998-04	LEADWIRE ASSY.	1
20	635176-00	BEARING SLEEVE	1
21	606290-01	BEARING	2
23	330019-04	SCREW,PLASTITE	8
24	650753-00	BRAND LABEL	1