



Model LC08ZW Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	183K60-4	HOUSING SET	1
	C10 424913-5	SPONGE SHEET 35-70	2 PC.
	C20 810P36-5	CAUTION LABEL	1 PC.
	D10	INC. 11	
002	144096-2	SWITCH PLATE COMPLETE	1 PC.
003	631973-2	SWITCH UNIT	1 PC.
004	620A19-5	CONTROLLER	1
	C10 620601-4	LED CIRCUIT	1 PC.
005	854T80-6	LC08 SERIAL NO. LABEL	1
006	644813-5	TERMINAL	1 PC.
008	126846-7	MOTOR ASSEMBLY	1
009	458834-9	FAN COVER	1
010	422377-7	RUBBER RING	1
011	183K60-4	HOUSING SET	1
	C10 424913-5	SPONGE SHEET 35-70	2 PC.
	C20 810P36-5	CAUTION LABEL	1 PC.
	D10	INC. 1	
012	266429-2	TAPPING SCREW 3X16	7 PC.
013	854T74-1	LC08 NAME PLATE	1
014	422268-2	SPONGE SHEET 57	1 PC.
015	458467-0	STAY	1 PC.
016	443060-3	FILTER	1 PC.
017	451208-3	PRE-FILTER	1 PC.
018	265995-6	TAPPING SCREW 4X18	1 PC.
019	941051-3	FLAT WASHER 4	1 PC.
020	424208-6	VALVE	1 PC.
021	809293-4	INDICATION LABEL	1 PC.
022	140G24-7	CAPSULE COMPLETE	1
	D10	INC. 18-21	
A01	123486-2	FLOOR T-NOZZLE 28 WHITE	1 PC.
	C10 451410-8	ROLLER	4 PC.
	C20 268208-4	PIN 3	4 PC.
	C30 424096-1	WIPER	1 PC.
A02	451240-7	SASH NOZZLE	1 PC.
A03	451241-5	PIPE	1 PC.
A04	451242-3	SASH NOZZLE HOLDER	1 PC.