



Parts List for LCSB2140 Type 1

Item Number	Part Number	Description	Qty Required
1	5140173-66	SWITCH HANDLE ASSY.	1
3	5140173-67	FOAM GRIP	1
4	5140173-68	SWITCH BOX ASSY	1
4	5140149-44	SWITCH	1
5	5140161-05	KEY BOX ASSY.	1
6	5140149-63	KEY STRAP	1
7	5140173-69	RUBBER RING	1
8	5140173-70	FIXED SEAT	1
9	5140150-09	LOCK NUT	1
10	5140173-71	CONNECTING HANDLE	1
11	5140173-72	CARRIAGE BOLT	2
12	5140173-73	CIRCLIP	1
13	5140173-74	WASHER	2
14	5140173-75	SLEEVE	1
15	5140173-76	RING	2
16	5140173-77	ROTATION ROD	1
17	5140171-28	WIRE PIE	2
18	5140172-65	KNOB	6
19	5140173-78	COTTER PIN	1
20	5140173-79	SCREW	25
21	5140173-80	PIN	1
22	5140173-81	GEAR	1
23	5140173-82	WASHER	1
24	5140173-83	SEAT	1
25	5140173-84	HANDLE	1
26	5140173-85	U-BOLT	2
27	5140173-86	WHEEL ASSEMBLY	1

Parts List for LCSB2140 Type 1

Item Number	Part Number	Description	Qty Required
27	5140172-36	WHEEL COVER	2
27	5140173-87	TEETH WASHER	2
27	5140173-88	REAR WHEEL	2
27	5140173-89	BUSHING	4
27	5140173-90	SUPPORT TUBE	1
27	5140173-91	AXLE	1
27	5140173-92	SLEEVE	4
28	5140173-93	INSERT PLATE	1
29	5140173-94	LOCK BAR	1
30	5140173-95	COVER	1
31	5140173-96	COVER	2
32	5140173-97	SCREW	15
33	5140173-98	BATTERY COVER	1
34	5140173-99	PIN	2
35	5140174-00	CLIP	2
36	5140174-01	COVER	2
37	5140174-02	SPRING	1
38	5140174-03	BATTERY COVER	1
39	5140174-04	SELF TAPPING SCREW	5
40	5140174-05	CONNECTING WIRE	1
41	5140150-39	TERMINAL	2
42	5140174-06	INSERT PLATE	1
43	5140172-48	LOCKING SCREW	7
44	5140174-07	WASHER	2
45	5140174-08	HEX BOLT	4
46	5140174-09	LOCK BAR	1
47	5140150-45	ANTI LOCK SPRING	4

Parts List for LCSB2140 Type 1

Item Number	Part Number	Description	Qty Required
48	5140174-10	DISCHARGE CHUTE	1
49	5140174-11	CARRIAGE BOLT	2
50	5140174-12	RUBBER STRIP	2
51	5140174-13	SIDE COVER	1
52	5140174-14	CABLE CLAMP	1
53	5140159-38	CORD CLAMP	1
54	5140150-27	SCREW	2
55	5140174-15	WASHER	1
56	5140174-16	LOCK NUT	1
57	5140174-17	HEX HEAD SCREW	3
58	5140174-18	BALL BEARING	1
59	5140174-19	MOUNTING PLATE	1
60	5140174-20	BRACKET	1
61	5140174-21	COVER PLATE	1
62	5140174-22	HEX BOLT	16
62	5140161-69	SELF LOCK NUT	17
62	5140174-23	SUPPORT	2
62	5140174-24	SCRAPER KNIFE	2
62	5140174-25	AUGER	1
62	5140174-26	HEX BOLT	1
62	5140174-27	FLAT WASHER	8
63	5140174-28	SCREW	4
64	5140174-29	HOUSING ASSEMBLY	1
64	5140174-30	SCREW	1
64	5140174-31	CHUTE	1
64	5140174-32	DISCHARGE CHUTE	1
64	5140174-33	HOUSING	1

Parts List for LCSB2140 Type 1

Item Number	Part Number	Description	Qty Required
65	5140174-34	BEARING	1
66	5140174-35	BRACKET	1
67	5140174-36	MOUNTING PLATE	1
68	5140174-37	HEX HD CAP SCR	3
69	5140161-69	SELF LOCK NUT	1
70	5140174-38	BRUSHLESS MOTOR	1
71	5140174-39	HEX HEAD BOLT	1
72	5140174-40	SIDE COVER	1
73	5140174-41	SCREW	2
74	5140174-42	SNOW SCRAPER	1
75	5140174-43	SNOW REMOVAL STICK	1
76	5140174-44	HEX BOLT	2
77	5140174-45	CLIP	1
78	5140161-69	SELF LOCK NUT	1
79	5140174-46	ELECTRONIC	1
80	5140174-47	SEALED CAP	1
81	5140150-34	CEMENT RESISTANCE	1
82	5140174-48	LEADWIRE ASSY.	1
866	000000-00	No Longer Available	2
871	LCS36	CHARGER	1