



BOSCH

Laser Level

LR 30 | 3 601 K69 211

Table of Content


Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration
899	1 600 A01 BM3	Laser detector	1
899/4	2 610 A07 677	Battery Cover	1

Illustration - Type - E

3 601 K69 240
Issue |
Stand | 20-07-07 **Fig./Abb. 1**



Modifications reserved
Änderungen vorbehalten
Modifications réservées
Salvo modificaciones