



Parts List for LSW40C Type 1

Item Number	Part Number	Description	Qty Required
1	90637023	HOUSING	1
2	N497302	MOTOR & FAN	1
3	90636991	PCB ASSEMBLY	1
4	90569746	SWITCH ACTUATOR	1
5	90569937	SWITCH	1
6	486563-00	SCREW	11
7	90637027	BLOWER TUBE	1
10	90641389	SCREW,PAN HD.	1
11	90642521	FOAM	2
25	90641156	RATING LABEL	1
866	LBX1540	BATTERY PACK	1
871	90604879-01	CHARGER	1