



Model LXMU02Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
1	915116-7	BINDING HEAD SCREW M4X12	1	PC.
2	141413-7	PROTECTOR COMPLETE	1	PC.
	C10 890785-4	CAUTION LABEL	1	PC.
3	187417-5	HOUSING SET	1	PC.
	C10 931102-0	HEX. NUT M4	1	PC.
	C20 346275-0	PLATE	2	PC.
	C30 890784-6	CAUTION LABEL	1	PC.
	C40 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 27		
5	643852-2	TERMINAL	1	PC.
6	452438-9	LOCK OFF BUTTON	1	PC.
7	231473-8	COMPRESSION SPRING 4	1	PC.
9	620119-5	CONTROLLER	1	PC.
10	451812-8	LOCK LEVER	1	PC.
11	651891-8	SWITCH V-15-3A6	1	PC.
12	231473-8	COMPRESSION SPRING 4	1	PC.
13	417564-1	SWITCH LEVER	1	PC.
16	451814-4	DUST GUARD	1	PC.
17	268254-7	PIN 6	1	PC.
18	261122-3	WASHER 6	1	PC.
19	268256-3	PIN 4	2	PC.
20	227728-7	HELICAL GEAR 47	1	PC.
21	165609-6	CRANK COMPLETE	1	PC.
22	629943-3	DC MOTOR	1	PC.
23	268076-5	PIN 6	1	PC.
24	261122-3	WASHER 6	1	PC.
25	226831-1	GEAR 12-31	1	PC.
26	261122-3	WASHER 6	1	PC.
27	187417-5	HOUSING SET	1	PC.
	C10 931102-0	HEX. NUT M4	1	PC.
	C20 346275-0	PLATE	2	PC.
	C30 890784-6	CAUTION LABEL	1	PC.
	C40 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 3		
28	266429-2	TAPPING SCREW 3X16	6	PC.
29	896942-2	LXMU02 NAME PLATE	1	PC.
30	195176-7	SHEAR BLADE ASSEMBLY SET	1	PC.
	C10 188369-3	OIL VESSEL SET	1	PC.
31	140451-6	UNDER COVER COMPLETE	1	PC.
A01	326146-7	BASE FRAME	1	PC.
A02	451813-6	CHANGE LEVER	1	PC.
A03	452055-5	BLADE COVER	1	PC.