




Model ML107 Parts List

Item#	Part#	Description	Q'ty
001	GM00002477	LENS	1
002	GM00002459	USB SWITCH BUTTON	1
003	GM00002478	STRAP HOOK	1
004	GM00002479	USB COVER	1
005	GM00002480	LED PCBA ASSY	1
006	GM00002481	MAIN PCBA ASSY	1
007-1	GM00002498	BODY ASSY BLUE	1
008	GM00002468	SWITCH SPRING	1
009	GM00002484	SWITCH SPRING BRACKET	1
010	GM00002485	SWITCH ASSY	1
011	GM00002486	SCREW 2.6X12 PB BLACK ZN	3
A01	GM00002476	LAMP SHADE	1