



N80CB/N80CB-HQ

COIL-FED PNEUMATIC NAILERS
 CLAVADORA NEUMÁTICA
 ALIMENTADA POR ROLLO
 CLOUSEURS PNEUMATIQUES
 A ENROULEMENT



ADHESIVES USED:

- † Loctite 271 - available as part #851325
- †† 2-part epoxy - available locally
- ††† Loctite 242 - available as part #851385
- †††† See available accessories in Operation and Maintenance Manual



Parts List for N80CB-HQ Type 0

Item Number	Part Number	Description	Qty Required
1	110005	FRAME	1
2	N70118	SEAL-CYLINDER CAP	1
3	105590	CAP (SERVICE PART)	1
4	N80161	PISTON STOP	1
5	104059	HEAD VALVE	1
6	101256	SPRING-COMPRESSION	1
7	101236	O-RING-2.48X.115	1
8	MRG041630	O-RING-1.638X.118	1
9	T55031	RING-BUMPER	1
10	107490	GRIP-HANDLE	1
11	MSC6100-40	SCREW-SOC. HD. CAP M	1
13	MSF8125-25	SCREW-SFHCS M8 X 1.2	1
14	102506	COVER-EXHAUST	1
27	102549	PIN-SPECIAL SPIROL M	1
28	MPP030020	PIN-SPIRAL M3X20MM	1
30	TVA6	KIT-TRIGGER VALVE	1
31	N70145	GUIDE-ARM	1
32	CNTK2	KIT-CONTACT TRIP CON	1
36	N70167	CAP-END	1
37	MRG049431	O-RING-2.343X.118	1
39	N80157A	DRIVER-PISTON ASSY.	1
40	851439	O-RING-1.689X.190	1
41	N80170	SLEEVE-CYLINDER	1
42	N80169	SEAL-CHECK	1
43	N70155	SEAL-CYLINDER	1
44	N80168	RING-CYLINDER	1
46	MRG084431	O-RING-3.323X.122	1

Parts List for N80CB-HQ Type 0

Item Number	Part Number	Description	Qty Required
47	N70156	BUMPER - A	1
48	N70157	BUMPER - B	1
49	N80354	GASKET-NOSE	1
50	N80130	DRIVER GUIDE	1
51	182225	NOSE	1
53	185938	PAWL-FEED	1
54	N50087	PIN-SPECIAL(STEP)	1
55	N80120	SPRING-TORSION	1
56	854004	WASHER-RUBBER-7	3
57	MRG009824	O-RING-.386X.094	1
58	851384	O-RING-.987X.103	1
59	N80128	PISTON-FEED	1
60	N80122	SPRING-COMPRESSION	1
61	N80123	BUMPER-FEED PISTON	1
62	N80124	COVER-FEED PISTON	1
63	851383	RING-RETAINING METRI	1
64	N80125	PIN-SPECIAL	1
65	182228	DOOR	1
66	N70149	PAWL CHECK	1
67	854011	COMPRESSION SPRING	1
68	N70140	PIN-SPECIAL(STEP)	1
69	N70150	LATCH DOOR	1
70	854013	SPRING,CMPRSN.	1
71	MPG030012	PIN SPRING	1
72	MSC8125-28	SCREW-SHCS M8X28	1
74	MHE6100-100	NUT-ESN M6X1	2
75	105973	SPACER	1

Parts List for N80CB-HQ Type 0

Item Number	Part Number	Description	Qty Required
76	MPW6.2	WASHER.SPECIAL	2
77	N70143	BUSHING-RUBBER	1
79	N80107	SPACER-FRAME	1
81	107455	LATCH-CANISTER	1
82	N80106	SPACER-LATCH	1
83	UB2126	PIN-ROLL 1/8 X 1 5/8	1
84	N80108	SPRING-FLAT	1
85	UB2110.4	PIN-ROLL 1/8 X 5/8	1
86	N80103	BOTTOM-CANISTER	1
88	UB5130	PIN-SPIROL 1/4 X 1 7	1
89	N80127	ARM-CONTACT-SERRATED	1
90	N80132	SPRING-CONTACT ARM	1
92	LW14.2	WASHER-1/4 HI COL LO	1
93	MSC6100-16	SCREW-SHCS-M6X1.00X1	1
94	N80131	GUARD-CONTACT ARM	1
95	N80121	ROD-FEED PISTON	1
96	112767	LABEL-BOSTITCH	1
97	159912	LABEL-WARNING-COIL N	1
102	121635	ASSEMBLY-CANISTER	1
103	121632	ASSEMBLY-BRACKET	1
104	851438	O-RING-2.236X.115	2
105	SEQ6	KIT-SEQUENTIAL	1
106	MPW6.3	WASHER-PWN M6	4
107	MSC6100-25	SCREW-SHCS-M6X1.00X2	4
800	100653	LUBE (2CC)	1
800	100679	LUBE (1LB.CAN)	1
811	851385	LOCTITE	1

Parts List for N80CB-HQ Type 0

Item Number	Part Number	Description	Qty Required
811	851325	LOCTITE	1
876	ORK11	REPAIR KIT	1
876	000000-00	No Longer Available	1
876	RBK8	N70/N80/N90 REBUILD	1