


ADHESIVES USED:

- † Loctite 271 - available as part #851325
- †† 2-part epoxy - available locally
- ††† Loctite 242 - available as part #851385
- †††† See available accessories in Operation and Maintenance Manual



ORIFICE CAP AND INSTRUCTIONS ARE SUPPLIED WITH VALVE

**N80SBM**  
**PNEUMATIC STICK NAILERS**  
**CLAVADORA NEUMÁTICA ALIMENTADA POR BARRA**  
**CLOUEUR PNEUMATIQUE EN BANDES**

IP1132-1REV D 2/07  
 TO BE USED WITH PARTS LIST IP1132-2 AND OPERATION AND MAINTENANCE MANUAL 103585.

## Parts List for N80SBM Type 0

Item Number	Part Number	Description	Qty Required
1	110005	FRAME	1
1	107490	GRIP-HANDLE	1
2	N70118	SEAL-CYLINDER CAP	1
3	104193	ASSEMBLY-CYLINDER CA	1
4	N80161	PISTON STOP	1
5	104059	HEAD VALVE	1
6	101256	SPRING-COMPRESSION	1
7	101236	O-RING-2.48X.115	1
8	MRG041630	O-RING-1.638X.118	1
9	T55031	RING-BUMPER	1
11	MSC6100-25	SCREW-SHCS-M6X1.00X2	4
13	MSF8125-25	SCREW-SFHCS M8 X 1.2	1
14	102506	COVER-EXHAUST	1
27	102549	PIN-SPECIAL SPIROL M	1
28	MPP030020	PIN-SPIRAL M3X20MM	1
30	TVA11	KIT-TRIGGER VALVE	1
31	N70145	GUIDE-ARM	1
32	CNTK2	KIT-CONTACT TRIP CON	1
36	N70167	CAP-END	1
37	MRG049431	O-RING-2.343X.118	1
39	N80367A	ASSEMBLY-DRIVER/PIST	1
40	851439	O-RING-1.689X.190	1
42	N80170	SLEEVE-CYLINDER	1
42	N80169	SEAL-CHECK	1
42	N80168	RING-CYLINDER	1
43	N70155	SEAL-CYLINDER	1
46	MRG084431	O-RING-3.323X.122	1

## Parts List for N80SBM Type 0

Item Number	Part Number	Description	Qty Required
47	N70156	BUMPER - A	1
48	N70157	BUMPER - B	1
49	N80354	GASKET-NOSE	1
50	105022	LOCATOR PLATE	1
51	000000-00	No Longer Available	1
52	N80356	SHOCK RING	1
53	N80357	SPACER	1
54	MSC8125-16	SCREW-SHCS M8X16	1
55	N70120	NUT- TORQUE	1
56	108576	LOWER C.T.ASSEM.COMB	1
57	N80349	TRIP-UPPER	1
58	MHE6100-100	NUT-ESN M6X1	5
60	100874	SPRING-COMPRESSION	1
61	MSC8125-28	SCREW-SHCS M8X28	4
62	158753	MAGAZINE ASSY	1
63	MSB6100-12	SCREW-SBHCS-M6X1.00X	1
65	MSC6100-30	SCREW-SHCS-M6X1.00X3	1
66	MPW6.2	WASHER.SPECIAL	2
67	N70143	BUSHING-RUBBER	1
68	N80322A	PUSHER ASSY.	1
69	N16175A	PUSHER SPRING ASSY	1
70	N80340	SPACER MAGAZINE	1
71	MSC4070-45	SCREW	1
72	LW8	WASHER-#8 LOCK	2
73	N80332	LATCH STOP	1
74	N80336	BUSHING-LATCH SPRING	1
75	MHE4070-100	ELASTIC STOP NUT-M4	2

## Parts List for N80SBM Type 0

Item Number	Part Number	Description	Qty Required
76	N80335	SPRING-TORSION	1
77	107451	LATCH-PUSHER	1
78	MSB4070-10	SCREW-SBHCS-M4X0.70X	1
79	103943	SPACER-SPRING	1
81	112767	LABEL-BOSTITCH	1
82	159911	LABEL-WARNING-CT/ST	1
83	86459	O-RING	1
84	MRG019824	O-RING-.780X.094	1
87	N16177	LINER- NAIL GUIDE	1
102	851438	O-RING-2.236X.115	2
104	SEQ6	KIT-SEQUENTIAL	1
106	MPW6.3	WASHER-PWN M6	4
107	000000-00	No Longer Available	1
800	100653	LUBE (2CC)	1
800	100679	LUBE (1LB.CAN)	1
811	851385	LOCTITE	1
811	851325	LOCTITE	1
876	ORK11	REPAIR KIT	1
876	000000-00	No Longer Available	1
876	RBK8	N70/N80/N90 REBUILD	1