



Parts List for NHT518B Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|---------------------|--------------|
| 1 | 574137-01 | GUARD | 1 |
| 2 | 5103541-00 | SCREW | 10 |
| 3 | 574847-00 | HANDLE | 1 |
| 4 | 574095-01 | CAP | 2 |
| 5 | 90542557 | BLADE ASSY. | 1 |
| 6 | 000000-00 | No Longer Available | 1 |
| 7 | 571828-00 | GEAR COVER | 1 |
| 8 | 798754-01 | BOLT | 1 |
| 9 | 573217-00 | SPACER | 9 |
| 10 | 576571-01 | SHEATH | 1 |
| 11 | 371954-01 | BLADE BOLT | 7 |
| 12 | 798755 | NUT - FLANGE | 7 |
| 13 | 573217-00 | SPACER | 2 |
| 14 | 576575-00 | SCREW | 2 |
| 15 | 574164-00 | INSERT | 1 |
| 16 | 570567-00 | SCREW | 2 |
| 17 | 571824-00 | GEARCASE | 1 |
| 18 | 370927-00 | PLATE | 1 |
| 866 | 90554640 | BATTERY PACK | 1 |
| 867 | 5102026-00 | BATTERY CAP | 1 |
| 871 | 90571729-01 | CHARGER | 1 |
| 871 | 5103069-12 | CHARGER | 1 |