


**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description	Ref. No.	Catalog No.	Description	Ref. No.	Catalog No.	Description
1	17698	Pump/Motor Assembly	15	17773	Tank Gauge	29	17883	Unloader
2	17703	Filter	16	17783	Screw, 1/4" - 20 x 1/2"	30	17888	Plug
3	17708	Filter Element	17	17793	Regulator	31	17893	3/8" Push To Connect
4	17713	Shoulder Bolt	18	17798	Safety Valve, 150 PSI	32	17898	Nipple
5	17718	Rubber Bushing-Rear	19	17808	Grip	33	17903	Pressure Switch Cover
6	17723	Rubber Bushing-Front	20	17813	Roll Bar	34	17908	Pressure Switch
7	17728	Check Valve	21	17838	Control Panel Bracket	35	17913	Tank Drain Valve
8	17733	Exhaust Tube	22	17848	Foot Screw	36	17918	Plug
9	17738	Nut	23	17853	Molded Rubber Bumper	37	17923	4.5 Gal. Twin Tank
10	17743	Ferrule	24	17858	3/8" Nylon Tube	38	17928	Shroud Screw
11	17748	1/4" Flexible Tube	25	17863	1/4" - 20 x 1/2" Self Tap Screw	39	17933	Shroud Screw
12	17753	Strain Relief screw	26	17868	3/8" 90 Degree Push to Connect	40	17938	Shroud
13	17758	Strain Relief	27	17873	Coupler	41	17943	Exhaust Fitting
14	17763	Cord	28	17878	Outlet Gauge			



**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	17953	Head Bolt Kit
2	17948	Head
3	17978	Discharge Valve Gasket
4	17973	Head Gasket
5	17983	Valve Plate Kit
6	17958	Cylinder Gasket
7	17968	Piston Assembly w/Screw
8	17988	Fan Kit
9	17963	Motor Assembly