


RYOBI 18 VOLT CORNER CAT™ P400 FINISHING SANDER

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your **FINISHING SANDER** or when ordering repair parts.




PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	019001001016	PLATEN COVER	1
2	019001001015	SELF-TAPPING SCREW (4 X 8).....	5
3	019001001017	PLATEN SUPPORT.....	1
4	940301034	DATA PLATE	1
5	940114119	LOGO PLATE.....	1
	200292003	LANYARD (NOT SHOWN)	1

RYOBI 18 VOLT CORNER CAT™ P400 FINISHING SANDER

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your **FINISHING SANDER** or when ordering repair parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	019001001023	SANDPAPER (60 GRIT)	2
2	019001001024	SANDPAPER (120 GRIT)	3
3	019001001025	SANDPAPER (240 GRIT)	2
4	019001001026	SCRUB, HEAVY	1
5	019001001027	SCRUB, LIGHT	1
6	019001001028	SCRUB, POLISHING	1
	983000622	OPERATOR'S MANUAL	
	983000622R	REPAIR SHEET (REV:00)	
	12-13-04		