


RYOBI 6 in. 18 VOLT BUFFER/POLISHER – MODEL NUMBER P430

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your **BUFFER/POLISHER** or when ordering repair parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	019011001003	PAD ASSEMBLY	1
2	019011001002	SPRING WASHER (M5)	1
3	019011001001	* SCREW (M5 X 12 MM).....	1
4	019011001012	POLISHING BONNET	1
5	019011001011	TERRY CLOTH BONNET	1
6	130255004	BATTERY PACK (P100) (NOT SHOWN).....	1
	130224028	BATTERY PACK (P100) (NOT SHOWN).....	1
7	1423701	CHARGER (P110) (NOT SHOWN)	1
	140237021	CHARGER (P110) (NOT SHOWN)	1
	140237023	CHARGER (P110) (NOT SHOWN)	1
	983000967	OPERATOR'S MANUAL (019011001017)	
	04-28-08		
	(REV:01)		

* Standard Hardware Item – May Be Purchased Locally