


**RYOBI 6 in.
18 VOLT BUFFER/POLISHER
MODEL NO. P430G
REPAIR SHEET**

RYOBI 6 in. 18 VOLT BUFFER/POLISHER – MODEL NUMBER P430G

The model number will be found on a label attached to the motor housing. Always mention the model number in all correspondence regarding your **BUFFER/POLISHER** or when ordering repair parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	019011001003	Pad Assembly.....	1
2	019011001002	Spring Washer (M5).....	1
3	019011001001	Screw (M5 x 12 mm).....	1
4	019011001012	Polishing Bonnet.....	1
5	019011001011	Terry Cloth Bonnet.....	1

NOT SHOWN:

130255004	Battery Pack (P100).....	1
130224028	Battery Pack (P100).....	1
1423701	Charger (P110).....	1
140237021	Charger (P110).....	1
140237023	Charger (P110).....	1
983000967	Operator's Manual (019011001017)	

4-20-15
(Rev:01)