

RYOBI
18 VOLT POLE SAW
MODEL NO. P4360
MANUFACTURING NO. 107369001
REPAIR SHEET


Techtronic Industries Power Equipment

1428 Pearman Dairy Road, Anderson, SC 29625

Phone 1-800-860-4050

www.ryobitools.com

RYOBI 18 VOLT POLE SAW – MODEL NUMBER P4360



RYOBI 18 VOLT POLE SAW – MODEL NUMBER P4360

The model number will be found on a label attached to the motor housing. Always mention the model number in all correspondence regarding your **18 VOLT POLE SAW** or when ordering replacement parts.


PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	760253019	Switch Assembly.....	1	29	941015018	Warning Label (English).....	1
2	532644001	18v Battery Foot.....	1	30	941015019	Warning Label (French/Spanish)	1
3	313216001	Handle Assembly (Inc. Key No. 28).....	1	31	941002197	Logo Label	2
4	660960002	Screw (M3 x 8 mm)	1	32	941016004	Data Label	1
5	634052001	Strap Hanger.....	1	33	941015017	Warning Icon Label	1
6	679022001	Compression Spring	1	34	531003001	Pump Clamp	1
7	310980003	Lower Pole Assembly (Inc. Key No.1).....	1	35	310987002	Chain.....	1
8	310980002	Middle Pole Assembly.....	1	36	312660001	Guide Bar	1
9	570115001	Rubber Pad.....	2	37	660936002	Adjustment Bolt (M5 x 46.5 mm).....	1
10	310975001	Motor Assembly (Inc. Key No. 27).....	1	38	678356003	Adjustment Guide Bar.....	1
11	300790003	Oil Tank And Cap Assembly.....	1	39	634030001	Guide Bar Plate.....	1
12	313214001	Clamp Assembly	1	40	660024020	Screw (M4 x 18 mm, T20 Torx Pan Hd.).....	10
13	660469001	Screw (M5 x 24 mm, Pan Hd.)	2	41	660526001	Screw (M4 x 11 mm, T20 Torx Pan Hd.).....	2
14	678536001	Hex Nut (M5)	2	42	678353001	Retaining Ring (4 mm).....	1
15	310980001	Top Pole Assembly (Inc. Key Nos. 29-30 & 33)	1	43	560219006	Contact Plate Stopper	2
16	312524001	Oil Pump	1	44	690733001	“D” Washer (OD25 x ID7.5 x 1t)	1
17	660005006	Screw (M3 x 10 mm)	4	45	610323001	Sprocket.....	1
18	313215001	Rear Trigger & Lock Button Assembly	1	46	670608002	Retaining Ring.....	1
19	570820001	Seal Gasket.....	1	47	580699010	Scabbard.....	1
20	661189003	Screw (M4 x 18 mm T15 Torx Hd.).....	8	48	310982003	Bar & Chain Assembly (Inc. Key Nos. 35-36).....	1
21	308319004	Harness Assembly	1	49	310984001	Rear Handle Assembly (Inc. Key Nos. 1-7, 12-14,18, 28, & 40-41)	1
22	313213001	Housing Assembly (Inc. Key Nos. 31-32).	1				
23	311071001	Output Shaft Assembly	1				
24	551057001	Chain Cover	1				
25	639255001	Wrench.....	1				
26	661868001	Bolt w/Washer (M6 x 29 mm, Hex Soc. Hd.).....	1				
27	661861001	Screw w/Washer (M4 x 8 mm)	2				
28	941002198	Logo Label	2				

Not Shown:
901215013
995000261
6-27-17
(Rev:01)

Bar/Chain Oil
Operator's Manual

RYOBI 18 VOLT POLE SAW – MODEL NUMBER P4360



WIRING DIAGRAM