


RYOBI 18 VOLT, 4 in. WET/DRY TILE SAW – MODEL NUMBER P580



RYOBI 18 VOLT, 4 in. WET/DRY TILE SAW – MODEL NUMBER P580

The model number will be found on a label attached to the motor housing. Always mention the model number in all correspondence regarding your **18 VOLT, 4 in. WET/DRY TILE SAW** or when ordering parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	660144006	Screw (M4 x 16 mm)	1	32	940114179	Logo Label.....	1
2	610121008	Outer Wheel Washer	1	33	515949001	End Cap.....	1
3	672334001	Outer Wheel Washer	1	34	940701011	Remove Battery Label	1
4	660212049	Screw (M4 x 12 mm).....	4	35	520082001	Vent Baffle.....	1
5	520299001	Water Adjust Button.....	1	36	660024045	Screw (M4 x 13.5 mm).....	1
6	940114178	Logo Label.....	1	37	515950001	Spindle Lock Button	1
7	641547001	Upper Guard Cover	1	38	670056001	Spindle Lock Spring	1
8	690736004	C-Ring (OD 9.0 x ID 6.5 x 1.0)	1	39	632136001	Spindle Lock Retainer Plate	1
9	303475001	Water Control Valve Assembly.....	1	40	901604001	Fiber Seal (1.5 mm).....	1
10	520332001	Bottle Release Button.....	1	41	560805001	Rubber Seal.....	1
11	303474001	Bottle Cover Assembly	1	42	301124002	Edge Guide Knob	1
12	520169001	Water Bottle.....	1	43	680027001	Washer.....	1
13	303518001	Vent Cap Assembly.....	1	44	681230001	Spring	1
14	303400001	Bottle Assembly (Inc. Key Nos. 11-13).....	1	45	660212053	Screw (M4 x 16 mm).....	1
15	680049002	Spring (OD 10 x ID 8.2 x 30)	1	46	680022003	Hex Nut (M4 x 3.2 mm).....	1
16	660024044	Screw (M4 x 16 mm).....	14	47	661097001	Screw (M6 x 52 mm).....	1
17	641546001	Upper Guard Support.....	1	48	670494002	Lock Nut (M6)	1
18	560804001	Rubber Seal	1	49	301124003	Bevel Adjustment Knob	1
19	940221105	Danger Label	1	50	691992001	Washer.....	2
20	940221106	Warning Label (French / Spanish).....	1	51	660142008	Screw (M6 x 12 mm).....	1
21	560219006	Hex Key Stopper	1	52	633167001	Base.....	1
22	200074009	Housing Assembly	1	53	661067002	Screw (M6 x 22 mm).....	1
23	220116001	Gear Box Assembly	1	54	301124004	Depth Adjustment Knob	1
24	660208049	Screw (M4 x 22 mm).....	4	55	6800201	Hex Key (5 mm)	1
25	660215010	Screw (M4 x 20 mm).....	2	56	681387002	Wheel (4 in. x 5/8 in. x 2t)	1
26	670030004	Spring Washer	2	Not Shown:			
27	230163006	Motor and Pinion Assembly.....	1		140151001	Charger.....	1
28	672552001	Spring	1		130429017	Battery Pack.....	1
29	515948001	Lock Off Button	1		987000617	Operator's Manual (961067190)	
30	940976588	Data Label.....	1		3-7-11		
31	270017249	Switch Assembly	1		(Rev:03)		