



Parts List for PC70THD Type 2

Item Number	Part Number	Description	Qty Required
1	90569282	HOUSING SET	1
3	90538663	BRUSH RING	1
4	90545899	BRUSH	2
5	90568025	SPACER	2
6	90567892	BEARING PLATE	1
7	90567589	INTERSHAFT	1
8	90567591-01	GEAR CASE ASSY.	1
9	90564365-01	SHIFTER ASSEMBLY	1
11	90567833	PLATE	1
12	90567835	KNOB	1
13	629149-00	SPRING	1
14	622172-00	RATCHET	1
15	90563338	GEAR	1
16	90563340	COMPRESSION SPRING	1
17	90563339	GEAR	1
18	90563337	GUIDE ROD	1
19	90566845	GUIDE PLATE	1
20	90606279	SWITCH	1
21	90539961	CORD PROTECTOR	1
22	90578994-27	CORDSET	1
23	329301-00	CLAMP,CORD	1
25	90571892	LEAD	1
26	90571893	LEAD	1
30	5140071-68	CHUCK & KEY	1
32	605256-01	SCREW	1
33	330019-14	SCREW	4
34	330019-01	SCREW PLASTITE	3

Parts List for PC70THD Type 2

Item Number	Part Number	Description	Qty Required
35	330019-03	SCREW,PLASTITE	7
41	940357-00	GAUGE,DEPTH	1
41	90577908	DEPTH STOP	1
42	N637491	SIDE HANDLE ASSEMBLY	1
42	939794-00	HANDLE ASSY.	1
44	330034-08	KEY,CHUCK	1
45	90538196	CHUCK KEY HOLDER	1
151	90568952	ID LABEL	1
152	90609408	NAME PLATE	1
800	286436-00	GREASE, 500GRAMS	1