



## Parts List for PCB120MS Type 1

Item Number	Part Number	Description	Qty Required
1	5140104-58	BLADE HOLDER	1
2	5140104-59	CUSHION	1
3	5140104-60	STOP SCREW	1
4	5140104-61	LOCK NUT	1
5	5140104-62	CORD CLAMP	1
6	5140104-63	ANCHOR BLOCK	1
7	5140104-64	PIVOT SHAFT	1
8	5140104-65	SLIDE PLATE	3
9	5140104-66	PIVOT SHAFT	1
10	5140104-67	SLEEVE	1
11	5140104-68	SPRING GUARD	1
12	5140104-69	BUMPER	1
13	5140104-70	SHIM	2
14	5140104-71	SPRING	1
15	5140104-72	BEARING	1
16	5140104-73	ROLLING WHEEL	1
17	5140104-74	BEARING	1
18	5140104-75	BOLT	1
19	5140104-76	ARBOR COLLAR	2
20	5140104-77	BLADE WRENCH	1
21	5140104-78	REDUCER	1
22	5140104-79	COMPRESSION SPRING	1
23	5140082-11	HEX WRENCH	1
24	5140082-12	FLAT WASHER	2
25	5140104-80	FLAT WASHER	1
26	5140089-39	FLAT WASHER	2
27	5140104-81	FLAT WASHER	1

## Parts List for PCB120MS Type 1

Item Number	Part Number	Description	Qty Required
28	5140104-82	FLAT WASHER	1
29	5140104-83	FLAT WASHER	2
30	5140104-84	FLAT WASHER	4
31	5140104-85	FLAT WASHER	1
32	5140104-86	FLAT WASHER	1
33	5140082-22	SPRING WASHER	1
34	5140104-87	WAVE WASHER	1
35	5140104-88	E-RING	1
36	5140104-89	SELF LOCKING RING	1
37	5140104-90	O-RING	1
38	5140104-91	O-RING	1
39	5140104-92	HEX HEAD BOLT	1
40	5140104-93	HEX HEAD BOLT	1
41	5140104-94	HEX SOC.HD.BOLT	1
42	5140104-95	HEX SOC.HD.BOLT	1
43	5140104-96	HEX. SOCKET SET SCRE	1
44	5140104-97	HEX. SOCKET SET SCRE	2
45	5140104-98	ARBOR BOLT	1
46	5140104-99	HEX SCREW & WASHER	2
47	5140105-00	HEX SOC HD SCR	1
48	5140084-45	HEX SOC HD SCR	3
49	5140105-01	HEX SOC HD SCR	4
50	5140082-38	SELF TAPPING SCREW	1
51	5140105-02	PAN HEAD SCREW	1
52	5140105-03	TRUSS HEAD SCREW	1
53	284925-00	SCREW	2
54	5140084-50	SELF TAPPING SCREW	2

## Parts List for PCB120MS Type 1

Item Number	Part Number	Description	Qty Required
55	5140105-04	PAN HEAD SCREW	4
56	5140077-71	SCREW	1
57	5140105-05	PAN HEAD SCREW	2
58	5140105-06	PAN HEAD SCREW	2
59	5140084-52	SELF TAPPING SCREW	1
60	5140105-07	PAN HEAD SCREW	10
61	5140105-08	PAN HEAD SCREW	2
62	285304-00	SCREW	2
63	5140105-09	PAN HEAD SCREW	1
64	5140084-56	PAN HEAD SCREW	1
65	5140105-10	HEX NUT	2
66	5140082-48	HEX NUT	2
67	5140077-75	HEX NUT	1
68	5140105-11	HEX NUT	1
69	5140105-12	LOCK NUT	1
70	5140105-13	LOCK NUT	1
71	5140105-14	LOCK NUT	1
72	5140105-15	TERMINAL	2
73	5140105-16	PAN HEAD SCREW	2
74	5140105-17	HEX. SOCKET SET SCRE	1
75	5140105-18	EXTENSION WING	2
76	5140105-19	ARM BRACKET	2
77	5140105-20	SPECIAL BOLT	1
78	5140105-21	NEEDLE POINTER	1
79	5140105-22	SET PLATE	1
80	5140105-23	PIVOT SHAFT	1
81	5140105-24	CROWN NUT	1

## Parts List for PCB120MS Type 1

Item Number	Part Number	Description	Qty Required
82	5140105-25	SPECIAL BOLT	1
83	5140105-26	PIN	2
84	5140105-27	SUPPORT ROD	1
85	5140105-28	GROMMET	1
86	5140105-29	TORSION SPRING	1
87	5140105-30	LOCATING PIN	1
88	5140105-31	PIN	1
89	5140105-32	COLLAR	1
90	5140105-33	TRUSS HEAD SCREW	2
91	5140105-34	FLANGE	1
92	5140105-35	CABLE SHIELD	1
93	5140105-36	FENCE	1
94	5140105-37	COVER	1
95	5140105-38	FENCE	1
96	5140105-39	RIVET	2
97	5140077-99	WARNING LABEL	1
98	5140078-00	WARNING LABEL	1
99	5140105-40	SWITCH ASSY.	1
100	5140105-41	TRIGGER SWITCH	1
101	5140105-42	TRUNNION	1
102	5140105-43	NEEDLE POINTER	1
103	5140105-44	NEEDLE POINTER	1
104	5140105-45	LEVER	1
105	5140105-46	LOCKING ROD	1
106	5140105-47	COIL SPRING	1
107	5140105-48	HANDLE	1
108	5140105-49	HANDLE	1

## Parts List for PCB120MS Type 1

Item Number	Part Number	Description	Qty Required
109	5140105-50	CLAMP BOLT	1
110	5140105-51	CLAMP BOLT	4
111	5140105-52	CLAMP BOLT	1
112	5140105-53	CLAMP HANDLE	1
113	5140105-54	KNOB	4
114	5140105-55	TABLE	1
115	5140105-56	HANDLE	1
116	5140105-57	BASE	1
117	5140105-58	MOTOR ASSY.	1
118	5140105-59	LEAD WIRE ASSY	1
119	5140105-60	HANDLE BAR ASSY	1
120	5140105-61	MATERIAL CLAMP	1
121	5140105-62	CABLE SHIELD	1
122	5140105-63	ARM	1
123	5140105-64	LOCKING HANDLE	1
124	5140105-65	DUST BAG ASSY	1
126	5140105-67	PLASTIC SLEEVE	1
127	5140105-68	LOCKING HANDLE	1
128	5140105-69	BUSHING	1
129	5140105-70	LOCKING HANDLE	1
130	5140105-71	HOUSING ASSY.	1
131	5140105-72	CLEVIS PIN	1
132	5140105-73	TABLE INSERT	1
133	5140105-74	TABLE INSERT	1
135	5140105-76	LABEL	1
136	5140105-77	BRAND LABEL	1
137	5140105-78	SWITCH LABEL	1

## Parts List for PCB120MS Type 1

Item Number	Part Number	Description	Qty Required
138	5140105-79	WARNING LABEL	2
139	5140105-80	WARNING LABEL	1
140	5140105-81	WARNING LABEL	1
141	5140105-82	CAUTION LABEL	1
142	5140105-83	HEX. SOCKET SET SCRE	1
143	5140105-84	TILTING SCALE	2
144	5140105-85	TILT BRACKET	1
145	5140105-86	CAUTION LABEL	1
146	5140105-87	LABEL	1
147	5140105-88	CAUTION LABEL	1
148	5140105-89	CAUTION LABEL	1
149	5140105-90	PLUNGER HSG. ASSY.	1
150	5140105-91	PAN HEAD SCREW	2
151	5140105-92	SHAFT SLEEVE	1
152	5140105-93	ARBOR COLLAR	1
153	5140105-94	LEAD WIRE ASSY	1
154	5140105-95	POWER CABLE	1
155	5140105-96	CONTROLLER ASSY	1
156	5140105-97	CABLE CLAMP	1
157	5140105-98	TRUSS HEAD SCREW	1
158	5140105-99	CUTTER SHAFT GUARD	1
159	5140105-75	PAN HEAD SCREW	1
160	5140106-00	PLUNGER HSG. ASSY.	1
161	5140078-78	LOCK NUT	1
162	5140078-79	LOCK NUT	1
200	5140106-01	SPRING PIN	1
201	5140106-02	HEX. SOCKET SET SCRE	2

## Parts List for PCB120MS Type 1

Item Number	Part Number	Description	Qty Required
202	5140106-03	PAN HEAD SCREW	3
203	5140084-50	SELF TAPPING SCREW	2
204	5140084-09	SELF TAPPING SCREW	2
205	5140106-04	LEAD WIRE ASSY	1
206	5140084-65	COMPRESSION SPRING	1
207	5140084-06	BRUSH HLDR ASSY	2
208	5140084-07	BRUSH ASSY.	2
209	5140084-08	BRUSH COVER	2
210	5140106-05	CUTTER SHAFT ASSY	1
211	5140084-11	WAVE WASHER	1
212	5140106-06	BALL BEARING	1
213	5140106-07	FLOW GUIDE	1
214	5140106-08	PAN HEAD SCREW	4
215	5140106-09	GEAR BOX	1
216	5140106-10	REAR MOTOR COVER	1
217	5140105-52	CLAMP BOLT	1
218	5140106-12	CLEVIS PIN	1
219	5140106-13	FIELD ASSY	1
220	5140106-14	ARMATURE ASSEMBLY	1
222	5140106-16	MOTOR COVER	1
223	5140106-17	BALL BEARING	1