







Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
1	5140132-53	BUSHING	1
2	5140157-77	WORM	1
3	5140082-00	CORD CLAMP	1
4	5140082-01	COMPRESSION SPRING	1
5	5140082-02	STRAP	1
6	5140082-04	SETTING NUT	1
7	5140082-05	ARBOR COLLAR	1
8	5140082-08	LOCATION SEAT	4
9	5140082-11	HEX WRENCH	1
10	5140078-51	FLAT WASHER	1
11	5140104-80	FLAT WASHER	1
12	5140132-59	FLAT WASHER	1
13	5140082-14	FLAT WASHER	1
14	5140082-16	FLAT WASHER	1
15	5140082-18	FLAT WASHER	4
16	5140104-84	FLAT WASHER	1
17	5140157-78	FLAT WASHER	1
18	5140084-32	FLAT WASHER	5
19	5140082-20	FLAT WASHER	1
20	000000-00	No Longer Available	1
21	5140082-23	SPRING WASHER	1
22	5140078-54	LOCK WASHER	2
23	283716-00	WASHER,LOCK	1
24	5140084-37	WAVE WASHER	1
25	5140132-45	SPRING PIN	1
26	5140082-26	C-RING	1
27	5140157-80	E-RING	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
28	5140104-92	HEX HEAD BOLT	2
29	5140132-42	HEX HEAD BOLT	1
30	5140157-81	HEX SOC HD SCR	2
31	5140132-50	HEX SOC HD SCR	1
32	5140078-65	HEX SOC HD SCR	4
33	5140082-28	PAN HEAD SCREW	1
34	5140082-30	TRUSS HEAD SCREW	1
35	5140078-70	SCREW	1
36	5140082-31	TRUSS HEAD SCREW	2
37	5140157-82	CR. RE. TRUSS HD SCR	2
38	5140082-32	TRUSS HEAD SCREW	2
39	5140157-83	CR. RE. TRUSS HD SCR	1
40	5140077-69	SCREW	2
41	5140082-33	SELF TAPPING SCREW	4
42	5140082-34	SELF TAPPING SCREW	4
43	5140082-35	SELF TAPPING SCREW	4
44	5140084-50	SELF TAPPING SCREW	4
45	5140082-36	SELF TAPPING SCREW	2
46	5140082-37	SELF TAPPING SCREW	2
47	5140082-38	SELF TAPPING SCREW	2
48	5140082-39	SELF TAPPING SCREW	1
49	5140082-40	SELF TAPPING SCREW	5
50	5140082-41	SELF TAPPING SCREW	2
51	5140082-42	SELF TAPPING SCREW	2
52	5140082-43	SELF TAPPING SCREW	10
53	5140082-44	SELF TAPPING SCREW	2
54	5140077-72	SCREW	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
55	5140082-45	PAN HEAD SCREW	2
56	5140132-84	CAP HD SQ NECK BOLT	1
57	5140082-47	BOLT	1
58	5140082-48	HEX NUT	3
59	5140084-57	HEX NUT	4
60	5140157-84	HEX NUT	2
61	5140132-56	FLANGE NUT	1
62	5140082-49	NUT	2
63	5140078-78	LOCK NUT	3
64	284867-00	CHUCK,NUT	4
65	5140082-51	STRAIN RELIEF	1
66	5140082-52	STRAIN RELIEF	2
67	5140082-53	CABLE CLAMP	1
68	5140082-54	LEADWIRE ASSY.	1
69	5140082-55	CIRCUIT BRKR/SWITCH	1
70	5140157-85	LOCATING RING	1
71	5140082-58	RUBBER PAD	1
72	5140157-86	SUPPORT	2
73	5140157-87	PIVOT SHAFT	1
74	000000-00	No Longer Available	1
75	5140157-89	LOCATING BAR	1
76	5140157-90	ROLL PIN	1
77	000000-00	No Longer Available	2
78	5140157-92	LOCATING BAR	1
79	5140157-93	BUSH	2
80	5140157-94	PARALLEL PIN	2
81	5140131-61	HEX SOC.HD.BOLT	4

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
82	5140157-95	BRACKET STOP	1
83	5140078-93	HEX SOC HD SCR	4
84	5140082-69	SCREW W/WASHER	1
85	5140082-70	FOLLOWER PLATE	1
86	5140082-73	CORD CLAMP	2
87	5140082-76	LOCATION SEAT	1
88	5140132-33	HEX SOC HD SCR	4
89	5140082-77	COVER	1
90	5140082-79	NEEDLE POINTER	1
91	5140082-80	TILT POINTER	1
92	000000-00	No Longer Available	1
93	5140082-82	PUSH STICK	1
94	5140082-83	CUSHION	1
95	000000-00	No Longer Available	1
96	5140082-84	HANDLE	1
97	5140082-85	LOCATING BAR	1
98	5140132-30	CLAMP BRACKET	1
99	5140132-31	GEAR	1
100	5140132-32	GUIDE CLAMP	4
101	5140132-36	RETAINING CLIP	1
102	5140132-41	SPACER	1
103	5140132-54	COLLAR	1
104	5140132-55	FLAT WASHER	1
105	5140082-98	POINTER BRACKET	1
106	5140096-02	HANDLE	1
107	5140083-05	FRONT SIDE COVER	1
108	5140157-97	SIDE COVER-R.H.	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
109	5140083-09	RETAINING CLIP	1
110	000000-00	No Longer Available	1
111	5140083-20	SWITCH KEY	1
112	5140078-14	ROCKER SWITCH	1
113	5140083-24	HAND WHEEL ASSY.	1
114	5140083-27	MITER GAUGE ASSY	1
115	5140083-29	LOCK HANDLE ASSY	1
116	5140083-30	HEX WRENCH	1
117	5140083-31	WRENCH	1
118	5140083-32	POWER CABLE	1
119	5140083-35	EXTENSION TABLE	1
120	5140083-37	LABEL	1
121	5140083-38	WARNING LABEL	1
122	5140083-39	STICKER	1
123	5140132-63	RETAINING CLIP	2
124	5140085-76	HANDLE ASSY.	1
125	5140083-45	PLUNGER HSG. ASSY.	1
126	5140083-47	LEAD WIRE ASSY	1
127	5140131-65	HANDLE	1
128	5140157-98	SLIDER	1
129	5140157-99	SUPPORT	1
130	5140158-00	BODY	1
131	5140158-01	PIVOT SUPPORT	1
132	5140158-02	TABLE	1
133	5140158-03	EXTENSION WING	1
134	5140158-04	PIVOT SUPPORT	1
135	5140158-05	RAIL	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
136	5140158-06	UPPER TUBE	2
137	5140158-07	BODY SHELL	1
138	000000-00	No Longer Available	1
139	5140158-09	DUST COLLECTOR	1
140	5140158-10	RIVING KNIFE	1
141	5140158-11	BLADE GUARD	1
142	5140158-12	BLADE GUARD	1
143	5140158-13	SIDE COVER	2
144	5140158-14	MOTOR ASSY	1
145	5140158-15	LOCKING ROD	1
146	5140158-16	SCALE ASSY.	1
147	5140158-17	RIP FENCE ASSY	1
148	5140158-18	ANTI-KICKBACK	1
149	5140158-19	BLADE GUARD ASSY	1
150	5140158-20	SLIDING BASE ASSY.	1
151	5140158-21	SLIDING BASE ASSY.	1
152	5140158-22	BEVEL ADJ. ASSY.	1
153	5140158-23	HEIGHT ADJUST BOLT	1
154	5140158-24	LABEL	1
155	5140158-25	SCALE	1
156	5140158-26	CAUTION LABEL	1
157	5140083-25	HAND WHEEL ASSY.	1
158	5140158-29	RACK	2
159	5140158-30	PUSH IN PIN	2
160	000000-00	No Longer Available	1
161	5140158-32	SWITCH BOX ASSY	1
162	5140158-33	WARNING LABEL	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
163	5140158-34	WARNING LABEL	1
164	5140160-29	DADO THROAT PLATE	1
164	5140158-35	TABLE INSERT ASSY	1
200	5140158-37	FLAT WASHER	4
201	5140083-52	FLAT WASHER	4
202	5140158-38	HEX HD BOLT	2
203	5140079-44	HEX HEAD BOLT	4
204	5140077-66	BOLT	1
205	000000-00	No Longer Available	4
206	5140078-70	SCREW	3
207	5140158-40	CR. RE. TRUSS HD SCR	4
208	000000-00	No Longer Available	2
209	000000-00	No Longer Available	4
210	5140158-43	CR. RE. TRUSS HD SCR	2
211	000000-00	No Longer Available	1
212	5140077-78	HEX NUT	1
213	284867-00	CHUCK,NUT	8
214	5140078-79	LOCK NUT	14
215	5140083-57	NUT	3
216	000000-00	No Longer Available	2
217	5140085-85	HEX NUT	4
218	5140083-65	WING NUT	1
219	000000-00	No Longer Available	2
220	5140158-47	FLAT WASHER	2
221	000000-00	No Longer Available	2
222	000000-00	No Longer Available	6
223	000000-00	No Longer Available	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
224	5140083-89	SLEEVE	2
225	000000-00	No Longer Available	1
226	5140132-83	TAPPING SCREW	2
227	5140083-99	BOLT	1
228	000000-00	No Longer Available	3
229	5140158-53	CASTER	2
230	5140158-54	RUBBER BUSHING	4
231	5140158-55	TUBE	1
232	000000-00	No Longer Available	1
233	000000-00	No Longer Available	1
234	5140158-58	SPACER	8
235	000000-00	No Longer Available	1
236	000000-00	No Longer Available	1
237	5140158-61	ELBOW	2
238	000000-00	No Longer Available	1
239	000000-00	No Longer Available	2
240	000000-00	No Longer Available	1
241	5140158-65	TUBE	1
242	000000-00	No Longer Available	2
243	000000-00	No Longer Available	1
244	000000-00	No Longer Available	1
245	000000-00	No Longer Available	1
246	000000-00	No Longer Available	6
247	5140158-71	BOTTOM BRACKET ASSY.	1
248	000000-00	No Longer Available	1
249	5140158-73	STIFFENER ASSY.	1
250	5140158-74	LEVELING PAD	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
251	000000-00	No Longer Available	4
252	000000-00	No Longer Available	2
253	5140158-77	BUMPER	2
254	000000-00	No Longer Available	2
255	000000-00	No Longer Available	2
256	000000-00	No Longer Available	1
257	5140158-81	ADJUSTABLE FOOT	1
258	5140158-82	HEX HEAD BOLT	1
259	000000-00	No Longer Available	1
260	5140158-84	CAP HD SQ NECK BOLT	2
261	000000-00	No Longer Available	1
262	000000-00	No Longer Available	1
263	000000-00	No Longer Available	1
264	000000-00	No Longer Available	1
300	5140132-26	SCREW AND WASHER	4
301	5140084-00	BALL BEARING	1
302	5140084-01	NEEDLE BEARING	1
303	5140084-02	C-RING	1
304	5140084-03	PARALLEL KEY	1
305	5140084-04	HEX SOC HD SCR	2
306	5140084-09	SELF TAPPING SCREW	2
307	5140082-52	STRAIN RELIEF	1
308	5140084-06	BRUSH HLDR ASSY	2
309	5140084-07	BRUSH ASSY.	2
310	5140084-08	BRUSH COVER	2
311	5140084-11	WAVE WASHER	1
312	5140084-12	FLOW GUIDE	1

Parts List for PCB222TS Type 1

Item Number	Part Number	Description	Qty Required
313	5140084-13	MOTOR COVER	1
314	5140084-14	SPACER	1
315	5140084-15	GEAR	1
316	5140084-16	CUTTER SHAFT ASSY	1
317	5140084-17	BEARING COVER	1
318	5140084-18	BEARING SEAT	1
319	5140084-19	ARMATURE ASSY.	1
320	5140084-20	SCREW	2
321	5140084-21	LABEL	1
322	5140158-36	BRACKET	1