



Parts List for PCK647LB Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|------------------|--------------|
| 1 | 90622439 | HOUSING ASSEMBLY | 1 |
| 3 | 90634946 | COVER | 1 |
| 4 | 5100035-03 | SPRING | 2 |
| 5 | 90556571 | NUT | 2 |
| 6 | 90627916 | BEZEL | 1 |
| 7 | 607906-02 | #2 PHIL. BIT TIP | 1 |
| 8 | 90628279 | REAR BADGE | 1 |
| 9 | 90629054 | FWD/REV BUTTON | 1 |
| 10 | 90627915 | PCB ASSEMBLY | 1 |
| 11 | 90626771 | GEARBOX ASSY | 1 |
| 13 | 90637196 | SCREW | 4 |
| 14 | 148354-03 | BIT CLIP | 1 |
| 15 | 90632774 | ELECTRONIC MOD. | 1 |
| 16 | 90637197 | SCREW | 3 |
| 17 | 90587838 | BELT CLIP | 1 |
| 18 | 90573424 | SCREW | 1 |
| 19 | 90630609 | RATING LABEL | 1 |
| 866 | PCC680L | BATTERY PACK | 1 |
| 871 | 90634912 | CHARGER | 1 |