



Parts List for PCE310 Type 1

Item Number	Part Number	Description	Qty Required
3	90568794	BRUSH &SPRING	2
4	90568788	BRUSH HOLDER	2
5	90568789	BRUSH CAP	1
8	90632708	RETAINER	1
11	90632702	LOWER GUARD	1
13	90632704	OUTPUT SPND.ASY	1
14	90568897	TORSION SPRING	1
15	90633041	SPRING CLIP	1
16	90632707	OUTER FLANGE	1
17	90578338	HEX SOC HD SCR	1
18	90569118	RUBBER STOP	1
19	90568797	CORD PROTECTOR	1
20	90632286	CARRIAGE BOLT	1
21	90635611	PIVOT PIN	1
22	90578384	E-CLIP	1
23	90633056	SPINDLE LOCK	1
24	90632292	E-CLIP	1
25	90632291	SPRING	1
27	90579371	ALLEN WRENCH	1
31	330024-13	MACHINE SCREW	1
32	330019-41	SCREW	5
33	330019-17	SCREW	2
36	370748	SCREW	2
37	N520004	SHOE ASSY.	1
46	90639988	SCREW	1
47	90568918	COMPRESSION SPRING	1
49	330016-18	WASHER	2

Parts List for PCE310 Type 1

Item Number	Part Number	Description	Qty Required
50	90569115	LOCK NUT	1
51	90641175	E-CLIP	1
52	90636210	LEVER	1
54	90632720	LOCK NUT	1
59	90595774	SWITCH	1
60	90576742	CORD SET	1
61	329301-00	CLAMP,CORD	1
62	370748	SCREW	2
63	330019-04	SCREW,PLASTITE	5