



Parts List for PCE6430 Type 1

Item Number	Part Number	Description	Qty Required
1	N381881	MOTOR CASE	1
2	N381882	BRACKET	1
3	N381911	TOP COVER	1
4	N381700	ARMATURE (120V)	1
5	N381701	FIELD (120V)	1
6	N381876	DEPTH ADJUSTING RING	1
7	N381738	BASE ASSEMBLY	1
8	N381883	SWITCH LEVER	1
9	N381703	MAGNET ASSY	1
10	N381502	COLLET	1
11	N381503	COLLET NUT	1
12	N381884	SPINDLE LOCK BUTTON	1
13	N381505	SPINDLE LOCK COVER	1
14	N381506	SPINDLE LOCK PLATE	1
15	N381513	COMPRESSION SPRING	1
16	N381514	ACTUATOR SPRING	1
17	N381704	POWER CORD	1
18	N381705	STRAIN RELIEF	1
19	N381706	CORD CLAMP	1
20	N381707	BRUSH HOLDER	2
21	N381708	BRUSH PAIR	1
22	N381709	BRUSH CAP	2
23	860094-03	SCREW	2
24	860094-05	SCREW	2
25	N381713	SELF TAPPING SCREW	2
26	N381714	SELF TAPPING SCREW	3
27	330019-41	SCREW	2

Parts List for PCE6430 Type 1

Item Number	Part Number	Description	Qty Required
28	N381716	SELF TAPPING SCREW	2
29	330019-17	SCREW	2
30	N381718	CLAMP,BEARING	1
31	N381719	RETAINING RING	1
32	330003-12	BEARING,BALL	1
33	605040-65	BALL BEARING	1
34	N276093	WARNING LABEL	1
35	N278601	BRAND LABEL	1
36	N377078	RATING LABEL	1
38	N381723	HOLDER,BEARING	1
39	N381724	RING	1
41	N381725	KNOB	1
42	N381726	FLAT WASHER	1
43	N381727	SPRING WASHER	1
44	N276107	WARNING LABEL	1
45	N381728	SUB-BASE	1
46	949894-06	SCREW	4
47	N381730	SWITCH	1
48	N381731	LED BOARD	1
49	N381732	LED ASSY	1
70	N381527	SET SCREW	1
71	N381739	BASE	1
72	N381520	CLAMP LEVER	1
73	N381521	CLAMP LINK	1
74	N381522	HOOK	2
75	N381523	HOOK SPRING	2
76	N381524	PIN	2

Parts List for PCE6430 Type 1

Item Number	Part Number	Description	Qty Required
77	N381525	PIN	2
78	N381526	PIN	1
79	N381749	PIN	1
500	N361320	EDGE GUIDE	1
503	N361321	WRENCH	1