



BOSCH

Random orbital sander

PEX 12 A | 0 603 310 043

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list

Item	Part Number	Description		
3	2 604 011 265	Armature	220-240V	
3/50	2 606 610 077	Fan		
4	2 607 200 260	Switch		
5	1 614 460 072	Power supply cord		
6	2 600 703 017	Grommet	Ø6,4-Ø7,2x76 MM	
7	2 601 035 001	Cable Clip		
9	2 601 118 415	Manufacturer's nameplate		
12	1 607 328 028	Suppression Filter		
14	2 600 905 034	groove ball bearing		
16	2 604 337 118	Brush Plate		
18	2 603 410 001	Socket head cap screw	M3x6,5-4.8	
19	2 603 490 022	Screw	4x16	
32	2 601 329 057	Contact Spring		
33	2 608 601 061	Backing Pad	Ø 125 MM	
33	2 608 601 062	Backing Pad	Ø 125 MM	
33	2 608 601 063	Backing Pad	Ø 125 MM	
36	1 603 100 036	Rubber Buffer		
38	2 604 448 180	Connecting Cable	L=113 MM	WHITE
39	2 604 448 181	Connecting Cable	L=233 MM	WHITE
42	2 604 448 184	Connecting Cable		
43	2 603 490 023	Torx Oval-Head Screw	4x20	
44	2 602 380 003	Seal Strip		
45	2 602 025 068	Handle	BLACK	
46	2 910 285 226	Round-Head Bolt	DIN 603-M6x110	
47	1 603 339 006	Wing Nut	M6	
48	2 608 005 043	Pusher		
50	2 610 364 015	Hexagon Socket Screw Key	5 MM	
51	2 600 206 015	Friction Ring		
52	2 601 022 000	Damping Plate		
801	2 605 104 796	Housing Section	GREEN	
808	2 601 117 166	Marking Plate		
813	2 605 805 005	Cartridge bearing		
816/04	2 604 321 917	Carbon-Brush Set		
816/05	2 604 610 026	Compression Spring		
816/06	2 601 322 017	Ratchet Cap		

Spare parts list

Item	Part Number	Description
826	2 606 610 901	Fan LEFTHAND THREADS
835	2 603 414 062	Hex Socket Head Cap Screw
854	2 605 411 129	Dust Chamber
855	2 605 702 039	Adapter

Illustration - Type - E

0 603 310 003
 Stand } 27-11
 Issue } 18-10-30

Fig./Abb. 1

