



## PJ7000 Plate Joiner Parts Breakdown

Item	Parts_No.	Parts_Description	Qty
1	922422-3	HEX. SOCKET HEAD BOLT M8X16	2
2	941202-8	FLAT WASHER 8	2
3	453218-6	GRIP	1
4	266324-6	TAPPING SCREW 4X22	4
5	417771-6	PIN CAP	1
6	234057-1	COMPRESSION SPRING 8	1
7	252186-8	HEX. NUT M6	1
8	227545-5	SPIRAL BEVEL GEAR 10	1
9	213445-5	O-RING 26	1
10	211092-6	BALL BEARING 629DDW	1
11	962105-3	RETAINING RING R-26	1
12	413126-3	GUIDE PLATE	1
13	240107-2	FAN 56	1
14	517646-0	ARMATURE ASS'Y 115V	1
14		INC. 131516	0
15	681636-0	INSULATION WASHER	1
16	210034-7	BALL BEARING 607LLB	1
17	421868-5	LABYRINTH RUBBER RING 19	1
18	450796-7	BAFFLE PLATE	1
19	266325-4	TAPPING SCREW 4X70	2
20	623531-8	FIELD 115V	1
21	896483-8	PJ7000 NAME PLATE	1
22	266492-5	TAPPING SCREW 3X8	2
23	643839-4	BRUSH HOLDER 6X9	2
24	195025-8	CARBON BRUSH CB-458	1
25	650621-4	SWITCH PS10	1
26	687681-3	STRAIN RELIEF	1
27	266326-2	TAPPING SCREW 4X18	1
29	682502-4	CORD GUARD 8-85	1
30	664064-4	POWER SUPPLY CORD AWG#18-2-2.5	1
31	266326-2	TAPPING SCREW 4X18	1
32	450794-1	REAR COVER	1
33	450797-5	SWITCH LEVER	1
34	233121-5	COMPRESSION SPRING 4	1
35	141325-4	MOTOR HOUSING COMPLETE	1
35	890412-3	CAUTION LABEL	1
36	419566-3	SWITCH KNOB	1
37	213032-0	O RING 4	1
38	256510-7	SHOULDER PIN 4	1
39	141327-0	GEAR HOUSING COMPLETE	1
39	263002-9	RUBBER PIN 4	1
40	210033-9	BALL BEARING 696ZZ	1
41	233950-6	RING SPRING 11	1
42	227546-3	SPIRAL BEVEL GEAR 37	1
43	962151-6	RETAINING RING R-32	1
44	211129-9	BALL BEARING 6201DDW	1

45	326120-5	SPINDLE	1
46	213561-3	O RING 42	1
47	318811-2	BEARING BOX	1
48	911136-9	PAN HEAD SCREW M4X20	4
49	911136-9	PAN HEAD SCREW M4X20	2
50	931203-4	HEX. NUT M5	1
51	266741-0	PAN HEAD SCREW M5X50	1
52	453406-5	BASE COVER	1
53	326145-9	ROD 10	2
54	141247-8	FENCE COMPLETE	1
54	890236-7	SCALE PLATE	1
55	961017-7	STOP RING E-3	2
56	256689-4	PIN 4	2
57	318813-8	BASE	1
58	231282-5	COMPRESSION SPRING 2.4	1
59	216001-0	STEEL BALL 3.5	1
60	318814-6	STOPPER	1
61	266264-8	H.S.SET SCREW(FLAT POINT)M5X6	2
62	266738-9	#NAME?	1
63	213008-7	O RING 22.4	1
64	415252-4	DUST NOZZLE	1
65	265785-7	THUMB SCREW M5X10	1
66	232131-9	LEAF SPRING	1
67	213023-1	O RING 4	1
68	266737-1	FLAT HEAD SQ. NECK BOLT M6X20	1
69	231282-5	COMPRESSION SPRING 2.4	1
70	216001-0	STEEL BALL 3.5	1
71	231795-6	TENSION SPRING 8	2
72	272263-0	LEVER 40	1
73	252159-1	HEX. NUT M6	1
74	961014-3	STOP RING E-8	1
75	253804-1	FLAT WASHER 6	1
76	224280-6	INNER FLANGE 40	1
77	224505-8	LOCK NUT 10-40	1
78	318845-5	BLADE COVER	1
79	424479-5	RUBBER SPIKE	2
80	213023-1	O RING 4	1
A01	123148-2	ANGLE GUIDE ASSEMBLY	1
A01		COMPO-PARTS	0
A02	123150-5	DUST BAG ASSEMBLY	1
A02	410602-8	FASTENER	1
A03	415579-2	SET PLATE 4	1
A04	A-95118	CUTTER 100MMX6T	1
A05	782401-1	LOCK NUT WRENCH 20	1
A06	821509-7	PLASTIC CARRYING CASE	1
A06	163455-1	LATCH	2

