



BOSCH

Percussion Drill

PSB 400 | 0 603 248 043

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list

Item	Part Number	Description		
1	2 605 104 569	Housing Section	GREEN	
2	2 604 220 555	Field	230V	
3	2 604 011 225	Armature With Fan	220-230V	
3/60	1 619 P11 262	Fan		
4	2 607 200 260	Switch		
5	1 614 460 072	Power supply cord		
6	2 600 707 059	Grommet	Ø6,9 MM	
7	2 601 035 001	Cable Clip		
9	2 601 118 978	Manufacturer's nameplate	SUNNY SIDE	
12	2 607 329 138	Suppression Capacitor		
13	2 600 905 032	Ball Bearing	7x19x6	
14	1 619 P00 433	Needle-Roller Bearing		
16	2 609 992 607	Brush Plate		
18	2 603 410 001	Socket head cap screw	M3x6,5-4.8	
19	2 603 490 022	Screw	4x16	
20	2 601 118 979	Reference Plate	SHADOW SIDE	
26	2 601 022 000	Damping Plate		
27	2 600 917 003	Needle-Roller Bearing	Ø8x8 MM	
29	1 900 210 000	O-Ring	5,0x1,5 MM	
30	2 601 990 000	Indexing Disk		
31	2 600 100 034	Supporting Disc		
32	2 600 025 005	Pressure Plate		
33	1 903 230 011	Ball	DIN 5401-6 G28	
35	2 910 951 132	Oval-Head Screw	DIN 7985-M4x25-8.8	
41	2 601 290 014	Disc Spring		
45	2 600 005 012	Felt		
46	2 604 448 122	Connecting Cable	L=162MM	WHITE
47	2 604 448 045	Cable	L=98 MM	BLACK
48	2 604 448 130	Connecting Cable	L=88 MM	WHITE
52	2 604 448 123	Connecting Cable	L=73 MM	WHITE
54	2 601 329 043	Contact Strap		
739	1 608 571 054	Key Chuck	Ø1-10 MM, 1/2"-24UNF	
739/7	2 607 950 007	Chuck Wrench	SG2	
808	2 609 922 499	Nameplate		
816/04	2 604 321 905	Carbon-Brush Set		

Spare parts list

Item	Part Number	Description
816/06	2 601 322 017	Ratchet Cap
828	2 912 401 020	Tapping Screw DIN 7981-3,9x19-C-Z-ST
834	2 605 807 931	Bearing Bracket
836	2 606 135 927	Drilling Spindle 1/2"
864	2 603 490 018	Torx Oval-Head Screw 3x18

Illustration - Type - E

0 603 248 003
 Stand }
 Issue } 99-05-11

Fig./Abb. 1

