



Parts List for PW18-B2C Type 1

Item Number	Part Number	Description	Qty Required
1	5140136-96	GUARD	1
2	5140137-70	CASING	1
3	5140137-84	KNOB	1
4	5140137-89	SWITCH	1
5	5140138-32	SUPPORT	1
6	5140137-98	SUCTION KIT	1
7	5140137-92	DELIVERY KIT	1
8	5140138-51	PUMP ASSEMBLY	1
9	5140137-11	BRUSH KIT	1
10	5140125-97	WATER COUPLING KIT	1
11	5140136-99	CONVEYOR	1
12	5140137-00	COVER	1
13	5140138-23	CASING	1
14	5140138-40	PLUG	1
15	5140138-41	TANK	1
16	5140138-36	NOZZLE CLEANING TOOL	1
17	5140138-39	LEVER	1
18	5140138-37	GREASE	1
19	5140138-46	WHEEL	2
20	5140138-35	BRACKET	1
21	5140138-34	BRACKET	1
22	5140138-24	BASE	1
23	5140126-64	CABLE	1
24	5140137-05	TSS KIT	1
25	5140138-00	PISTON SEAL KIT	1
26	5140137-97	WATER SEAL KIT	1
27	5140138-02	DETERGENT KIT	1

Parts List for PW18-B2C Type 1

Item Number	Part Number	Description	Qty Required
28	5140137-99	SCREW KIT	1
29	5140138-27	BRACKET	1
30	5140137-88	HUB PIN	2
31	5140137-74	BRACKET	1
32	5140137-77	ACCESSORY HOLDER	1
33	5140137-78	ACCESSORY HOLDER	1
34	5140137-73	HANDLE	1
35	5140126-60	QUICK COUPLING	1
101	5140137-42	GUN	1
102	5140137-50	EXTENSION	1
103	5140137-58	LANCE HEAD	1
104	5140137-10	GASKET KIT	1
105	5140138-55	HIGH PRESSURE HOSE	1