

PARTS LIST


LISTE DES PIÈCES

LISTA DE PIEZAS

KEY	P/N	DESCRIPTION	QTY	PIÈCE RÉF.	DESCRIPTION	QTÉ	REF. N/P	DESCRIPCIÓN	CANT.		
1	661075001	Screw (M5 x 28 mm, T25 Torx Pan Hd.).....	4	1	661075001	Vis (M5 x 28 mm, tête bombée Torx T25)....	1	661075001	Tornillo (M5 x 28 mm, cab. tronc. Torx T25).....	4	
2	204992002	Gear Case Assembly	1	2	204992002	Ensemble de carter et couvercle.....	1	204992002	Conjunto de caja de engranajes.....	1	
3	550339001	Rubber Plug.....	1	3	550339001	Bouchon de caoutchouc	1	2	550339001	Tapón de goma.....	1
4	660385018	Screw (M5 x 14 mm, T25 Torx Pan Hd.).....	4	4	660385018	Vis (M5 x 14 mm, tête bombée Torx T25)....	4	3	660385018	Tornillo (M5 x 14 mm, cab. tronc. Torx T25).....	4
5	564333001	O-ring (ID64 x OD69 x 2.5t).....	1	5	564333001	Joint torique (ID64 x OD69 x 2.5t).....	1	4	564333001	Junta tórica (ID64 x OD69 x 2.5t).....	1
6	204991003	Output Shaft and Gear Case Cover	1	6	204991003	Arbre de sortie et couvercle du carter d'engrenage	1	5	204991003	Eje de salida y tapa caja engranajes	1
7	672503001	Backing Flange.....	1	7	672503001	Claque de support.....	1	6	672503001	Brida de apoyo	1
8	671701002	Clamp Nut (5/8-11 unc).....	1	8	671701002	Écrou de serrage (5/8-11 unc).....	1	7	671701002	Tuerca de fijación (5/8-11 unc).....	1
9	531975002	Gear Case Cap.....	1	9	531975002	Capuchon de carter et couvercle	1	8	531975002	Tapa de caja de engranajes.....	1
10	662088001	Screw w/Washer (M5 x 10.5 mm, Pan Hd.)..	2	10	662088001	Vis w/rondelle (M5 x 10.5 mm, tête bombée)	2	10	662088001	Tornillo w/arandela (M5 x 10.5 mm, cab. tronc.)	2
11	206760002	Armature Assembly	1	11	206760002	Ensemble d'armature	1	11	206760002	Conjunto de inducido	1
12	206822002	Field, Circuit Board and Contact Plate Holder Assembly	1	12	206822002	Carte de circuit imprimé et ensemble de plaque de contact.....	1	12	206822002	Placa de circuits y conjunto del placa de catacto.....	1
13	660024044	Screw (M4 x 16 mm, T20 Torx Pan Hd.).....	17	13	660024044	Vis (M4 x 16 mm, tête bombée Torx T20)...	17	13	660024044	Tornillo (M4 x 16 mm, cab. tronc. Torx T20).....	17
14	204993002	Motor Housing Assembly	1	14	204993002	Ensemble de boîtier du moteur	1	14	204993002	Conjunto de alojamiento del motor	1
15	204994002	Damper Assembly	1	15	204994002	Ensemble de registre.....	1	15	204994002	Conjunto de amortiguador	1
16	639039001	Wavy Washer	1	16	639039001	Rondelle ondulée.....	1	16	639039001	Arandela ondulada	1
17	696093002	Compression Spring.....	1	17	696093002	Ressort de compression.....	1	17	696093002	Resorte de compresión	1
18	531973001	Lock Button	1	18	531973001	Bouton de verrouillage	1	18	531973001	Botón del seguro	1
19	204995002	Handle Assembly.....	1	19	204995002	Ensemble de poignée.....	1	19	204995002	Conjunto del mango	1
20	300160017	Side Handle Assembly	1	20	300160017	Ensemble de poignée latérale	1	20	300160017	Conjunto del mango lateral	1
21	204997004	Guard Assembly	1	21	204997004	Ensemble de protège	1	21	204997004	Conjunto de la protección	1
22	901964001	Grinding Wheel (7 in.)	1	22	901964001	Meule disque (7 po).....	1	22	901964001	Muela abrasiva (7 pulg.)	1
23	634192002	Spanner Wrench.....	1	23	634192002	Clé à ergots	1	23	634192002	Llave de gancho	1
24	672665001	Wavy Washer	1	24	672665001	Rondelle ondulée.....	1	24	672665001	Arandela ondulada	1
25	941122093	Data Label	1	25	941122093	Étiquette de données	1	25	941122093	Etiqueta de datos	1
26	940534055	Side Label.....	2	26	940534055	Étiquette latérale.....	2	26	940534055	Etiqueta de lateral.....	2
27	941120405	Warning Label.....	1	27	941120405	Étiquette d'avertissement.....	1	27	941120405	Etiqueta de advertencia.....	1
	Not Shown 995000564	Operator's Manual (961152970)			Non illustré 995000564	Manuel d'utilisation (961152970)			No se ilustra 995000564	Manual del operador (961152970)	

RIDGID

R88040



WIRING DIAGRAM
SCHÉMA DE CÂBLAGE / DIAGRAMA DE CABLEADO