



Parts List for RD1440K Type 1

Item Number	Part Number	Description	Qty Required
1	498796-00	KEYLESS CHUCK	1
2	149518-01	SCREW	1
3	607918-41	SCREWDRIVER BIT	1
866	FSB14	BATTERY	1
867	5102026-00	BATTERY CAP	1
871	90500933	CHARGER	1