













Parts Breakdown

RPT250

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	621-10150-01	PIPE SHAFT COMPLETE, RBC252	1
1	621-10260-00	SHAFT PIPE CPL.RBC2510	1
2	619-15004-01	SHAFT, EM4250	1
3	601-95025-00	CAUTION LABEL, RPT250	1
4	627-15015-00	SPACER, EM4251	1
4	627-15015-01	SPACER, EM4251	1
5	625-95147-00	CAUTION LABEL, RBC321	1
6	621-40140-01	HANDLE COMPLETE, RPT250	1
6	621-40160-00	HANDLE SET, RBC2510	1
7	627-40040-10	LOOP HANDLE, EM4251	1
8	621-40140-10	GUARD STAY, EM4251	2
9	621-40160-20	HANDLE HOLDER, RBC2510	1
9	627-40040-20	LOOP HANDLE COVER, EM4251	1
10	621-40160-30	SCREW, RBC2510	4
10	627-40040-41	S.H. BOLT M6X18,RPT250	2
11	273668-7	N/A	1
11	601-45038-00	GRIP, RPT250	1
12	601-50010-00	CONTROL LEVER ASS'Y,RPT250	1
13	625-40190-00	HANGER ASSY, RBC251	1
14	004-36052-00	SCREW & WASHER ASS'Y, RBC281	1
15	601-50010-00	CONTROL LEVER ASS'Y,RPT250	1
16	619-50060-30	LEVER, EM4251	1
17	621-50230-60	LEVER, EM4251	1
18	619-50061-50	TOP, RPT250	1
19	601-50010-10	SWITCH ASS'Y, RPT250	1
20	601-50010-20	WIRE COMPLETE, RPT250	1
21	619-50060-50	SPRING, EM4251	1
22	011-90597-20	S.H. BOLT M5X20, EM4251	2
23	641-50111-60	NUT M5, EM4251	2
24	619-50060-60	T. SCREW M4X20, EM4251	4
25	034-00090-0R	CLAMP LEVER, RPT250	1
26	210-06000-0K	SPRING WASHER M6, RPT250	3
27	207-06020-9K	WASHER,RPT250	3
28	224-14500-3A	PLATE, RPT250	1
29	054-06022-0K	BOLT M6X22, RPT250	2
30	224-14800-2A	CASE A, RPT250	1
31	224-14100-3A	HANDLE, RPT250	1
32	150-06000-0K	HEX NUT M6, EH561	2
33	055-00010-0R	GREASE NIPPLE, EH450	3
34	016-04008-0K	SCREW M4X8, RPT250	4
35	196-11200-4A	PLATE, RPT250	1
36	280-00600-0K	STOP RING ETW6, RPT250	2
37	023-50044-4A	GEAR, RPT250	1
38	282-02600-0K	SNAP RING(INNER)R26,RPT250	2
39	354-06000-0K	BALL BEARING 6000,RPT250	2
40	024-00005-3A	CRANK SHAFT, RPT250	1
41	283-02800-0K	SNAP RING STW28, RPT250	1
42	224143009A	BLADE SET, RPT250	2
43	351-00608-0K	BALL BEARING 608Z, EH561	1
44	224-15300-3A	CASE LOWER, RPT250	1
45	054-04012-0K	BOLT M4X12, RPT250	4
46	224-11200-4A	FELT, RPT250	1
47	040-00200-9A	BLADE SLIDING SCREW (L=19), EH450	1
48	008-25000-00	BLADE SLIDING WASHER, EH561	5
49	040-00100-9A	SCREW L17, RPT250	4
50	164-06000-0K	HEX U-NUT M6, EH561	5
51	031-05020-0K	C.S.H. SCREW M3X5, EH561	2
52	224-14400-3A	GUIDE PLATE, RPT250	1
53	224-13100-4A	GUIDE, RPT250	1
54	224-10800-4A	PLATE, RPT250	1
55	162-05000-0K	FLANGE NUT M5, EH561	2
56	054-06012-0K	BOLT M6X12,RPT250	2
57	354-00608-0K	BALL BEARING 608, RPT250	1
58	282-02200-0K	SNAP RING (INNER)R22,RPT250	2



Parts Breakdown

RPT250

59	224-13000-4A	GEAR SHAFT, RPT250	1
60	440-P4100-0K	O RING, RPT250	1
61	224-15400-4A	PACKIN, RPT250	1
62	224-14900-2A	CASE B, RPT250	1
63	200-05000-0K	WASHER, RPT250	2
64	010-05010-0K	P.H.SCREW M5X10, RPT250	1
65	054-05025-0K	BOLT M5X25, RPT250	1
66	224-14600-4A	JOINT R, RPT250	1
67	196-10900-4A	GEAR SHAFT B, RPT250	1
68	352-06900-0K	BALL BEARING 6900, RPT250	2
69	023-50043-4A	GEAR, RPT250	1
70	196-11400-4A	PACKIN, RPT250	1
71	196-11300-4A	PLATE, RPT250	1
72	028200039A	BLADE COVER, RPT250	1
73	224-14700-4A	CAP, RPT250	2
74	523-55047-00	BOLT, RBC251	1
75	625-15095-00	PIPE BRACKET 1, RBC251	1
75	625-15095-01	PIPE BRACKET (1), RBC251	1
76	625-15096-00	PIPE BRACKET 2, RBC251	1
77	525-60580-00	FUEL TANK CAP ASSEMBLY, RBL500	1
77	531-60140-00	FUEL TANK CAP, RBL500	1
78	523-75033-01	PLUG CAP, RST250	1
79	621-15042-04	CLUTCH CASE, RPT250	1
80	044-01299-70	OIL SEAL, RBC221	2
81	525-50130-00	CYLINDER COVER, RPT250	1
82	592-85004-00	CLUTCH BOLT, RPT250	2
83	592-85000-00	CLUTCH SHOE, EM4251	2
84	592-85001-00	SPRING, EM4251	1
85	625-25009-00	WASHER, RBC255	2
86	523-10110-01	CRANK CASE ASS'Y, RBC256	1
87	523-15022-02	CRANKCASE GASKET, RST250	1
88	523-20170-00	CRANKSHAFT CPL. RBC255	1
88	525-20070-00	CRANKSHAFT COMPLETE, RBC255	1
89	523-15018-04	CYLINDER, RBC251	1
90	521-65002-00	DAMPER, RBC230	2
91	625-15066-04	PIPE DAMPER 1, RPT250	1
92	625-15067-03	PIPE DAMPER 2, RPT250	1
93	621-20140-00	CLUTCH DRUM CPL., RPT250	1
94	523-70310-24	COIL, RBC256	1
95	525-70020-10	FLYWHEEL, RBC255	1
96	523-15023-04	CYLINDER GASKET, RBE250, RBC221	1
97	523-35039-02	INSULATOR GASKET, RST250	2
98	525-35006-02	MUFFLER GASKET, RPT250	1
99	523-75032-02	GROMMET, RST250	1
100	523-30140-00	INSULATOR COMP., RBC230	1
101	525-35010-01	INSULATOR, CARBURETOR, RPT250	1
102	601-95026-00	MODEL LABEL, RPT250	1
103	523-30370-03	EXHAUST MUFFLER, RST250	1
103	525-30260-01	EXHAUST MUFFLER, RST250	1
104	523-25026-00	PISTON PIN, RST250	1
105	523-25019-02	PISTON, RST250	1
106	503-65002-00	PLATE, RBC230	1
107	503-65003-00	PLATE RBC230	1
108	524-25007-01	PISTON RING, RBC260	1
109	525-35003-00	GASKET SPACER, RPT250	1
110	523-35066-00	SPARK ARRESTER, RBC256	1
110	525-30330-10	SPARK ARRESTER, RBC2510	1
111	525-50120-01	STARTER ASS'Y, RPT250	1
112	523-50250-01	PULLEY, RBC251	1
113	521-90020-00	STAND SET, RBC230	1
114	525-50010-40	DAMPER, EH450	1
115	521-50030-40	E-RING, RBL500	1
116	541-50110-10	RATCHET, RBL500	1
117	523-50240-12	REEL, RBC221	1
118	542-50030-10	SET SCREW, RBC221	1
119	523-50240-32	SPIRAL SPRING, RBC221	1
120	524-50070-20	RETURN SPRING	1



Parts Breakdown

RPT250

121	523-50240-22	STARTER ROPE, RBC221	1
122	522-50040-20	STARTER KNOB, RBC221	1
123	525-60670-00	STRAP, RBL500	1
123	625-50210-02	STRAP UNIT, RBC201	1
124	060-01298-50	BALL BEARING 6001C3 UR,RPT250	2
125	523-65039-00	FILTER, RBL500	1
126	525-65013-04	FUEL TANK, RPT250	1
127	616-55002-01	WIRE, RBC201	1
127	616-55012-00	WIRE, RST250	1
128	001-13061-60	BOLT ASS'Y, RBL500	1
129	003-12060-00	WASHER, G2400R	1
130	003-14320-00	INNER SNAP RING, RBC260	1
131	003-15120-00	OUTER SNAP RING, RBC260	1
132	011-90596-00	S.H. BOLT M5X45, RBE250	2
133	011-90596-40	S.H.BOLT M5X25,RPT250	2
134	020-00899-11	WASHER, EH450	2
135	011-90597-30	S.H. BOLT M5X20, RBC221	2
136	014-00595-20	SCREW M5X25, RBL250	3
137	056-10599-90	HOSE CLAMP, EM4251	1
138	011-90599-50	S.H. BOLT M5X18, RBC230	2
139	014-00499-20	SCREW M4X20, RST250	2
140	014-00594-50	SCREW M5X18, RBC255	4
141	014-00594-80	SCREW M5X14, BBX2500	3
142	014-00597-00	SCREW M5X20, RST250	3
143	056-50899-70	CLIP, BBX2500	2
144	060-01299-50	BALL BEARING 6201DD/6201 2RU,EM4250	1
145	061-00899-90	NEEDLE R. BEARING, RBC230	1
146	065-01497-21	SPARK PLUG, LT50 DOLMAR	1
147	065-40099-31	PLUG CAP SPRING,RBC221	1
148	625-95280-01	LABEL TRADE MARK, RPT250	1
149	073-92099-80	LABEL	1
150	085-10699-20	TUBE, RPT250	1
151	002-17050-00	NUT M5, EW110R	2
152	085-11999-71	TUBE, RPT250	1
153	525-60650-00	CARBURETOR,RPT250	1
154	523-60461-30	PUMP BODY ASSEMBLY, RBC230	1
155	523-60460-60	AIR PURGE BODY ASS'Y, RST200	1
156	523-60460-50	PRIMER PUMP COVER, EM4251	1
157	524-60011-50	PRIMER PUMP, BBX7600	1
158	531-60052-50	METERING DIAPHRAGM ASS'Y,RBC260	1
159	523-60460-40	METERING DIAPHRAGM GASKET,RBC260	1
160	524-60010-40	PUMP DIAPHRAGM, BBX7600	1
161	524-60010-30	PUMP GASKET, RBC230	1
162	525-60650-10	JET, RPT250	1
163	524-60010-10	O RING, RBC230	1
164	531-60051-20	RING, RBC230	1
165	523-60180-40	SWIVEL, RBC230	1
166	520-60080-30	P.H. SCREW, RBC221	2
167	523-60460-10	PUMP COVER SCREW, RBC230	4
168	501-60040-10	INLET SCREEN, RBC230	1
169	525-35026-00	AIR CLEANER CASE, RPT250	1
169	525-35026-00	AIR CLEANER CASE, RPT250	1
170	523-35047-00	AIR CLEANER ELEMENT, RST250	1
171	525-30210-00	CLEANER PLATE CPL., RPT250	1
172	014-00594-70	SCREW M5X62, BBX7600	2
173	523-35042-00	CARBURETOR GASKET, RST250	1
174	004-36051-40	SCREW M5X14, RBC251	1
175	073-63099-80	LABEL	1
176	501-35024-00	AIR CLEANER PLATE ASS'Y, RBC321	1
177	510-35028-00	SPACER GASKET, RBC230	1
177	510-35028-01	SPACER GASKET, RBC281	1
178	525-65019-00	CABLE BRACKET, RPT250	1
179	014-90699-81	ADJUST SCREW, RPT250	1
180	002-27060-00	NUT, G3510R	1
181	002-27050-00	NUT M5, RBC230	4
1,001	6207003002	BAND ASS'Y, EM4251	1
1,002	6029015000	N/A	1



Parts Breakdown

RPT250

1,002	6029015001	N/A	1
1,003	5109006000	TOOL KIT, RPT250	1
1,003	5109017000	N/A	1
1,004	0713199900	BOX WRENCH, RPT250	1
1,005	0717059990	HEX. WRENCH, RBC256	1
1,006	0717049990	HEX. WRENCH, RBC2510	1