







Item No.	Type	Sub	Part No.	Description	Qty	Unit
1	1		6164500700	GRIP	1	PC.
	2		273673-4	GRIP	1	PC.
2	1		6165028001	* CONTROL LEVER ASSY	1	PC.
		INC.		* Item No. 3, 5-12		
	2		126043-5	* CONTROL LEVER ASSY	1	PC.
		INC.		* Item No. 3, 5-12		
	3		126569-7	* CONTROL LEVER ASSY	1	PC.
		INC.		* Item No. 3, 5-10, 12		
3	1		6195018111	WIRE SET	1	PC.
		INC.		Item No. 4		
	2		126051-6	WIRE ASSEMBLY	1	PC.
		INC.		Item No. 4		
4	1		6195018121	CONTROL CABLE	1	PC.
	2		168688-3	CONTROL CABLE	1	PC.
5	1		6195018050	TUBE	1	PC.
	2		412104-0	TUBE	1	PC.
6	1		0043505300	SCREW ASSEMBLY M5X30 W/SW	3	PC.
	2		266708-8	PAN HEAD SCREW M5X30 W/SW	3	PC.
7	1		6195018060	LEVER SWITCH	1	PC.
	2		452993-1	SWITCH LEVER	1	PC.
8	1		6195018130	SWITCH PLATE	1	PC.
	2		346512-2	SWITCH PLATE	1	PC.
9	1		6195018030	LEVER	1	PC.
	2		452994-9	LEVER	1	PC.
10	1		6195018040	SPRING	1	PC.
	2		233592-6	SPRING	1	PC.
11	1		6165028030	* TAPPING SCREW M5X12	1	PC.
	2		266722-4	* TAPPING SCREW M5X12	1	PC.
12	1		002-18050-00	NUT M5	3	PC.
	2		264035-7	HEX. NUT M5	3	PC.
14	1		0043505300	SCREW ASSEMBLY M5X30 W/SW	3	PC.
	2		266708-8	PAN HEAD SCREW M5X30 W/ SW	3	PC.
15			0021805003	NUT M5	3	PC.
16	2		6169512800	CAUTION LABEL	1	PC.
	3		893204-9	CAUTION LABEL	1	PC.
17	1		6161019000	* FLEXIBLE PIPE UNIT	1	PC.
		INC.	6161026000	* PIPE ASSEMBLY	1	PC.
		INC.		* Item No. 18		
	2		6161027000	* FLEXIBLE PIPE UNIT	1	PC.
		INC.	6161026000	* PIPE ASSEMBLY	1	PC.
		INC.		* Item No. 18		
	3		126040-1	* FLEXIBLE PIPE ASSEMBLY	1	
		INC.	6161026000	* PIPE ASSEMBLY	1	PC.
		INC.		* Item No. 18		
18	1		6161501300	FLEXIBLE SHAFT	1	PC.
	2		6161027020	FLEXIBLE SHAFT	1	PC.
19	1		6163004000	GEAR CASE ASSY	1	PC.
		INC.		Item No. 20-27		
	2		6163005000	GEAR CASE ASSY	1	PC.
		INC.		Item No. 20-27		
	3		126041-9	GEAR CASE ASSEMBLY	1	PC.
		INC.		Item No. 20-27		
20	1		6163500800	CUTTER SHAFT	1	PC.
	2		6163003020	CUTTER SHAFT	1	PC.
21	1		6163500600	BEARING BALL #608ZZ	2	PC.
	2		6163002031	BALL BEARING 608LLU	2	PC.
22	1		6163500700	SPACER	1	PC.
	2		6163003041	SPACER	1	PC.
23			0017005100	CROSS RECESS HEAD BOLT	1	PC.
24	1		6163500900	WASHER	1	PC.
	2		6163002051	WASHER	1	PC.
25	1		6163501000	WASHER SPRING	1	PC.
	2		6163002061	SPRING WASHER	1	PC.
26	1		6163501101	* RECEIVE WASHER	1	PC.
	2		6168500800	* RECEIVE WASHER	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
27			6163002121	BOLT ASSY	1	PC.
30	1		6161501500	SPACER	1	PC.
	2		331959-3	SPACER	1	PC.
31	1		5103502801	SPACER GASKET	1	PC.
	2		442177-9	AIR CLEANER GASKET	1	PC.
32	1		0140059500	SCREW M5X25	2	PC.
	2		266700-4	PAN HEAD SCREW M5X25	2	PC.
33	1		5233014000	INSULATOR COMPLETE	1	PC.
	2		141056-5	INSULATOR COMPLETE	1	PC.
34	1		6165500201	WIRE	1	PC.
	2		638784-6	WIRE	1	PC.
35	1		5193500501	INSULATOR GASKET	1	PC.
	2		442175-3	INSULATOR GASKET	1	PC.
36	1		0119059730	SOCKET HEAD BOLT M5X20	2	PC.
	2		266814-9	HEX SOCKET HEAD BOLT M5X20	2	PC.
	3		922233-6	HEX SOCKET HEAD BOLT M5X20	2	PC.
37	1		5197500100	PLUG CAP COVER	1	PC.
	2		424445-2	PLUG CAP COVER	1	PC.
39	1		5191500901	CYLINDER	1	PC.
	2		318785-7	CYLINDER	1	PC.
40	1		5195503000	COVERCYLINDER HD	1	PC.
	2		452973-7	CYLINDER COVER	1	PC.
41	1		6279505700	MAKITA LOGO LABEL	1	PC.
	2		801B04-5	MAKITA LOGO LABEL	1	PC.
42	1		0150059790	TAPPING SCREW 5X14	1	PC.
	2		266702-0	TAPPING SCREW 5X14	1	PC.
43	1		0655009870	PLUG CAP	1	PC.
	2		424337-5	PLUG CAP	1	PC.
44	1		0654009931	PLUG CAP SPRING	1	PC.
	2		324891-8	PLUG CAP SPRING	1	PC.
45	1		0851089950	TUBE	1	PC.
	2		444021-6	TUBE	1	PC.
46	1		5197018000	WIRE COMPL	1	PC.
	2		141049-2	WIRE COMPLETE	1	PC.
47	1		0140049770	SCREW ASSY M4X16(WSW)	2	PC.
	2		911128-8	PAN HEAD SCREW M4X16	2	PC.
48	1		5197011010	IGNITION COIL	1	PC.
	2		168683-3	IGNITION COIL	1	PC.
49	1		0119059520	SOCKET HEAD BOLT M5X40	2	PC.
	2		266440-4	HEX SOCKET HEAD BOLT M5X40	2	PC.
50	1		5193001002	EXHAUST MUFFLER	1	PC.
	2	INC.		Item No. 51		
			168679-4	EXHAUST MUFFLER	1	PC.
		INC.		Item No. 51		
51			5193001050	SPARK ARRESTER	1	PC.
52	1		5193500002	INSULATOR MUFFLER	1	PC.
	2		168680-9	MUFFLER GASKET	1	PC.
53	1		5191500301	CYLINDER GASKET	1	PC.
	2		442173-7	CYLINDER GASKET	1	PC.
54	1		5212500500	PISTON RING	1	PC.
	2		257320-5	PISTON RING	1	PC.
55	1		0565089970	CLIP	1	PC.
	2		233976-8	CLIP	1	PC.
56	1		5192501701	PISTON	1	PC.
	2		318831-6	PISTON	1	PC.
57	1		5192500500	PISTON PIN	1	PC.
	2		268277-5	PISTON PIN	1	PC.
58	1		0565089970	CLIP	1	PC.
	2		233976-8	CLIP	1	PC.
59	1		5192001003	CRANKSHAFT COMPLETE	1	PC.
	2		141047-6	CRANK SHFT COMPLETE	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
60	1		0140049770	SCREW ASSY M4X16(WSW)	3	PC.
	2		911128-8	PAN HEAD SCREW M4X16	3	PC.
61	1		5195009000	REWIND STARTER	1	PC.
		INC.		Item No. 62-69		
	2		126037-0	RECOIL STARTER ASSEMBLY	1	PC.
		INC.		Item No. 62-69		
62	1		5195500000	PULLEY	1	PC.
	2		168483-1	PULLEY	1	PC.
63	1		5195002060	SET SCREW	1	PC.
	2		266585-8	TAPPING SCREW 5X12	1	PC.
64	1		5195002100	SWING ARM	1	PC.
	2		325923-4	SWING ARM	1	PC.
65	1		5195002110	COLLAR	1	PC.
	2		451938-6	COLLAR	1	PC.
66	1		5195002030	REEL	1	PC.
	2		452972-9	REEL	1	PC.
67	1		5195002050	SPIRAL SPRING	1	PC.
	2		234220-6	SPIRAL SPRING	1	PC.
68	1		5225004020	HANDLE	1	PC.
	2		424319-7	STARTER KNOB	1	PC.
70	1		6169511400	MODEL LABEL	1	PC.
	2		893199-6	MODEL NO. LABEL	1	PC.
71			5191004001	CRANK CASE ASS'Y	1	PC.
		INC.		Item No. 72-75		
72	1		0440109980	OIL SEAL	2	PC.
	2		213638-4	OIL SEAL	2	PC.
73	1		5191500400	CRANKCASE GASKET	1	PC.
	2		442174-5	CRANK CASE GASKET	1	PC.
74	1		0600109980	BALL BEARING 6000	2	PC.
	2		210086-8	BALL BEARING 6000	2	PC.
	3		211064-1	BALL BEARING 6000	2	PC.
75	1		0140059520	SCREW M5X25	3	PC.
	2		266701-2	PAN HEAD SCREW M5X25	3	PC.
76	1		5197017010	FLYWHEEL	1	PC.
	2		318791-2	FLY WHEEL	1	PC.
77	1		6192006000	CLUTCH	1	PC.
	2		126049-3	CLUTCH ASSEMBLY	1	PC.
78	1		6162011000	CLUTCH DRUM COMPLETE	1	PC.
	2		141050-7	CLUTCH DRUM COMPLETE	1	PC.
79	1		6191006001	CLUTCH CASE COMPLETE	1	PC.
	2		141058-1	CLUTCH CASE COMPLETE	1	PC.
80	1		0031510000	OUTER SNAP RING 10	1	PC.
	2		961006-2	RETAINING RING S-10	1	PC.
81	1		0119059880	SOCKET HEAD BOLT M5X25	1	PC.
	2		266712-7	HEX SOCKET HEAD BOLT M5X25	1	PC.
82	1		6191500203	PIPE DAMPER	1	PC.
	2		424461-4	PIPE DAMPER	1	PC.
83	1		6191501300	PIPE BRACKET	1	PC.
	2		318792-0	PIPE BRACKET	1	PC.
84	1		0566059980	CLAMP	1	PC.
	2		345963-6	CLAMP	1	PC.
85	1		0150059780	TAPPING SCREW M5X20	3	PC.
	2		266713-5	TAPPING SCREW 5X20	3	PC.
86	1		0119059850	SOCKET HEAD BOLT M5X14	1	PC.
	2		266711-9	HEX SOCKET HEAD BOLT M5X14	1	PC.
87	1		5256059000	FUEL TANK CAP COMPLETE	1	PC.
		INC.		Item No. 88,89		
	2		168668-9	FUEL TANK CAP COMPLETE	1	PC.
		INC.		Item No. 88,89		
88	1		5256058000	FUEL TANK CAP	1	PC.
	2		452920-8	FUEL TANK CAP	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
89	1		5256067000	STRAP	1	PC.
	2		140436-2	STRAP COMPLETE	1	PC.
90	1		5196500003	FUEL TANK	1	PC.
	2		452989-2	FUEL TANK	1	PC.
91	1		0851159850	TUBE	1	PC.
	2		162329-3	TUBE	1	PC.
92	1		0561059990	HOSE CLAMP	1	PC.
	2		345920-4	HOSE CLAMP	1	PC.
93	1		5236503900	FILTER	1	PC.
	2		163447-0	GASOLINE FILTER	1	PC.
94	1		5036500200	PLATE	1	PC.
	2		424102-2	PLATE	1	PC.
95	1		5036500300	PLATE	1	PC.
	2		424103-0	PLATE	1	PC.
96	1		5193500101	PLATE	1	PC.
	2		452988-4	MUFFLER PLATE	1	PC.
97	1		5216500200	DAMPER	2	PC.
	2		424446-0	DAMPER	2	PC.
98	1		5196036000	CARBURETOR	1	PC.
		INC.		Item No. 99-126		
98	2		168681-7	CARBURETOR	1	PC.
		INC.		Item No. 99-126		
99	1		5196019240	ADJUST SCREW	1	PC.
	2		266717-7	ADJUST SCREW	1	PC.
100	1		5196019310	SCREW	2	PC.
	2		266719-3	TAPPING SCREW M3X7	2	PC.
101	1		5196019450	LEVER END	1	PC.
	2		326099-0	END LEVER	1	PC.
102	1		5196019460	WASHER	1	PC.
	2		267837-0	WASHER	1	PC.
103	1		5196036010	STARTER LEVER	1	PC.
	2		452976-1	STARTER LEVER	1	PC.
104	1		5196036020	STARTER SPRING	1	PC.
	2		234221-4	STARTER SPRING	1	PC.
105	1		5196019250	SLOW STOP SCREW	1	PC.
	2		266718-5	TAPPING SCREW M3X16	1	PC.
106	1		5196019510	E-RING	1	PC.
	2		259051-2	E-RING 4.5	1	PC.
107	1		5196019220	O-RING	1	PC.
	2		213630-0	O-RING 18	1	PC.
108	1		5196019150	O-RING	1	PC.
	2		213629-5	O-RING 2	1	PC.
109	1		5196032010	MAIN JET	1	PC.
	2		326100-1	MAIN JET	1	PC.
110	1		5196019410	O-RING	1	PC.
	2		213631-8	O-RING 4	1	PC.
111	1		5196019360	CHECK VALVE ASSY	1	PC.
	2		126052-4	CHECK VALVE ASSEMBLY	1	PC.
112	1		5196019420	GUIDE PLATE	1	PC.
	2		346509-1	GUIDE PLATE	1	PC.
113	1		5196019430	SCREW	1	PC.
	2		266721-6	TAPPING SCREW M2.6X6	1	PC.
114	1		5196019040	DIAPHRAGM ASSY	1	PC.
	2		126038-8	DIAPHRAGM ASSEMBLY	1	PC.
115	1		5196019050	DIAPHRAGM COVER	1	PC.
	2		346513-0	DIAPHRAGM COVER	1	PC.
116	1		5196019060	SCREW	2	PC.
	2		266715-1	TAPPING SCREW M3X8	2	PC.
117	1		5196019110	PUMP PACKING	1	PC.
	2		442176-1	PUMP PACKING	1	PC.
118	1		5196019120	PUMP DIAPHRAGM	1	PC.
	2		424460-6	PUMP DIAPHRAGM	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
119	1		5196019350	PUMP PLATE	1	PC.
	2		346508-3	PUMP PLATE	1	PC.
120	1		5196019330	FILTER	1	PC.
	2		352018-0	FILTER	1	PC.
121	1		5196019130	PUMP PACKING	1	PC.
	2		442178-7	PUMP PACKING	1	PC.
122	1		5196019340	PUMP COVER	1	PC.
	2		452975-3	PUMP COVER	1	PC.
123	1		5246009030	COMBINATION VALVE	1	PC.
	2		452977-9	COMBINATION VALVE	1	PC.
124	1		5246009040	PRIMING PUMP	1	PC.
	3		424462-2	PRIMING PUMP	1	PC.
125	1		5196019320	PRIMING PUMP PLATE	1	PC.
	3		346507-5	PRIMING PUMP PLATE	1	PC.
126	1		5196019140	SCREW	4	PC.
	2		266716-9	TAPPING SCREW M3X18	4	PC.
127	1		5193017040	O-RING	1	PC.
	2		213632-6	O-RING 14.8	1	PC.
128	1		5193018010	PLATEAIR CLEANER ASSY	1	PC.
	2		126036-2	AIR CLEANER PLATE ASSEMBLY	1	PC.
129	1		0043105600	PAN HEAD SCREW M5X60	2	PC.
	2		266695-1	PAN HEAD SCREW M5X60	2	PC.
130	1		5193017030	ELEMENTAIR CLEANER	1	PC.
	2		443168-3	AIR CLEANER PLATE ELEMENT	1	PC.
131	1		5193018020	CASEAIR CLEANER	1	PC.
	2		452971-1	AIR CLEANER CASE	1	PC.
132	1		0140059480	SCREW ASS'Y M5X14	1	PC.
	2		266809-2	P.H.SCREW M5X14 WITH WR	1	PC.
	3		911218-7	PAN HEAD SCREW M5X14	1	PC.
133	1		6259514700	CAUTION LABEL	1	PC.
	2		808723-2	CAUTION LABEL	1	PC.

#### **ACCESSORIES**

- See Catalogue or visit [www.makita.ca](http://www.makita.ca) for more accessories -

A01			6169030000	TOOL KIT(INCL. HEX WRENCH)	1	SET
A02			0717049990	HEX WRENCH	1	PC.
A03	2		6168020000	BUMP&FEED (NYLON) CUTTING HEAD (RH) (See Parts breakdown 6168020000)	1	PC.
		INC.	A-89246	HOUSING RH (BLACK)	1	PC.
		INC.	B-03090	NUT M8 (R.H) FOR BF4L	1	PC.
		INC.	A-15992	EYELET FOR U.AUTO & BF4L, 2PC/SET	1	SET
		INC.	B-03056	TAP SPRING FOR BF4L	1	PC.
		INC.	A-89252	COVER (BLACK)	1	PC.
		INC.	B-03137	SPOOL(W/O NYLON CORD)FOR BF4L	1	PC.
		INC.	A-89193	NYLON LINE,DIA 2.4MX3M	1	PC.
A04	1		6164010000	HANDLE ASSY	1	PC.
		INC.		Item No. 14,15		
	2		126042-7	HANDLE ASSEMBLY	1	PC.
		INC.		Item No. 14,15		
A05	1		6168016001	PROTECTOR ASSY	1	PC.
				* (Components of each parts are not available as indivisual sales)		
	2		6168016002	PROTECTOR ASSY	1	PC.
				* (Components of each parts are not available as indivisual sales)		
				PROTECTOR ASSY		
				* (Components of each parts are not available as indivisual sales)		
	3		126045-1		1	PC.
A06			965 603 014	SPARK PLUG (BPMR7A)	1	PC.
A07	1		5255016020	STARTER ROPE	1	PC.
	2		444024-0	STARTER ROPE	1	PC.
A08			B-60121	ULTRA AUTO 4X(RH) ASSY(RH) (See Parts breakdown "Trimmer Head")	1	PC.
A09			A-90124	BUMP & FEED HEAD ASSY (RH) (See Parts breakdown "Trimmer Head")	1	PC.
A10			B-02951	TRIMMEDR HEAD, MANUAL (Component parts are not available)	1	PC.