

IPL, Rotary Broom, 2006-01, 106 39 65-61

T-20430, 953 53 78-01

Rotary Broom

Spare parts


Ersatzteile



Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar







953 53 78-01 Street Brush KOVA LH1200, Pro Flex

| Pos | Part number | Part name | Qty | Pos | Part number | Part name | Qty |
|-----|--------------|---------------------|-----|-----|--------------|-------------------|-----|
| 1 | 535 46 66-03 | Guard, Brush Roller | 1 | 53 | 531 02 12-09 | Pin, Spring | 1 |
| 2 | 535 41 48-35 | Rubber | 2 | 54 | 535 46 66-41 | Angle Control Rod | 1 |
| 3 | 535 41 48-36 | Support, Rubber | 2 | 55 | 535 46 66-42 | Rod, Lock | 1 |
| 4 | 535 46 66-01 | Dust Cap | 2 | 56 | 535 46 66-43 | Spring | 1 |
| 5 | 535 41 50-98 | Tube | 2 | 57 | 535 46 66-44 | Pin | 1 |
| 6 | 535 41 48-11 | Chain Tightener | 1 | 58 | 531 02 12-26 | Nut | 8 |
| 7 | 535 41 48-10 | Shaft | 1 | 59 | 535 46 66-45 | Rod | 1 |
| 8 | 535 41 48-37 | Chain Tightener | 1 | 60 | 535 46 66-46 | Support | 1 |
| 9 | 531 00 10-46 | Bearing | 1 | 61 | 535 46 66-47 | Tarpaulin | 1 |
| 10 | 535 41 48-43 | Slide Ring | 1 | 62 | 531 00 50-15 | V-Belt | 1 |
| 11 | 535 46 66-11 | Plate, upper | 1 | 63 | 506 98 26-01 | Screw, special | 8 |
| 12 | 535 41 50-99 | Support Wheel | 2 | 64 | 506 55 97-01 | Washer | 8 |
| 13 | 535 41 48-14 | Plate, side | 2 | 65 | 535 43 74-01 | Decal | 1 |
| 14 | 535 41 48-40 | Plate, lower | 1 | 66 | 535 41 50-45 | Screw | 24 |
| 15 | 535 46 66-02 | Locking knob | 2 | 67 | 531 02 12-19 | Nut, Lock | 22 |
| 16 | 535 46 66-14 | Locking knob | 1 | 68 | 535 46 66-49 | Screw | 4 |
| 17 | 535 41 48-09 | Mounting Plate | 1 | 69 | 531 02 12-25 | Screw | 4 |
| 18 | 535 46 66-16 | Pulley A112 | 1 | 70 | 535 46 66-57 | Washer | 1 |
| 19 | 531 00 52-78 | Key | 2 | 71 | 535 46 66-58 | Screw | 4 |
| 20 | 535 41 48-02 | Worm Gear, 7:1 | 1 | 72 | 531 02 11-84 | Washer | 13 |
| 21 | 535 41 48-48 | Washer | 2 | 73 | 531 00 51-98 | Circlip | 1 |
| 22 | 531 02 11-37 | Washer | 4 | 74 | 535 41 50-92 | Washer | 1 |
| 23 | 535 41 48-28 | Chain Wheel | 1 | 75 | 531 02 12-59 | Screw | 1 |
| 24 | 535 46 66-20 | Shaft | 1 | 76 | 535 41 50-36 | Screw | 3 |
| 25 | 535 46 66-21 | Frame | 1 | 77 | 535 41 50-11 | Washer | 2 |
| 26 | 531 02 11-73 | Screw | 4 | 78 | 531 02 11-30 | Nut, Lock | 4 |
| 27 | 535 46 66-22 | Pin | 1 | 79 | 535 46 66-53 | Pin, Split | 2 |
| 28 | 535 46 66-23 | Belt Guard | 1 | 80 | 535 46 66-54 | Pop Rivet | 9 |
| 29 | 535 46 66-24 | Mounting Frame | 1 | 81 | 535 46 66-55 | Washer | 2 |
| 30 | 506 77 91-01 | Spring | 1 | 82 | 531 00 52-17 | Pin Set | 2 |
| 31 | 506 91 87-01 | Washer | 1 | 83 | 531 02 11-98 | Nut, Lock | 2 |
| 32 | 506 92 89-01 | Tight Pulley | 1 | 84 | 535 46 66-06 | Slide Ring | 1 |
| 33 | 531 02 11-38 | Bearing | 1 | 85 | 535 41 50-40 | Screw | 4 |
| 34 | 535 41 48-08 | Flange | 2 | | | | |
| 35 | 535 41 48-06 | Roller Shaft | 2 | | | | |
| 36 | 535 41 48-07 | Flange | 2 | | | | |
| 37 | 506 51 95-02 | Mounting Plate | 1 | | | | |
| 38 | 535 41 48-05 | Roller Shaft | 1 | | | | |
| 39 | 535 41 50-41 | Screw | 1 | | | | |
| 40 | 535 41 48-26 | Chain | 1 | | | | |
| 41 | 535 41 48-27 | Chain Shackle | 1 | | | | |
| 42 | 535 41 48-34 | Collar, Plastic | 4 | | | | |
| 43 | 535 41 48-52 | Spring | 4 | | | | |
| 44 | 535 41 48-61 | Brush Ring Kit | 0 | | | | |
| 45 | 535 41 48-01 | Bearing | 2 | | | | |
| 46 | 535 46 66-35 | Screw | 1 | | | | |
| 47 | 535 41 48-04 | Collar, Plastic | 24 | | | | |
| 48 | 535 41 48-13 | Mounting Plate | 2 | | | | |
| 49 | 535 41 48-03 | Brush Ring | 31 | | | | |
| 50 | 535 41 50-94 | Washer | 1 | | | | |
| 51 | 535 41 48-15 | Protection, plastic | 2 | | | | |
| 52 | 535 41 48-12 | Screw | 2 | | | | |