Tanaka.

Parts Catalog

Brush Cutter

Model: TBC-4000

DPL-T4000-HST 04-29-96

TBC-4000

OPTIONS AND ACCESSORIES

NYLON LINE



746156 .095, Box, 50 ft.
746157 .105, Box, 50 ft.
746160 .095, 1/2 lb. Box, 143 ft.
746161 .105, 1/2 lb. Box, 110 ft
746165 .095, 1 lb. Box, 285 ft.
746166 .105, 1 lb. Box, 235 ft.
746169 .095, 3 lb. spool, 855 ft.
746170 .105, 3 lb. spool, 705 ft.
746173 .095, 5 lb. spool, 1425 ft.
746174 .105, 5 lb. spool, 1175 ft.

SEMI-AUTO HEAD



4633000 PNH-170

Parts	L	.ist
--------------	---	------

SN-341	Body
SN-348	Cap
UA-1006	Adapter
SN-349	Spool
SE-103	Eyelet
SN-354	Spring
SN-347	Bump Disk

PERFECT MIX® 2-Cycle Engine Oil



MANUALS / CATALOGS

046014E Owner's Manual
DPL-T4000-HST Parts Catalog
WSM-TBC Service Manual

700109 2.8 oz. Bottle, 1 Gallon Size (24*) 700108 16 oz. Self-measuring Bottle (24*) 700110 1 Gallon Jug Commercial Size (6*) * Case Quantity

SPECIAL TOOLS

 009-29323-500
 Piston Pin Remover
 070-2000W-501
 Carb. Tool Kit

 073-29374-180
 Fan Case Remover
 001-29000-000
 Tachometer

 037-29476-522
 Clutch Remover
 070-2000W-500
 Pressure Tester








FIG.1 ENGINE



2 3 4 5 6 7 8 9					5		•
2 3 4 5 6 7 8 9	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO	REMARKS
3 4 5 6 7 8 9	157-01570-900	CAP,SPARK PLUG,ASS'Y	1		С		
4 5 6 7 8 9	018-11660-21	PLUG,SPARK	1		В		
5 6 7 8 9	002-00025-20	CYLINDER	1		В		
6 7 8 9 10	990-11050-221	SCREW,5X22	2		В		
7 8 9 10	992-10050-012	WASHER,S,5	2		A		
8 9 10	017-00025-200	GASKET,CYLINDER	1		Α		
8 9 10							
9 10		RING,PISTON,LOWER	1	ĺ	A,		
10	031-00025-20	PISTON	1		D		
1 1	039-06100-200	CIRCLIP,PISTON PIN	2		Α		
1 12	037-06097-20	PIN,PISTON	1	l	В		
'-	046-00025-80	CRANKSHAFT	1		D		
13	061-00025-800	ROD,CONNECTING	1		C		
	077-00025-21	CRANKCASE	1		D		
		GASKET,CRANKCASE	1		В		
	999-66152-511	SEAL,OIL,#VE15X25X7	1		Α		
1 [999-61600-200	BEARING,BALL,#6002	1		В		
		COIL,IGNITION	1		C		
28	992-00040-011	WASHER,4	2		В		
29	992-10040-012	WACHED C 4			٦		
		WASHER,S,4	2		В		
1		SCREW,4X20	2		C		
		ROTOR,MAGNETO ASS'Y			C		
		SPRING,PAWL			D		
i 1		PAWL,STARTER			D		
"	992-01120-011	WASHER,12	1		D		
38	991-11120-011	NUT,12	1		Α		
1 1		WASHER,5	2		A		
		COVER, CRANK CASE	1		i I	~N207750	
		WASHER,S,5	3			~N207750	
l f	990-11050-161	SCREW,5X16	3			~N207750	
						.1207700	

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

FIG.2 ENGINE COMPONENTS



		1 BC-4000 1		~	J	LIGITIA	
REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
3-2	752-00025-200	PROTECTOR, MUFFLER B	1		D	~K190595	
3-1	752-00025-210	PROTECTOR, MUFFLER B	1		D	~N207750	
3	752-00025-22	PROTECTOR,MUFFLER	1		С	N207751~	•
7	994-16050-162	SCREW,5X16/WS	4		D	~N207750	
7	990-11050-161	SCREW,5X16	3		В	N207751~	
11	112-00025-80	CASE,FAN	1		В		
		BEARING,BALL,#6000ZZ	1		В		
	277-0635M-800	1	1		В		
15		SPRING,RECOIL	1		С		
16	1	PULLEY,STARTER	1		С		
		STAY,PULLEY	2		D		
18	839-00025-200	SCREW,SET	2		D		
40	000 40050 040	l <u>-</u>					
	992-10050-012		3			N207751~	
		WASHER,5	3			N207751~	
21		ROPE,STARTER			С		
	1	HANDLE,STARTER	1		C		
		CORD,STOP	ן י		D		
25	994-15050-202	SCREW,5X20/PS	3		С		
26	992-00040-011	WASHER,4	2		В		
		O-RING,S-48	1			N207551~	
		ARRESTER, SPARK			D	11207331~	
		GASKET,MUFFLER	'		c		
	717-00025-801	BODY,MUFFLER B			ď		
	992-00050-011	WASHER,SMALL,5	2		c		
		,					
36	990-51050-103	BOLT,HEX.HOLE,5X10	2		c		
37	990-51040-083	BOLT,HEX.HOLE 4X8	2		D		
40	403-0631A-202	GASKET,INLET MANIFOLD	1		A		
41	404-0631A-800	INSULATOR, CARBURETOR	1		В		
42	402-0602K-21	GASKET,CARBURETOR	1		В		
45	992-00050-011	WASHER,SMALL,5	2				
	992-10050-012	WASHER,S,5	2		Α		
47	990-11050-221	SCREW,5X22	2		В		
49	999-67015-000	O-RING,P15	1		익		
	992-00050-011	WASHER,SMALL,5	2				
1 3	992-10050-012	WASHER,S,5	2		A		
55	990-11050-601	SCREW,5X60	2				
59	700-13005-130	PIPE,FUEL			С		
60	680-00731-201	CLIP	╏╏		В		
				-	7		

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

FIGURE 2 cont.

REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO.	REMARKS				
61	675-04042-80	FILTER,FUEL	1		Ā						
62	591-00025-200	TANK,FUEL	1		D	~K190595					
62	591-00025-21	TANK,FUEL	1		С	K190596~					
63	595-0650A-90	CAP,TANK	1		Α						
64	659-00801-200	COLLAR, TANK HOLDING METAL	2		C		İ				
65	992-01050-011	WASHER,5	2		Α	~L277320					
66	992-10050-012	WASHER,S,5	2		Α	~L277320					
67	990-11050-181	SCREW,5X18	2		В	~L277320					
67	994-15050-185	SCREW,5X18	2		D	~M253724					
67	994-63050-185	BOLT,HEX 5X18PS	2		D	M253725~					
73	700-15007-01	PIPE,RUBBER	1		С						
75	655-06400-200	CUSHION,TANK	2		D						

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

FIG.3 AIR CLEANER





FIGURE 3

TBC-4000 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS
0	410-00025-900	CLEANER, AIR ASS'Y	1		C		
1	424-00025-200	CAP,AIR CLEANER	1		c		
2	446-00025-200	ELEMENT, CLEANER	1		В		
3	470-00025-200	COLLAR	2		D		
4	423-00025-800	BODY,CLEANER,AIR	1		c		
		<u>[</u>					

FIG.4 CARBURETOR



REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO.	REMARKS
0	455-25140-900	CARBURETOR,ASS'Y	1		C		
1	548-25140-200	SCREW,THROTTLE SET	1		D		
5	539-25120-200	SWIVEL	1		D		
7	489-25100-200	RING,STOP	1		D		
8	488-25140-800	VALVE,THROTTLE	1		C		
10	~~~	*O-RING	1		С		
11	599-2000W-370	l ' '	1		C		* Contained in Carb. Repair Kit
13	~~~	*GASKET,PUMP	1		В		650-25140-900
14	~~~	*DIAPHRAGM,PUMP	1		В		(Not availiable individually)
15	523-25100-201	PLATE,PUMP	1		С		
16	522-25100-200	PLATE,CIRCUIT	1		С		
17	~~~	*SCREEN,INLET	1		С		
18	575-25140-800	BODY,PUMP	1		D,		
19	~~~	*GASKET,DIAPHRAGM	1		Α		
20	~~~	*DIAPHRAGM,METERING	1		Α		
21	476-25004-200	COVER,DIAPHRAGM	1		D		
22	548-25101-200	SCREW,SET	1		D		

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

FIG.5 CLUTCH CASE





FIGURE 5

TBC-4000 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS
1	289-00025-80	DRUM,CLUTCH	1		Ċ		
2	999-61620-101	BEARING,BALL #6201ZZ	1	l	C		
4	331-00025-21	CASE,CLUTCH	1		С		
5	990-73050-184	SCREW,TAPPING,5X18	4		D		
6	599-0635A-200	CUSHION	1		D		
8	990-51050-253	BOLT,HEX,5X25	1	li	В		
	}						
9	992-10050-062	WASHER,S,5	1		D		
10	249-0630G-201	SPACER	1		D		
11	380-0635D-200	BOLT,SPECIAL	1		С		

FIG.6 HANDLE




REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO.	REMARKS
1	343-37718-00	PIPE,DRIVE SHAFT SET	1		A		Contains pipe, liner, shaft & gearcase
2	299-37710-00	SET,GEAR CASE	1		c	~L247577	as per PI-3036
2	300-37710-90	CASE,GEAR,ASS'Y	1			L247578~	, ,,
3	341-37715-20	PIPE,DRIVE SHAFT	1		С		
4	350-37651-210	LINER,FLEXIBLE	1		В	•	
5	344-37651-21	SHAFT,FLEX	1		Α		
		·					
6	304-37651-21	SHAFT,CUTTER	1		C		
7	999-61608-004	BEARING,BALL,608DD	2		c		
8	348-37651-20	COLLAR	1		D		
9	990-11050-101	SCREW,5X10	1		в	~L24 7 577	
9	990-11050-081	SCREW,5X8	1		c	L247578~	
10-1	300-37651-200	CASE,GEAR	1			~L247577	
10	300-37710-20	CASE,GEAR	1		D	L247578~	
11	994-25050-301	BOLT,PS,5X30	1		Ы		
1		WASHER, SPECIAL	1		ı	~L247577	
12	315-37710-200	NUT,SPECIAL	1		- 1	L247578~	
13	992-10080-012	WASHER,S,8	1		- 1	~L247577	
14-1	310-37651-200	HOLDER, CUTTER	1		- 1	~L247577	
		·					
14	310-37710-20	HOLDER,CUTTER	1		в	L247578~	
16	885-00025-800	WIRE,THROTTLE	1		cl		
20	441-37701-810	COVER, SAFETY	1		c		
21		BRACKET,SAFETY GUARD	2		c		
22		WASHER,S,6	2		A		
23	990-23060-161	BOLT,6X16 PLUS	2	İ	cl		
		·					
26	500-37704-20	HANDLE	1		c		
27	991-01060-011	NUT,6	2		A		
28	506-37704-200	BRACKET,HANDLE A	2				
		WASHER,6	2		A		
31	990-23060-401	BOLT,P,6X40	2		D		
50	504-37400-200	GRIP,SHAFT	1		D		
51	178-37300-801	CORD,STOP	2		c		
52	164-10014-010	TUBE,PROTECTION	1				
55	870-37400-900	LEVER,THROTTLE ASS'Y	1		c		
56	162-37101-200	SWITCH,STOP	1		С		
57	993-42030-081	SCREW, TAPPING, 3X8	3		D		
58	259-37101 <i>-</i> 200	BASE,STOP SWITCH	1		c		
59	262-37101-200	SPRING,STOP SWITCH	1				
60	177-37101-200	TERMINAL,EARTH B	1		c		

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS				
61	176-37101-200	TERMINAL, EARTH A	1		D						
62	991-86050-000	NUT,LOCK,5	1		D						
63	993-55060-001	RING,STOP,6	1		D						
64	832-37101-200	SPRING,RETURN	1		C						
65	880-37101-200	LEVER,THROTTLE	1		В						
66	994-31050-251	SCREW,S.,5X25	1		C						
			i								
67	853-37101-200	SHAFT,LOCK BUTTON	1		D						
68	958-37101-200	SPRING,LOCK,BUTTON	1		D						
69	956-37101-200	BUTTON,LOCK	1		D						
73	320-37651-200	SPACER	1		D						
85	306-37651-201	PROTECTOR, WINDING, C	1		D	~L247577					
86	308-37651-201	PROTECTOR, WINDING, B	1		D	~L247577					
87	992-10050-012	WASHER,S,5	2		Α	~L247577					
88	990-11050-201	SCREW,MX20	2		D	~L247577					
89	307-37651-200	PROTECTOR, WINDING	[1]		D	~K075476					
89	307-37301-201	PROTECTOR, WINDING	1		D	K075477~					

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

FIG.7 TOOLS & NYLON HEAD



REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO	REMARKS
0	783-33071-91	HEAD,BRAIN,R	1		В		TH-95R
1	786-33004-900	BODY,CUTTING,ASS'Y	1		Α		
2	789-33004-21	CAP,BODY	1		Α		
3	787-33004-202	REEL,(R S M X)	1		Α		
4	315-33071-200	NUT,RH,OLIVE,8X1.25	1		В		
6	792-33004-200	WASHER,REEL	3		Α		
7		SLIDER,REEL	1		Α		
8	1	HOOK,REEL SLIDER	1		Α		
	673-35600-20	BALL,STEEL	4		В		
10	793-33071-200	SPRING,REEL,GREEN	1	ĺ	Α		
11	358-02103-200	WASHER,CLUTCH A	1		Α	ĺ	
21	788-33071-20	EYELET	2		Α		
1		DECAL	1		E		
30	813-20000-200	WRENCH,HEX,4	1		D		
	829-20000-80	SPANNER,COMBI,13X19	1		C		
35	948-39907-200	BAG,TOOL	1		D		
75	798-37714-20	BRACKET,LIMITER	1		C		
76	990-11050-161	SCREW,5X16	2		В		
		WASHER,5	2		Α		
79	797-37714-20	BLADE,LINE LIMITER	1				
	992-10040-012	WASHER,S,4	2		В		
81	990-11040-081	SCREW,4X8	2		C		
					ıl		

REF.	PART NO.	PART DESCRIPTION	Q		s	SERIAL NO	REMARKS
0	783-33820-90	HEAD,AUTO,(TH-96R)	1		В		TH-96R
1	786-33810-90	BODY,CUTTING	1		В		
2	788-33071-20	EYELET	2		Α		NOTE: This head can be fitted on any
3	760-33810-20	WASHER,MOUNTING	1		Α		TBC-4000
4	785-33810-20	BASE,ADJUSTMENT	1		В		
5	793-33820-20	SPRING, REEL,	1		Α		
6	792-33810-20	WASHER,ADJUSTMENT	1		Α		
7	787-33810-20	REEL	1		В		
8	673-35600-20	BALL,STEEL	3		В		
9	790-33810-20	SLIDER,REEL	1		В		
10	789-33810-20	CAP,BODY	1		в		:

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part


FIG.8 MARKS

CAUTION

TO AVOID POSSIBLE INJURY. GUARD MUST BE IN PLACE DURING OPERATION.
FOR SAFE USE. FOLLOW INSTRUCTIONS IN OWNER'S MANUAL.
EYE PROTECTION SHOULD BE WORN BY USER OF THIS UNIT.

PRO FORCE

Tanaka PROFORCE.—5








FIGURE 8

REF.	PART NO.	PART DESCRIPTION	Q	C	s	SERIAL NO	REMARKS
1	906-37724-20	DECAL,TBC-4000	1		D		
2	919-37701-200	DECAL	1		D		
3	950-37503-200	DECAL,PRO-FORCE A	1		D		
4	923-37400-200	DECAL,LEVEL	1	i	D		
5	951-37503-200	DECAL,PRO-FORCE B	1		D		
6	933-37710-200	DECAL,SYMBOL	1		D		
<u></u>							