Tanaka.

Parts Catalog

Portable Edger

Model: TPE-2110

DPL-PE210-HST 01-02-96

TPE-2110

OPTIONS AND ACCESSORIES

SHOULDER STRAP



MANUALS / CATALOGS

211672 Owner's Manual DPL-PE210-HST Parts Catalog

PERFECT MIX® 2-Cycle Engine Oil




700109 2.8 oz. Bottle, 1 Gallon Size (24*) 700108 16 oz. Self-measuring Bottle (24*) 700110 1 Gallon Jug Commercial Size (6*) * Case Quantity

SPECIAL TOOLS

215432 Pressure Test Tool 217720 Torx Drive Set 222785 T-25 Torx Drive 3.5


009-29323-500 Piston Pin Remover

111124 T-27 Torx Drive 3.5" 323330 Ignition Tester 91424 Tachometer









REF.	PART NO.	PART DESCRIPTION	O	C	S	SERIAL	NO	REMARKS
1	216027	SCREW, M5X28.5mm	2	 	C	SEINAL	. 140	1 NEIVIANNO
2	227694	COVER, AIR CLEANER	1		C			
3	227023	FILTER, AIR	1		C.	:		
4	302029	BOX, AIR ASS'Y			C			
5	223730	KIT, CHOKE ASS'Y	¦		D			
6	~~~	* SHUTTER, CHOKE LEVER	<u>'</u>		ט			
		Shorter, choke leven	'					
7	219016	SPRING, SHUTTER	4		С			
8	~~~	* PLATE, CHOKE SHUTTER			١			
9	227022	BUSHING	2		С			
10	215992	GROMMET	1		D			
11	~~	* AIR BOX			וטו			
12	216591	WASHER, FLAT	4		С			
'-	210001	WASHER, I LAT	'					
13	229524	NUT	2		c			
14	323702-02	CARBURETOR, ASS'Y	-		C			SEE FIG. 3
15	224148	GASKET, CARBURETOR		ļ	C			OCE 1 Id. 0
16	223984	INSULATOR, CARB.	1		D			
17	224315	GASKET, SHIELD INSULATOR	1 1		C			
18	219508	SCREW, MUFFLER SHIELD	2		c			
] [210000	SOLICIT, MOLT ELIT OFFICE	-		Ĭ			
19	229121	BUSHING	4	-	С			
20	215874	SCREW, M4X9.5mm	1		Ď			
21	68497	WASHER	2		c			
22	300139	STUD, INTAKE	2		c			
23	216585	NUT, LOCK	2		c			
24	227695	SHIELD, MUFFLER	1	l	c			
		,						
25	323760	SHIELD, MUFFLER, HEAT	1		в			
26	224350	NUT	1		c			
27	300632	KIT, MUFFLER	1		c			
28	301833	MUFFLER	1		c			
29	322018	SCREEN, SPARK ARRESTOR	1	ļ	cl			
30	322017	PLATE, DEFLECTOR	1		С			
31	323829	GASKET, MUFFLER	1		c			
32	235642	NUT	2		C			
33	323419	STUD, MUFFLER	2		C			
34	216022	SCREW, M4X21.4mm	2		С			
35	217669	SCREW, M4X25mm	1		С			;
36	301355	STARTER, ASS'Y	1		C			
	004							
37	301356	HOUSING, STARTER	1		C			
38	218932	GUIDE, ROPE	1		C			
39	219585	SPACER, START HOUSING	3					
40	222800	SCREW, M4X9.5mm	1		미			İ
41	216590	WASHER, FLAT M4mm	1		Č			
42	301252	DRUM, ROPE, ASS'Y	1		C			
Щ.		<u> </u>						

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.

	SONE I COIL.	IPE-2110		7111			
REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS
43	216093	ROPE, STARTER, 36"	1		D		
44	216792	HANDLE, STARTER	1		D		
45	218941	WASHER, NYLON	1		D		
46	300474	SPRING, STARTER	1		C		
47	217390	CUSHION, TANK	1		C		
48	222239	TANK, FUEL, ASS'Y	1		C		
49	217264	HOSE, FUEL	1		C		
50	300869	FILTER, FUEL	1		В		
51	222238	HOSE, FUEL RETURN	1		C		
52	217382	CUSHION, TANK	1		C		
53	301376	KIT, FUEL CAP/DECAL	1		Α		
54	216583	NUT, HEX M8mm	1		C		(Torque to 150~170 in./lbs.)
55	225037	PAWL, STARTER ASS'Y	1		C		
56	213177	SCREW, TORX	4		D	·	
58	323141	HOUSING, ASS'Y	1		C		
59	~~~	* MOUNT, ANTI-VIB	1				
60	236381	SCREW, M5X10mm	1		C		
61	236529	WASHER	2		C		
	007700 00				_		
62	227700-68	CLAMP, UPPER, ORANGE			C		
63	227701-68	CLAMP, LOWER, ORANGE	1		C		
64	235804	SCREW M5X30mm	2		С		
65	218065	DRUM, CLUTCH ASS'Y			С		
66	213186	RING, RETAINING			С		
67	213187	BEARING, BALL	1		D		
68	~~~	* DRUM, CLUTCH					
69	217554	CLUTCH ASS'Y	$ \cdot $		С		
70	~~~	* SHOE, CLUTCH	2				
71	223770	SPRING, CLUTCH	2		С		
72	215536	ROTOR, CLUTCH	1		D		
73	215539	PLATE, SIDE	$ \cdot $		C		
74	216022	SCREW, M4X21.4mm	2		С		
75	219383	WIRE, SWITCH ASSY	1		c		
76	302138	IGNITION ASS'Y	1		Č		
77	223884	KIT, SPARK PLUG WIRE	1		С		
78	215533-01	GROMMET, H/T LEAD	1		С		
79	110995	GROMMET, PLUG WIRE	1		С		
_	4						
80	102556	CONNECTOR	1		С		
81	95266	BOOT, PLUG	1		С		
82	222308	FLYWHEEL, ROTOR	1		С		
83	322189	PLUG, SPARK DJ7Y	[]		C		
84 85	213178	SCREW M5X8.5mm	[D		
တ	215540-01	COVER, CYLINDER	1		C		
ш		1	11				

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS			
86	217320	SCREW, M6X18mm	2		D	·				
87	224448-01	CYLINDER, ASS'Y	1		C					
88	323716	GASKET, CYLINDER	1		В					
90	302026	CRANKCASE, ASS'Y	1		C					
91	301443	KIT, PISTON	1		C					
92	323611	RING, PISTON	1		В					
93	218275	PIN, PISTON	1		D					
94	111026	RING, SNAP	2		D					
95	110984	BEARING, NEEDLE	1		D					
96	301273	CRANKSHAFT, ASS'Y	1		С					
97	213282	BEARING, ROLLER	1		С					
98	216143	BEARING, BALL	1		С					
] .							
99	215545	GASKET, CRANKCASE	1		D					
100	83859	SEAL, OIL	1		С					
101	216500	SEAL, OIL	1		С					
102	213191	PIN, LOCATOR	4		D					
103	216027	SCREW, M5X28.5mm	4		С					
104	102164	KEY, FLYWHEEL	1		С					
105	215541	GROMMET	1		D	i				

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.

REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO.	REMARKS
1	217403	NUT, M6X1.0mm	1		С		
2	216596	WASHER, M6	2		С		
3	227280	HANDLE, ASS'Y	1		С		
4	229837	HANDLE, LEFT	1		С		
5	229836	HANDLE, RIGHT	1		С		
6	229824	SLIDE, THROTTLE CABLE	1		С		
7	229823	PIN	1		С		
8	229973	SPRING	1		В		
9	227065	RING	1		С		
10	227058	SPRING, TRIGGER	1		В		
11	227064	TRIGGER	1		В		
12	227067	WIRE, THROTTLE	1		В		
13	229846	SCREW, TC, 2.9X22mm	4		С		
14	227074	SCREW, 2.9X16, SELF THD.	2		С		
15	235912	NUT	1		В		
16	111012	SCREW, 4-40X0.31	2		С		
17	301605	HOUSING, OUTER, ASS'Y	1		С		
18	46750-65	DECAL, CAUTION, SHAFT	1		D		
10	000407	DECAL EVE/ELD COVED	.				
19 20	223407	DECAL, EYE/EAR COVER	1		D		
21	223408	DECAL, WARNING, SHAFT			D		
22	301256	SHAFT, DRIVE ASS'Y	1		C		
23	323396 111185	CASE, GEAR ASS'Y	1		C		
24	217159	BOLT, M5X40mm, HEX NUT, M5mm, HEX	2		C		
	217133	NOT, WISHIN, HEX			\leq		
25	216795	SCREW, M5X12mm, PHL.			С		
26	216832	BOLT, M8X8mm, HEX			č		
27	322009-01	SLEEVE, SPLINED			c		
28	323363	COLLAR	$ \cdot $		В		
29	301272	BLADE	1		В		
30	218075	FLANGE, SPINDLE	1		c		
31	216751	NUT, M10mm, HEX	1		c		
32	218159	PIN, COTTER	1		c		
33	111136	BOLT, SHOULDER, 10-24	3		c		
34	323618	PLATE, BACKUP	1				
35	323527	PLATE, ADJUSTMENT	1		C		
36	111135	NUT, 10-24, HEX LOCK	3		디		
37	110070	MACHED Moves			إ		
38	110879	WASHER, M8mm	[]				
39	111138 323547	WASHER, LOCK	¦				
40	323024	GUARD, SAFETY WHEEL, 6"	¦				
41	323024	SLEEVE, WHEEL	¦		C		
42	110879	WASHER, M8mm			č		
		The state of the s					
		· · · · · · · · · · · · · · · · · · ·	نب				

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.

FIGURE 2 cont.

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS
43	111138	WASHER, LOCK	1		С		
44	111140	BOLT, 5/16-18X2.5	1		С		
45	111137	WASHER	1]	C		
46	323022	FLAP	1		C		
47	219079	SPACER	2		C		
48	216633	WASHER	1		С		
49	111054	SCREW, 10-24X.625	2		C		
50	323021	KNOB	1		C		
51	224977	KIT, LOOP HANDLE	1		С		
52	227045	HANDLE, LOOP	1		C		
53	227046	CLAMP, HANDLE	1		C		
54	228320	SCREW, M6X0.8X45mm	4		C		
55	236936	WASHER	4		c		
56	236642	NUT	4		c		
57	224127	SPACER, HANDLE	1		C		
58	222831	DECAL, ON-OFF	1		D		

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.




FIGURE 3

	TONE 3	1FL-21101					
REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS
1	323702-02	CARBURETOR, ASS'Y	1		С		
2	~~~	SCREW, PUMP COVER	2			ĺ	
3	~~~	COVER, PRIMER PUMP	1		ļ		
4	223077	BULB, PRIMER	1		С		(1) Carb. Repair Kit
5	223913	COVER, FUEL PUMP, ASS'Y	1		С		224462
6	~~~	SCREW, IDLE ADJ.	1				
							(2) Carb. Gasket/Diaphragm Kit
7	~~~	SPRING, IDLE SCREW	1				223833
8	~~~	(1)(2) GASKET, FUEL PUMP	1				
9	~~~	(1)(2) DIAPHRAGM, FUEL PUMP	1				(3) Swivel-Carb Kit
10	~~~	(1) SCREEN, FUEL PUMP INLET	1				224466
11	~~~	SHAFT ASS'Y, THROTTLE	1				
12	~~~	(1) SPRING, THROTTLE RETURN	1				
		•					
13	~~~	RING, SHAFT RETAINER	1				
14	~~~	(1) NEEDLE, IDLE	1	į			
15	~~~	(1) NEEDLE, HIGH SPEED	1				
16	~~~	(1) SPRING, IDLE NEEDLE	1				
17	~~~	(1) SPRING, HI-SPEED NEEDLE	1				
18	~~~	(1) WASHER	1				
19	~~~	(1) "O" R!NG	1				
20	~~~	(1) SCREW, VALVE	1				
21	~~~	VALVE, THROTTLE	1				
22	~~~	(1) SCREW, METERING LEV. PIN	1				
23	~~~	(1) PIN, METERING LEVER	1				
24	~~~	(1) LEVER, METERING	1				
			I				
25	~~~	(1) VALVE, INLET NEEDLE	1				
26	~~~	(1) SPRING, METERING LEVER	1				
27	~~~	SEAT ASS'Y, CHECK VALVE	1				
28	~~~	(1) PLUG, WELCH 5/16	1				
29	~~~	(1) PLUG, WELCH 1/4	1				
30	~~~	(1) RING, SCREEN RETAINER	1				
31	~~~	(1) SCREEN, CHECK VALVE	1				
32	~~~	(1) SCREW, METERING COVER	4				
33	~~~	COVER, METERING DIAPHRAGM	1				
34	~~~	(1)(2) DIAPHRAGM ASS'Y, METER.	1			}	
35	~~~	(1)(2) GASKET, METERING DIAP.	1				
36	~~~	(3) SWIVEL	1				
37	~~~	(3) CLIP	1	ł			
38	323601	CAP, LIMITER, HIGH	1		С		
39	323602	CAP, LIMITER, LOW	1		С		

^{(1) (2)} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=slow move E=N.L.A. F=Superceded or replaced by a new part.