Tanaka^{*}


Parts Catalog

Telescopic Shaft Trimmer

Model: TST-218


Units Prior To Serial No. J 075260

FIG.1 ENGINE




-		/// / 5
REF. MER PARTIER	PARMANE	ST SERVINGER REMARKS
1-001 157-11668-900 1-002 018-01805-200 1-003 002-0630R-200	SPARK PLUG CAP ASS'Y SPARK PLUG CJ8 CYLINDER CYLINDER GASKET PISTON RING	1 1 1 1 2 2 I -H125860 2 H126861-
1-011 999-62071-121	CIR CLIP	1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1-013 167-21952-80 1-014 994-16040-22 1-015 330-00200-21 1-015 330-00200-22	IGNITION COIL COMP. IGNITION COIL COMP. SCREW 4X22/WS GEAR SHAFT SHIM 0.10 GEAR SHAFT SHIM 0.15 GEAR SHAFT SHIM 0.20	1 I -H104350 H104351- 2 V V V
1-016 072-06308-90 1-017 090-06097-20 1-018 999-66122-26 1-019 999-61600-10	GEAR SHAFT SHIM 0.30 CRANK CASE ASS'Y CRANK CASE GASKET OIL SEAL 12227 BALL BEARING #6001, 28MM/OD STARTER PULLEY ASS'Y	V 1 1 2 2 2 1 1
1-023 790-06097-20 1-024 788-06097-20 1-025 359-10112-20 1-026 991-01080-01	STOP RING 5 D STARTER PAWL SPRING D STARTER PAWL B CLUTCH WASHER B HEX. NUT 8 D STOP CORD COMP.	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1-031 155-21713-81	I NUT 7	1 N H255951-
1-041 1-042 1-043 992-10050-01 992-10050-01	1 SCREW 5X25	4 4 4

FIG.2 ENGINE COMPONENTS




/	<u> </u>		
REF	MER PARTER	PARHAME	SE PARTIER REMARKS
2-001 2-002 2-003 2-004 2-005 2-006	255-0630G-210 738-0630B-210 994-15040-122	SPARK PLUG RUBBER COVER MUFFLER PROTECTOR SCREV 4X12/PS CYLINDER COVER COLLAR SCREV 5X45	
2-007 2-008 2-009 2-011 2-012 2-013	706-0630R-900 133-0630R-200 359-02103-200 290-00501-802	SMALL VASHER 5 MUFFLER ASSY, W/HET INSULATOR CLUTCH VASHER B CLUTCH SHOE COMP. CLUTCH SPRING	
2-014 2-016 2-020 2-022 2-027 2-029	112-0630N-200 994-14050-162	STEP BOLT MUFFLER GASKET FAN CASE	2 2 1 1 1 1 4 1 D H255661-
2-032 2-033 2-034 2-035 2-036	011-06308-200 994-15050-162 203-06308-201 994-15050-142	SCREW 5X16/PS CYLINDER COVER COLLAR SCREW 5X16/PS PRIMARY CORD GROWNET SCREW 5X14/PS SCREW 5X12/PS	
2-037 2-039 2-040 2-041 2-043 2-043	994-15040-142 653-0630B-202 655-0630B-200 403-0631A-200	SCREW 4X12/PS SCREW 4X14/PS TANK BRACKET TANK BRACKET RUBBER INLET MANIFOLD GASKET INLET MANIFOLD GASKET	2 2 1 4 1 1 - J074960 J074961-
2-044 2-045 2-048 2-046 2-047 2-050	994-16050-221 402-0602K-200 402-0602K-201	CARBURETOR INSULATOR COMP. SCREW 5X22/VS CARBURETOR GASKET CARBURETOR GASKET AIR CLEANER GASKET SCREW 5X55	1 2 1 P -J074960 J074961- H255661-
2-051 2-052 2-055 2-056 2-056 2-056	534-32710-200 700-02504-085 700-02504-070	S. WASHER 5 SMALL WASHER 5 RETURN GROWNET FUEL PIPE 2.5X4X85 FUEL PIPE 2.5X4X70 FUEL PIPE 2.5X4X45	2 2 1 1 1 1 1 1 1 1
2-057 2-057 2-058 2-065 2-065 2-066	595-0062A-910 595-0062A-901		1
2-066 2-067 2-068 2-070 2-071 2-080	680-00731-201 675-11600-900 990-11050-101 992-10050-012	PUMP FILTER BODY ASS'Y SCREW 5X10	
2-080 2-081 2-082 2-083	740-0602B-201 739-0802B-200	MUFFLER BODY B COMP. MUFFLER COLLAR MUFFLER COUPLING GASKET MUFFLER PARTITION PLATE COMP.	1 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

FIG.3 RECOIL STARTER




RES	NER PARTIER PARTIANE	SERIANER REMARKS
₩8 −000	762-06097-902 RECOIL STARTER BODY ASS'Y	
3-001	772-08097-202 RECOIL STARTER BODY	
3-002	780-06097-200 RECOIL SPRING	
3-003	774-06097-200 STARTER ROPE REEL	
3-004	801-06091-200 ROPE REEL WASHER	
3-005	990-15050-126 SCREW 5X12	i
3-006	782-06097-200 ROPE GUIDE	
3-007	783-06097-200 STARTER ROPE	
3-008	785-06097-200 STARTER HANDLE	<u> i </u>


FIG.4 AIR CLEANER



RE		AME SERIANER REMARK	5
4-000 4-001 4-002 4-003 4-004 4-005	410-0602D-901 AIR CLEANER ASS'Y 424-0802K-201 AIR CLEANER CAP 446-0602K-200 CLEANER ELEMENT 453-0602K-200 SPACER 470-0602K-200 COLLAR	1 1 1 1 2	
4-006	528-0602D-200 CHOKE PLATE. W/2MM 423-0602K-210 CLEANER BODY	HOLE I	


FIG.5 CARBURETOR






	-	
REF NER PARTIER	PARHAME	SERVINER REMARKS
5-000,1 455-25117-900	CARBURETOR ASSY, WY-54 CARBURETOR ASS'Y, WYJ-6 SVIVEL STOP RING ADJUSTER STAY	1 P - N255860 1 1 1 1 1 1 2 P 1255661-
5-005.1 5-006.1 5-007.1 5-008.1 5-009.1 5-010.1 614-25100-200 613-25100-201 462-25100-201 463-25100-200 488-25106-800 437-25100-200	CABLE ADJUST NUT IDLE ADJUST SCREV IDLE ADJUST SPRING ITHROTTLE VALVE CONP.	
5-011,1 5-012,1 5-012,1 5-012,1 5-013,1 5-013,1 5-014,1 5-015,1 5-015,1	MAIN JET #43 MAIN JET #44 PUMP GASKET PUMP DIAPHRAGN	1 R - H126860 - N255660
5-016,1 522-25100-200 5-017,1 578-25007-200 5-018,1 575-25100-810 5-019,1 475-25016-200 5-020,1 474-25001-800 5-021,1 452-25105-200	INLET SCREEN PUMP BODY COMP. DIAPHRAGN GASKET METERING DIAPHRAGN COMP.	
5-022,1 5-023,1 5-024,1 5-001 5-004 5-005 548-25117-200 549-25100-200 514-25100-200 544-25120-200 539-25120-200	THRUST WASHER PRIMING BODY THROTTLE SET SCREW CABLE ADJUST STAY	4 1 1 2 1 1
5-010 550-25100-200 5-011 599-2000W-420 5-012 577-25100-200	THROTTLE VALVE COMP. O-RING NAIN JET #42	
5-016 578-25007-200 5-017 575-25129-800 5-018 475-25016-200	CIRCUIT PLATE	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
5-021 548-25117-200 5-022 613-25100-200 5-023 614-25100-200 5-024 431-0634C-200	DIAPHRAGH COVER SET SCREW CABLE ADJUST NUT CABLE ADJUSTER CLEANER PACKING AIR PURGE COMP.	1 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
5-026 447-25108-200	PRINING BODY	


FIG.6 CLUTCH CASE



	NER PAR NER			<u> </u>	SERIANBR REMARKS
6-001		CLUTCH DRUN COMP.	\prod	Г	
6-002		STOP RING C-32 IN	1		
6-003		BALL BEARING #6201DD, 32MM/OD	\mathbf{H}	!	
6-004		STOP RING C-12 EX	11		ł l
6-005,1	331-37500-200		1	l	-H255860
6-005	331-37500-210	CLUTCH CASE	1	M	M255661-
1			1		
6-006,1	990-51060-253	HEX. HOLE BOLT 6X25	1		-H255660
6-006		HEX. HOLE BOLT 5X25	1	N	M255661-
6-007.1	992-10060-062		1	!	- H255660
6-007	992-10050-062		11	N	H255661-
6-008,1	990-51060-203	HEX. HOLE BOLT 6X20	4		-H255660
6-008	990-53060-203	HEX. HOLE SCREW 6X20	4	N	
1					
6-009	992-10060-062	S. VASHER B	4		i
6-010	992-01060-061	WASHER 6	4		
6-011	599-0630M-200	ANTI-VIBE RUBBER	1_{1}	N	H255661-
6-012	990-51050-153	HEX. HOLE BOLT 5X15	li	N	
6-014		GEAR CASE VASHER	l i	N	H255661-

FIG.7 HANDLE







MER		ars ars
RET NER PARTER		ST SERVINGE REMARKS
7-001.1 503-37100-200 7-001 503-37113-200 7-001 503-37113-200 7-002 500-37503-200 7-003 870-37101-900) HANDLE GRIP, RIGHT) HANDLE GRIP, RIGHT) HANDLE GRIP, RIGHT	1
7-007 507-37500-200 7-008 506-37500-200) HANDLE BRACKET C) HANDLE BRACKET B) HANDLE BRACKET A) HANDLE SPACER	1 D H255661- 1 D H255661- 1 D H255661- 1 D H255661- 2 D H255661- 1 I -H104350
7-010 165-33130-200 7-011 499-37100-200 7-016 335-37500-800 7-017 992-10050-062	HANDLE GRIP A HANDLE GRIP A PIPE GROMMET LIFTING METAL COMP. S.WASHER 5 HEX. HOLE BOLT 5X12	1 D - H255680 H255661- 1 D H255661- 1 1 1
7-019 341-37500-210 7-020 035-37500-210 7-021 384-37500-200 7-022 999-61698-001	DRIVE SHAFT PIPE DRIVE SHAFT PIPE DRIVE SHAFT A BEARING HOLDER SPRING A BALL BEARING 698ZZ, 19MM/OD BEARING HOLDER	1 R -H255660 H255661- 1 1 2 2
7-025 355-37500-820 7-026 290-37500-200 7-027 280-37500-201 7-028 992-10060-062	BEARING HOLDER SPRING B DRIVE SHAFT ADAPTOR PIPE BUSHING JOINT CASE S.WASHER 6 HEX. HOLE BOLT 6X22	1 1 1 1 1 1 - H255660
7-030 991-74080-040 7-031 992-01080-061 7-032 890-37500-800 7-033 036-37500-801		1 H255661- 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
7-040 993-42030-081 7-040 993-42030-081 7-041 162-37101-200 7-042 259-37101-200	BUSHING ASS'Y TAPPING SCREW 3X8 TAPPING SCREW 3X8 STOP SWITCH STOP SWITCH BASE STOP SWITCH SPRING	3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
7-045 176-37101-200 7-046 991-86050-000 7-047 993-55060-001 7-048 994-31050-251		
7-051 956-37101-200 7-052 832-37101-200 7-053 880-37101-200 7-059 336-33800-810	LOCK BUTTON SPRING LOCK BUTTON RETURN SPRING THROTTLE ARM CUSHION RUBBER COMP. PROTECTION TUBE 13X460L	1 1 1 1 1 D H255661- 1 D H255661-
7-065	HANDLE GRIP, RIGHT HANDLE BRACKET A	2 D H255661- 1 H H255661- 1 N H255661- 1 N H255661- 4 H H255661- 4 N H255661-
7-071 511-37505-200	HANDLE BRACKET B HANDLE SPACER HANDLE BRACKET C	1 N H255661- 1 N H255661- 1 N H255661-

	NER	PARTIER		PARMAPAE		_	SERIAL	R REMARKS
7-073 7-074 7-075	992-1	0060-062 3060-253	S. WASHER 6 HEX. HOLE S PIPE GROWNE	CREW 6X25	2 2 2	* = *	H255661- H255661- H255661-	Ar .
7-076 7-077 7-078 7-079 7-080	274-3 164-1 198-3 504-3	7504-800 3049-000 3130-200 7505-200	STOP CORD C EARTH CORD PROTECTION CORD CLAMP SHAFT GRIP THROTTLE WI	COMP. TUBE 13X490L	1 1 1 1 1 1 1 1	H	H255661- H255661- H255661- H255661- H255661-	
7-088 7-089	164-1 746-3	3012-000 3407-900	PROTECTION SHOULDER BE	TUBE 13X12OL ELT ASSY,KOREAN	MAKE 1			
i								
					:			


FIG.8 GEAR CASE






REF	NER PARTER	PARTHAME	SERIN REPROPER
8-001 8-002 8-003 8-004 8-005 8-006	300-37500-900 990-51050-253 992-10050-062 993-53022-002 993-50010-002	GEAR CASE ASS'Y HEX. HOLE BOLT 5X25	
8-007 8-008 8-009 8-009 8-010 8-011	302-37500-201 300-37300-200 300-37300-201 99 1-01050-041	GEAR CASE GEAR CASE	1 1 1 P H255660 H255661-
8-012 8-013 8-014 8-015 8-015	301-37300-200 304-37300-200 304-37300-201	BALL BEARING 626 , 19NN/OD GEAR GEAR SHAFT	1 1 1 1 1 1 P H126860 H126861-
8-017 8-018 8-019 8-020 8-021 8-022,1	310-37300-210 311-37300-202 992-01080-011 992-29080-000	STOP RING C-28 IN CUTTER HOLDER CUTTER HOLDER CAP WASHER 8 TOOTHED LOCK WASHER 8 L/H FIXING BOLT (L.H. THREAD)	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
8-022 8-023 8-026 8-027 8-028 8-029,1	324-37300-200 990-51050-183 992-10050-062 442-37500-200	SAFETY GUARD BRACKET	1 P J074961- 1 2 2 1 1 -J074960
8-029 8-030 8-037	441-37500-800 315-37500-200	SAFETY COVER COMPVERNILION	1 P J074961- 2 D J074961-
	į		

FIG.9 TOOLS & NYLON HEAD



	NER PARNER	/	_	<u> </u>	SERIANBR REMARKS
9-000	783-33440-901	[MYLUN HEAD ASS'Y (TH-95X)	Īī	I	-H102680
9-001	783-33440-902		ij	١.	H102681-
9-001	700-33004-601	CUTTING BODY COMP.	[]	П	-H102680
9-002	789-33004-201	CUTTING BODY ASS'Y	[]		H102681-
9-003	787-33004-201		!		1
	101-33004-202	CORD REEL	1		
9-005	314-33670-200	8X1.25 L/H BOLT (GOLD)	١,		1
9-006	792-33004-200	RFFI WASHER	1:		1
9-007	790-33004-200	REEL SLIDER	17	1	i l
9-008	791-33004-200	REEL SLIDER HOOK	li		
9-009	673-35600-200	STEEL BALL 5/16"			
9-010	793-33440-200	REEL SPRING (GOLD)	7]
		ASSE STRING (GOLD)	1 *		ì
9-011	358-02103-200	WASHER	١,		1
9-021	788-33071-200		ĺ	l w	H102681-
9-022	926-33440-200	IDENTIFICATION MARK, X	١ī	Ι"	1 "102001
9-030	813-20000-200	HEX. VRENCH 4	li	l	i I
9-031	829-20000-800	COMBI. BOX SPANNER 13X19 .PLUS	li	l	l
9-032	814-20000-200	HEX. WRENCH 5	Ιī	D	H255681-
9-033	948-39907-200	TOOL BAG	1		

FIG. 10 MARKS







CAUTION TO AVOID FOSSIBLE INVURY GUARD MUST BE IN FLACE DURING CERRATION FOR SAFELSE FOLLOW INSTRUCTIONS IN OWNERS MANUAL EYE FROTECTION SHOULD BE WORN BY USER OF THIS UNIT



ASSURE TIGHTNESS ______5

-3-1

CAUTION
TO AVOID POSSIBLE INJURY. GUARD MUST BE IN PLACE DURING OPERATION. FOR SAFE USE, FOLLOW INSTRUCTIONS IN OWNER'S MANUAL. EYE PROTECTION SHOULD BE WORN BY USER OF THIS UNIT.

Tanaka PROFORCE --

REF	NER PARTIER	PARNAME	19	SERIANIER REMARKS
10-001 10-002 10-003 10-004	950-37503-200 906-37503-200 929-33576-201 951-37503-200 919-37701-200	SYMBOL WARK PROFORCE MARK B CAUTION WARK	1 1 1 1 1 1 1 N	-H255660 H255661- H255661- -H255660 H255661- H255661-
10-005	919-37502-201	CAUTION WARK A	1	