



Parts List for TV700 Type 2

Item Number	Part Number	Description	Qty Required
1	158498-00	BEARING,SPHER.	1
3	089754-01	BRUSH	2
4	085943-02	BRUSH SPRING	2
5	134252-00	HOLDER,BRUSH	2
6	380419-00	BRUSH PLATE ASY	2
7	000000-00	No Longer Available	1
8	330073-98	CORD/8 FT/18-2	1
10	384852-00	PLATEN	1
11	330019-04	SCREW,PLASTITE	10
13	384859-00	BAFFLE	1
15	000000-00	No Longer Available	1
16	448387-00	TERMINAL	3
17	148481-00	PROTECTOR,CORD	1
18	380414-00	CLAMP,CORD	1
19	584741-00	FOAM PAD	1
20	151288-00	CLAMP,PAPER	2