





Parts Breakdown

UH5530

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	957-801-410	CARBON BRUSH CPL., UH5530	1
2	970-001-210	SWITCH, UH6350	1
2	970-001-210	SWITCH, UH6350	1
3	970-801-220	STATOR ASS'Y. UH5530	1
4	970-201-220	SCREW WIRE CONNECTOR, UH5530	1
6	970-001-210	SWITCH, UH6350	1
6	970-001-210	SWITCH, UH6350	1
7	970-311-250	CONNECTING CABLE, UH5530	1
8	960-101-074	BALL BEARING, UH5530	1
9	970-801-820	ROTOR ASS'Y, UH5530	1
10	960-101-104	BALL BEARING, UH5530	1
11	204-152-010	BREAK PROTECTION, UH5530	1
12	970-102-140	CABLE WITH PLUG, UH5530	1
13	221-213-111	HAND GUARD, UH5530	1
14	980-114-292	LABEL, UH5550	1
15	913-540-205	SCREW 4.0X20, UH5530	2
16	917-005-250	SCREW, UH5530	2
17	221-310-110	TUBULAR HANDLE, UH5530	1
18	221-145-110	PRESSURE SPRING, UH5530	1
19	221-144-110	FRONT GRIP SWITCH, UH5530	1
20	980-114-296	LABEL, UH5550	1
21	920-204-000	HEXAGONAL NUT M4, UH6330	2
22	203-152-050	TRACTION RELIEF, UH5530	1
23	915-635-164	SELF CUTTING SCREW 3.5X16, UH5530	1
24	221-145-120	PRESSURE SPRING, UH5530	1
25	221-220-020	GEAR COMPLETE, UH5530	1
25	221-220-021	GEAR ASSEMBLY	1
25	221-220-022	GEAR ASSEMBLY	1
25	222-220-020	GEAR CPL., UH6350	1
26	221-211-010	GEAR PLATE WITH AXLE, UH5530	1
27	221-144-120	REAR GRIP SWITCH, UH5530	1
28	920-205-000	HEX NUT M5, DCS340	2
29	221-110-611	CASE COMPLETE, UH5530	1
30	221-144-130	SWITCH FORK, UH5530	1
31	913-540-205	SCREW 4.0X20, UH5530	8
32	001-230-010	SCREW M4X25, UH6330	2
33	221-233-170	SAFETY NUT, UH5530	5
34	221233180	MOUNTING BAR, UH5530	1
35	221233280	SHEAR PLATE A, UH5530	1
36	221233380	SHEAR PLATE B, UH5530	1
37	221-233-430	BAR, UH5530	1
38	221-233-150	DISTANCE PIECE, UH5530	5
39	221-233-160	SCREW M5X14, UH5530	5
40	220233620	SHEATH, UH5530	1
41	221230650	SHEAR BLADE, UH5530,17-3/4	1
42	221-229-240	PLATE, UH6330	1
43	970-311-270	CONNECTING CABLE, UH5530	1
44	970-311-280	CONNECTING CABLE, UH5530	1
47	221-229-210	WASHER, UH6330	1