



## Parts List for Model W & WU

NOTE: The quantity number indicates the total number of pieces required for a complete pump repair.  
When ordering parts give compressor model, serial number and part number. Order assemblies when possible.

<u>REF. NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	120-1166	PIN,FLYWHEEL, STL, 5/16 ODX 1-1/4 L, W25	1 EA
2	610-1423	FLYWHEEL,W PUMP,CI,16"DIA,2 GROOVE,W23A	1 EA
3	150-1038	SEAL,OIL,LIP,SINGLE,1.575 DIA,W11	1 EA
4	610-1051	PLUG,FILL,OIL,W/O-RING&DIPSTICK,ASSY,W14	1 EA
5	610-1441	CRANKCASE,W PUMP,CI,MACHINED,W1	1 EA
6	360-1114	SIGHT GLASS 1" INSTALLED LOW	1 EA
7	122-1084	CAP,FEMALE,MI,3/8"NPT	1 EA
8	122-1037	NIPPLE,STEEL,SCH 40,3/8" X 2" L	1 EA
9	150-1031	BEARING,BALL,W9	1 EA
10	610-1428	CRANKSHAFT,W PUMP,CI,MACHINED,W20	1 EA
11	150-1032	BEARING,BALL,W10	1 EA
12	104-1014	GASKET,CAP,BEARING,W PUMP,1/32THK,W3	1 EA
13	150-1081	COIL SPRING C/U UNLOADER ZN	1 EA
14	220-1049	TUBE,OPERATING,CENTRIFICAL UNLOADER,EQ71	1 EA
15	610-1066	PIN,PIVOT,UNLDR,CNTRFCL,W/CTTR PIN,EQ73	1 EA
16	120-1169	PIN,COTTER,ST,BLACK,1\16DIA X 1\2LG,EQ73B	1 EA
17	610-1167	UNLOADER,CENTRIFUGAL,WEIGHT,SET,EQ70	1 EA
18	610-1434	CAP,BEARING,W PUMP,CI,MACHINED,W2	1 EA
19	120-1002	SCREW,CAP,HEXHD,GR5,ST,BLK,1/4-20X5/8 ( 15 FT - LB. )	4 EA
20	121-1025	CONNECTOR,MALE,COMPRESSION,BR,1/4TBX1/8"	2 EA
21	220-1050	PIN,UNLOADER,CENTRIFICAL,EQ74D	1 EA
22	120-1171	NUT,HEX,JAM,STEEL,PLATED,7/16-20,EQ74C	1 EA
23	120-1170	VALVE,CORE,EQ74A	1 EA
24	150-1035	BODY,UNLOADER,EQ74B	1 EA

## Parts List for Model W & WU

NOTE: The quantity number indicates the total number of pieces required for a complete pump repair.  
When ordering parts give compressor model, serial number and part number. Order assemblies when possible.

<u>REF. NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
25	310-1012	ROD,CONNECTING,AL,HIGH PRESSURE,W21W	1 EA
26	150-1003	RING,COMPRESSION,PISTON,STEEL,EBA 22,K33	4 EA
27	150-1013	RING,COMPRESSION,PISTON,W/TPR HK,EBA 33	4 EA
28	610-1065	RING,OIL,K34	4 EA
29	104-1103	BUMPER,WRIST PIN,PLASTIC,K36A	6 EA
30	220-1005	PISTON,PUMP,ALUMINUM,MACHINED,K32	3 EA
31	150-1005	PIN,PISTON,STEEL,HARDENED,K35	3 EA
32	310-1007	ROD,CONNECTING,PUMP,ALUM,MACHINED,W21	3 EA
33	120-1026	SCREW,CAP,HEXHD,GR5,ST,BLK,5/16-18X1-1/2 (15 FT-LB)	8 EA
34	120-1074	WASHER,LOCK,SPLIT,STEEL,BLACK,5/16"	8 EA
35	120-1165	PIN,ROLLED,STEEL,BLACK,1/8ODX5/16L,EQ37	1 EA
36	150-1039	PIN,PISTON,STEEL,EQ35	1 EA
37	150-1034	BEARING,NEEDLE,EQ38	1 EA
38	220-1042	PISTON,MACHINED,2 STAGE,K32W	1 EA
39	104-1015	RING,O,BUNA-N,1/2"IDX11/16"ODX3/32"THK	4 EA
40	122-1051	PLUG,HEX ,BRASS,11/16-16 UN-2B X .550	4 EA
41	150-1028	PISTON,UNLOADER,VALVE,CHECK,BRASS,KU81	4 EA
42	104-1020	RING,O,SILICON,7/16"IDX5/8"ODX3/32"THK	4 EA
43	150-1020	SPRING,VALVE,UNLOADER,INTAKE, KU83	4 EA
44	121-1032	ELBOW,MALE,COMPRESSION,BR,1/4TBX1/8"NPTM	3 EA
45	310-1008	HEAD,UNLOADING,G PUMP,CI,6HOLES,LU80	1 EA
46	120-1028	SCREW,CAP,HEXHD,GR5,ST,BLK,5/16-18X2-1/4(22FT-LB)	10 EA
47	120-1252	BOLT,STUD,HEX,ST,5/16-18X2-1/4X5/8,K52-1(22FT-LB)	2 EA

## Parts List for Model W & WU

NOTE: The quantity number indicates the total number of pieces required for a complete pump repair.  
When ordering parts give compressor model, serial number and part number. Order assemblies when possible.

<u>REF. NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
48	310-1004	HEAD,START/STOP,G PUMP,REPLACEMNT,L50	1 EA
49	104-1008	GASKET,HEAD,K&G&W PUMP,1/32THK,L51	1 EA
50	150-1041	RETAINER,VALVE,STEEL,PAS,0.062"THK,K43	9 EA
51	109-1010	VALVE,CHECK,BUMPER,STEEL,K44	9 EA
52	150-1018	SPRING,CONE,SS,VALVE,DISCHARGE,K46	6 EA
53	109-1011	VALVE,DISC,STEEL,K47	9 EA
54	610-1396	PLATE,VALVE,L PUMP,CI,MACHINED,L40	1 EA
55	150-1017	SPRING,CONE,SS,VALVE,INTAKE,K45	3 EA
56	104-1007	GASKET,PLATE,VALVE,K&G&W PUMP,1/32TK,L41	2 EA
57	360-1152	CYLINDER W30 REPLACEMENT BLUE W30	2 EA
58	120-1017	SCREW,CAP,HEXHD,GR5,ST,BLK,5/16-18X3/4 ( 15 FT - LB. )	12 EA
59	104-1006	GASKET,CYLINDER,K&G&W PUMP,1/32THK,K31	2 EA
60	122-1144	NIPPLE,CLOSE,STEEL,SCH 80,PLATED,1/2"	2 EA
61	141-1006	VALVE,SAFETY,NON-CODE,1/4",65 PSI,SV65	1 EA
62	121-1013	ELBOW,MALE,BRASS,1/2-45SAEX1/2"NPTM	2 EA
63	121-1015	ELBOW,MALE,BRASS,5/8-45SAEX1/2"NPTM	1 EA
64	310-1022	HEAD,START/STOP,EQ PUMP ( RIGHT HEAD )	1 EA
65	104-1013	GASKET,HEAD,K&G&W PUMP,1/32THK,EQ51	1 EA
66	610-1392	PLATE,VALVE,W PUMP,CI,MACHINED,W40	1 EA
67	121-1039	TEE,BRANCH,BRASS,1/4"TBX1/4"TBX1/8"NPTM	1 EA
68	610-1136	TUBING,UNLOADER,HEAD-HEAD,W PUMP,WU88	1 EA
69	150-1104	ELEMENT,FILTER,AIR,(92 EMGLO),G54E	2 EA
70	610-1058	INTERCOOLER,FINNED,W/FLARE NUTS,ASSY,W62	1 EA

## Parts List for Model W & WU

NOTE: The quantity number indicates the total number of pieces required for a complete pump repair.  
When ordering parts give compressor model, serial number and part number. Order assemblies when possible.

<u>REF. NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
71	610-1135	TUBE,UNLOADER,CENTRIFUGAL,W PUMP,CU,W78	1 EA
72	610-1059	INTERCOOLER,FINNED,W/FLARE NUTS,ASSY,W65	1 EA
73	610-1134	TUBE,BREATHER,COPPER,BENT,J&W PUMP,W18	1 EA
74	220-1043	HEAD,UNLOADING,EQ PUMP,CI,6HOLES,EQ80	1 EA
75	121-1021	ELBOW,MALE,BRASS,1/2-45SAEX1/2"NPTM	1 EA
76	104-1102	BRACKET,FILTER,AIR,NYLON,BLACK,L53	2 EA
77	150-1010	ELEMENT,FILTER,AIR,COMPRESSOR,JENNY,L54E	2 EA
78	320-1006	COVER,FILTER,W/DECALS,L54	2 EA
79	120-1104	NUT,WING,ST,FORGED,PLATED,1/4-20, L55	2 EA
<b>ASSEMBLIES</b>			
80	320-1000	FILTER,W/DECAL,ASSY,L154 INCLUDES 76, 77, 78, 79	2 EA
81	320-1121	FILTER,W/DECAL,ASSY,G154S	2 EA
82	610-1032	VALVE,CHECK,DISCHARGE,ASSY,K146 INCLUDES 50, 51, 52, 53	6 EA
83	610-1031	VALVE,CHECK,SUCTION,ASSY,K145 INCLUDES 50, 51, 53, 55	3 EA
84	610-1042	VALVE,UNLOADER,HEAD,PUMP,ASSY,KU181 INCLUDES 39, 40, 41, 42, 43	4 EA
85	610-1020	KIT,PUMP,RING,PISTON,F&K&G&W PUMP,K133 INCLUDES 26(2), 27(2), 28(2)	2 EA
86	610-1028	PISTON,W/RINGS&PIN,ASSY,K132 INCLUDES 26, 27, 28, 29(2), 30, 31	3 EA
87	610-1053	WEIGHT,UNLOADER,CENTRIFICAL,W/GSKT,W170 ASSY, W / GASKET,INCLUDES 12, 13, 14, 15, 16, 17	1 EA
88	310-1016	VALVE,UNLOADER,CENTRIFICAL,ASSY,EQ174 ASSY. INCLUDES 20, 21, 22, 23, 24	1 EA

## Parts List for Model W & WU

NOTE: The quantity number indicates the total number of pieces required for a complete pump repair.  
When ordering parts give compressor model, serial number and part number. Order assemblies when possible.

<u>REF. NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
89	610-1054	UNLOADER,CENTRIFICAL,W/B CAP,ASSY,W175 ASSY. W / BEARING CAP, TUBING AND GASKET	1 EA
90	610-1045	PLATE,VALVE,W/VALVES,ASSY,L140 INCLUDES 49, 54, 56, 82(2), 83(2)	1 EA
91	610-1052	PLATE,VALVE,RIGHT,W/VALVES,ASSY,W140 56, 65, 66, 82(4), 83	1 EA
92	610-1013	PISTON,HIGH PSI,W/RINGS&PIN,ASSY,EQ132 INCLUDES 26, 27, 28, 35, 36, 37, 38	1 EA
93	310-1008	HEAD,UNLOADING,K&G,W/1/2"PRT 6 HLE,LU180 COMPLETE W / UNLOADERS ( LEFT HEAD )	1 EA
94	310-1013	HEAD UNLOADING,SVC REPLACEMENT,EQ180 COMPLETE W / UNLOADERS ( RIGHT HEAD )	1 EA
NOT SHOWN	610-1132	KIT,BASIC,REPAIR,W PUMP,W101 KIT INCLUDES 49, 56(2), 59(2), 65, 69, 82(6), 83(3), 85(2)	1 EA
NOT SHOWN	610-1050	KIT,GASKET,W PUMP,ASSY,W100 KIT INCLUDES 12, 49, 56(2), 59(2), 65	1 EA
NOT SHOWN	610-1133	KIT,BASIC,REPAIR,WU PUMP,WU101 KIT INCLUDES 49, 56(2), 59(2), 65, 69, 82(6), 83(3), 85(2) , 94(4)	1 EA
NOT SHOWN	105-1209	OIL,PUMP,SYNTHETIC,BLUE,1 QUART,ESQ	2 EA
NOT SHOWN	105-1210	OIL,PUMP,SYNTHETIC,BLUE,1 GALLON,ESG	1 EA
NOT SHOWN	610-1225	KIT,ELEMENT,FILTER,G54E,PKG OF 4,G54EP	1 EA
NOT SHOWN	610-1186	KIT,ELEMENT,FILTER,L54E,PKG OF 4,L54EP	1 EA