





Model XCV16ZX Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	144486-9	BATTERY COVER COMPLETE	1 PC.
	C10 891977-8	CAUTION LABEL	1 PC.
002	855W77-6	XCV16 NAME PLATE	1
003	455734-4	GRIP	1 PC.
004	459262-1	SWITCH BUTTON	1
005	234273-5	COMPRESSION SPRING 20	2 PC.
006	266340-8	TAPPING SCREW 4X65	6 PC.
007	144973-8	COWLING COMPLETE	1 PC.
	D10	INC. 8,9	
008	263005-3	RUBBER PIN 6	4 PC.
009	424688-6	TOP DAMPER	1 PC.
010	266326-2	TAPPING SCREW 4X18	2 PC.
011	451343-7	SWITCH HOLDER	1 PC.
012	686023-8	RECEPTACLE SLEEVE	8 PC.
013	651098-6	SWITCH 1703.4801	1 PC.
014	961062-2	STOP RING E-12	1 PC.
015	620649-6	LED CIRCUIT	1 PC.
016	631922-9	SUB CONTROLLER	1 PC.
017	961013-5	STOP RING E-7	1 PC.
018	140H44-7	SWITCH BASE COMPLETE	1 PC.
	C10 812D41-6	INDICATION LABEL	1
	C20 818H47-6	SWITCH LABEL	1 PC.
019	213176-6	O RING 14	1 PC.
020	455733-6	SWITCH LEVER	1 PC.
021	213054-0	O RING 9	1 PC.
022	451344-5	SWITCH DIAL	1 PC.
023	455728-9	BATTERY COVER HOOK	1 PC.
024	231240-1	COMPRESSION SPRING 7	1 PC.
025	644808-8	TERMINAL	2 PC.
026	455729-7	TERMINAL BASE	1 PC.
027	620726-4	CONTROLLER	1 PC.
028	457609-3	CONTROLLER HOLDER	1 PC.
029	651910-0	SWITCH D2VW-01-3HS	1 PC.
030	686039-3	RECEPTACLE SLEEVE	1 PC.
031	424981-8	SPACER	1 PC.
032	424980-0	CAP	1 PC.
033	252268-6	HEX. NUT M6	1
034	455726-3	SEPARATER	1 PC.
035	253752-4	FLAT WASHER 8	1 PC.
036	240178-9	FAN 104	1 PC.
037	313062-2	FLANGE	1 PC.
038	424685-2	RUBBER RING 60	1 PC.
039	123974-9	MOTOR ASSEMBLY	1 PC.
	D10	INC. 66-76	
040	424686-0	RUBBER RING 120	1 PC.
041	424687-8	SUPPORT RING	1 PC.
042	424690-9	REAR BLOCK FILTER	2 PC.
043	143175-3	TANK COVER COMPLETE	1 PC.
	D10	INC. 44,45	

044	424691-7	BAND DAMPER	1 PC.	
045	424689-4	FRONT DAMPER	1 PC.	
048	197166-6	POWDER FILTER H SET	1 PC.	
049	423398-2	DAMPER	1 PC.	
050	195553-3	PRE-FILTER COMPLETE	1 PC.	
051	422148-2	BUMPER	1 PC.	
052	424382-0	RUBBER HOLDER	1 PC.	
053	266257-5	TAPPING SCREW 4X28	3 PC.	
054	419351-4	HOLDER PLATE	1 PC.	
055	419350-6	HOLDER	1 PC.	
056	421468-1	CORD SEAL	1 PC.	
057	266192-7	TAPPING SCREW 4X14	4 PC.	
058	213655-4	O RING 56	1 PC.	
059	451348-7	INLET	1 PC.	
060	168537-4	HOOK	2 PC.	
061	168535-8	CASTER 50	2 PC.	
062	168434-4	CASTER 50	2 PC.	
063	649150-2	EARTH LINE 120	1 PC.	
064	191B57-5	TANK ASSEMBLY SET B	1	
	D10	INC. 51-63		
065	347171-5	FAN COVER	1 PC.	
066	266326-2	TAPPING SCREW 4X18	3 PC.	
067	457486-3	FAN BASE	1 PC.	
068	266326-2	TAPPING SCREW 4X18	4 PC.	
069	619431-8	ROTOR	1 PC.	
070	652069-6	FLAT HEAD SCREW M3X6	3 PC.	
071	632J83-8	LEAD UNIT	1 PC.	
072	183F90-5	MOTOR HOUSING SET	1 PC.	
	D10	INC. 73		
073	183F90-5	MOTOR HOUSING SET	1 PC.	
	D10	INC. 72		
074	629256-2	STATOR	1 PC.	
075	620648-8	CONTROLLER B	1 PC.	
076	266490-9	TAPPING SCREW PT 2X6	3 PC.	
077	620755-7	WIRELESS UNIT COMPLETE	1 PC.	
A01	195433-3	HOSE COMPLETE 28-3.5 SET	1 PC.	
	C10	417191-4	CUFF LOCK	1 PC.
	C20	417586-1	STOPPER	1 PC.
	C30	417662-1	SLEEVE	1 PC.
	C40	417766-9	FRONT CUFF 38	1 PC.
	D10	INC. A03,A04		
A02	195432-5	POLY BAG SET(650X650)	1 PC.	
A03	417765-1	FRONT CUFF 22	1 PC.	
A04	424379-9	FRONT CUFF 24	1 PC.	
A05	455732-8	TOOL BOX	1 PC.	