



A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	815C82-5	XPH01 NAME PLATE	1	
	802R26-4	XPH01CW NAME PLATE	1	
	804V36-1	XPH01RW NAME PLATE	1	
002	188971-2	HOUSING SET	1	PC.
	188970-4	HOUSING SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 19		
003	266429-2	TAPPING SCREW 3X16	9	PC.
004	126289-3	SPEED CHANGE LEVER ASSEMBLY	1	PC.
	C10 233438-6	COMPRESSION SPRING 4	2	PC.
005	419250-0	F/R CHANGE LEVER	1	PC.
006	650731-7	SWITCH C3HZ-1A-TLMS	1	
007	620012-3	LED CIRCUIT	1	PC.
008	643852-2	TERMINAL	1	PC.
009	251468-5	- FLAT HEAD SCREW M6X22	1	PC.
010	766008-1	KEYLESS DRILL CHUCK 13	1	PC.
011	126460-9	GEAR ASSEMBLY	1	
012	638425-4	YOKE UNIT	1	PC.
013	619263-3	ARMATURE	1	PC.
014	638494-5	BRUSH HOLDER COMPLETE	1	PC.
015	CB440	CARBON BRUSH CB-440 (195021-6)	1	SET
016	263032-0	RUBBER PIN 4	2	PC.
017	452205-2	REAR COVER	1	PC.
	452202-8	REAR COVER	1	PC.
018	266429-2	TAPPING SCREW 3X16	2	PC.
019	188971-2	HOUSING SET	1	PC.
	188970-4	HOUSING SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 2		
020	232182-2	LEAF SPRING	1	PC.
021	689170-4	HEAT SINK	1	PC.
022	911013-5	PAN HEAD SCREW M3X10	1	PC.
023	802P77-5	CAUTION LABEL	1	
024	424476-1	CUSHION	1	PC.
A01	251314-2	+ SCREW M4X12	1	PC.
A02	346449-3	HOOK	1	PC.
A03	784637-8	+ BIT 2-45	1	PC.
A04	142146-7	PLASTIC CASE COMPLETE	1	PC.
	141856-3	PLASTIC CASE COMPLETE	1	PC.
	C10 162302-3	LATCH	2	PC.
	C20 324207-7	SHAFT	1	PC.
	C30 451749-9	HANDLE	1	PC.
A05	450128-8	BATTERY COVER	1	PC.
A06	***DC18RC	DC18RC FAST CHARGER	1	PC.
A07	BL1830	BATTERY BL1830 SET	2	SET
	BL1815	BATTERY BL1815 SET		
	BL1820	BATTERY BL1820 SET		